
Kindle + KOREader

A layperson handoff guide

Send books, read PDFs comfortably, connect by SSH, and always return to the normal Kindle interface.

Prepared for this device

Kindle Paperwhite 10th generation (PW4)

Firmware 5.18.1; Sanctuary jailbreak; KPM; KOREader kindlehf

Last observed address: 192.168.1.109; KOREader SSH port: 2222

lazing.art • flow.lazing.art

Contents

1	Start here	2
1.1	What is installed	2
1.2	What KOREader can open	2
2	Moving between KOREader and the normal Kindle	2
2.1	Enter KOREader	2
2.2	Return to the normal Kindle interface	2
2.3	Autostart and the recovery switch	2
3	Send books by USB cable	3
3.1	Books placed on this Kindle	3
3.2	Keep sidecar folders when backing up	3
4	Recommended: use Kindle Book Sender	4
4.1	Recommended first connection: no-password Wi-Fi bootstrap	4
4.2	USB pairing fallback	4
4.3	Every wireless transfer after pairing	4
4.4	Platform notes	5
5	Kindle Book Sender 1.3	5
6	Send books over Wi-Fi with SSH	5
6.1	Before connecting	5
6.2	Open a shell from Windows	5
6.3	Send books wirelessly	5
6.4	Manual SCP command	6
6.5	Use WinSCP instead of commands	6
7	Where files live	6
8	Everyday KOREader use	6
8.1	Open menus and books	6
8.2	Make a PDF easier to read	7
8.3	Useful PDF controls	7
8.4	Rotate the screen	7
8.5	Highlights, notes, and dictionaries	7
9	Return to the normal Kindle system	7
9.1	Normal exit	7
9.2	If KOREader is unresponsive	8
9.3	Recovery marker	8
10	Dedicated handoff SSH key	8
10.1	Important warning	8
10.2	Install the public key again over USB	8
10.3	Revoke this key	8
10.4	Embedded private key	9
11	Troubleshooting	9
12	Safe maintenance	9
13	Package contents	10
14	References	10

1 Start here

The easiest everyday workflow

1. In KOREader, open the File Browser.
2. Find books under `/mnt/us/documents/`.
3. To add books with a cable, exit KOREader first, connect USB, and copy into the Kindle's `documents` folder.
4. To add books over Wi-Fi, start KOREader's SSH server and use the included `send-books-to-kindle.ps1`.
5. To return to Amazon's normal Kindle interface, choose **Exit KOREader**. It does not remove KOREader or the jailbreak.

1.1 What is installed

Component	Purpose
Sanctuary	The jailbreak used on firmware 5.18.1. It installed the modern Kindle package stack.
KPM	Kindle Package Manager. KOREader was installed with <code>;kpm install koreader</code> .
KOREader	The reading application. This device uses the <code>kindlehf</code> build because firmware 5.16.3 and later is hard-float.
SSH server	KOREader's Dropbear SSH server, normally on TCP port 2222. It permits command-line access and wireless file transfer while KOREader is running.

1.2 What KOREader can open

KOREader supports PDF, EPUB, DJVU, MOBI, CBZ/CBT, DOCX, RTF, HTML, TXT, XPS, FB2, PDB, CHM, Mark-down, images, and several archive formats. Amazon books can still be read in the normal Kindle interface. KOREader is especially useful for PDFs, technical documents, multilingual material, comics, and sideloaded EPUB files.

2 Moving between KOREader and the normal Kindle

2.1 Enter KOREader

If the native Kindle Home screen is visible, tap the **KOREader** document/scriptlet in the library. KPM launches KOREader with the correct hard-float package.

2.2 Return to the normal Kindle interface

1. Tap near the top edge of the KOREader screen to reveal the top menu.
2. Open the main or hamburger menu.
3. Choose **Exit KOREader**.
4. Wait for the native Kindle Home screen to reappear.

Exit is not uninstall. Your books, settings, highlights, jailbreak, KPM, and KOREader remain installed. Open the KOREader library item whenever you want to return.

2.3 Autostart and the recovery switch

Autostart must always be optional and device-specific. The repository's accepted PW5SE deployment uses two persistent marker names at the visible USB root. The PW4 named on this guide's cover is a separate firmware/package family; do not copy the PW5SE root job to it.

<code>_DISABLE_KOREADER_AUTOSTART</code>	Parked regular file: autostart is enabled.
<code>DISABLE_KOREADER_AUTOSTART</code>	Active regular file: autostart is disabled and the native interface remains.

The state change is rename-only: never delete either marker. Disable by atomically renaming the parked name to the active name. Enable only through the audited manager, which checks the exact installed job hash before performing the reverse rename. The job gives the native system a recovery window, applies final safety gates, launches only once, and never respawns KOREader. Therefore choosing **Exit KOREader** returns to the normal interface for the rest of that boot.

Accepted PW5SE state. The production job SHA-256 is 2de0232b971926b7e70d913a27ba76168ed69760504ae2a90947e4402e7e5828. With USB data disconnected, reboot traced started -> native-ready -> launching; the job was start/running, KOREader was running, and Wi-Fi/SSH returned. The parked `_DISABLE_KOREADER_AUTOSTART` regular file is present and the active name is absent. The root filesystem is read-only and `preventScreenSaver=0`. Exiting KOREader left the job stop/waiting with no reader after at least 45 seconds, proving no respawn.

Disconnect USB **data** before boot. No cable, a wall charger, or a charge-only cable is safe. A computer data cable can enter USB Drive Mode and export or make unavailable `/mnt/us`, where KOREader and its marker live.

3 Send books by USB cable

USB is the simplest and most reliable method.

1. In KOREader, choose **Exit KOREader**.
2. Connect the Kindle to the computer with a data-capable USB cable.
3. Open the drive named **Kindle**.
4. Open the `documents` folder.
5. Create a clear folder such as `documents/Books` OR `documents/LinguaLeaf/en-main-blackwhite`.
6. Copy the book files into that folder.
7. Use Windows **Safely Remove Hardware / Eject** before unplugging.
8. Open KOREader and browse to the same folder.

KOREader may not expose normal USB mass storage while it controls the screen. If the Kindle drive does not appear, exit KOREader and reconnect the cable.

3.1 Books placed on this Kindle

The following five bilingual black-and-white PDFs were copied into `/mnt/us/documents/LinguaLeaf/en-main-blackwhite/`:

- A Game of Thrones
- A Clash of Kings
- A Storm of Swords
- A Feast for Crows
- A Dance with Dragons

3.2 Keep sidecar folders when backing up

KOREader commonly stores per-book progress, highlights, notes, and settings in a neighboring folder ending in `.sdr`. When moving or backing up an annotated book, copy both the book and its matching `.sdr` folder.

For the PW2-to-PW5SE migration, the completed initial 249-PDF snapshot copied no sidecars during its PDF transfer. The later guarded apply reported 10 copied sidecar trees and 239 skips: one existing destination, 161 not inspected, 68 absent or ambiguous, and nine checksum/current-PDF mismatches. Candidate identity used current PDF size and KOREader partial MD5 rather than stale metadata checksums. An independent audit matched every file in all 10 copied trees to its PW2 source by size and SHA-256, found no owned temporary files, and both keep-awake guards restored their original `preventScreenSaver=0` value.

Zizhi Tongjian, Part 1 was the existing-destination skip and was not overwritten. The PW5SE records page 11 while the PW2 records page 4651; both report 18079 document pages, and the full PDF SHA-256 matches Nutstore, PW2, and PW5SE. Preserving PW5SE state is the safe default. Its explicit transactional replacement path is implemented and tested but has not run; replacement awaits closing the book in KOREader/file browser and a separate guarded run. *Shiji* uses differently named or different-edition sidecars, so no match is guessed and none was copied.

The 249 count is an initial dated snapshot. A later Nutstore addition, *Giving Up the Gun...* | 黑白.pdf, increased the desired corpus to 250 (240 LinguaLeaf plus 10 PocketPolished); that new book is pending and is not yet claimed transferred.

4 Recommended: use Kindle Book Sender

For a layperson, the easiest method is the free Kindle Book Sender desktop app:

<https://lazying.art/eink>

Latest application downloads: <https://github.com/lachlanchen/Kindle/releases/latest>

Original project website without redirection: <https://lachlanchen.github.io/Kindle/?stay=1>

The website automatically recommends the correct download for Windows, Ubuntu/Linux, or macOS. The app removes the need to find an IP address, type SSH commands, or choose between SFTP and SCP.

4.1 Recommended first connection: no-password Wi-Fi bootstrap

1. Download and open Kindle Book Sender from the website.
2. In KOREader, stop SSH if it is already running, enable **Login without password (DANGEROUS)**, then start SSH again.
3. Enter the address and port displayed by KOREader, such as 192.168.5.26:2222. A hostname, IPv6 address, or another routed private subnet also works.
4. Check **First connection: KOREader allows login without password**, then click **Connect / find Kindle**.
5. The app creates a new RSA key for that computer, connects without a password once, installs only its public key, and verifies a second connection with the key.

The app-generated private key stays in that computer's user application-data folder. A new computer can repeat the no-password bootstrap without installing Python, SSH tools, or a key manually. The app does not disable KOREader's no-password option; leaving it enabled is convenient but allows any reachable client to attempt root access.

4.2 USB pairing fallback

Exit KOREader first so the Kindle drive can appear. Connect USB, click **Pair over USB**, safely eject, reopen KOREader, and start SSH. If KOREader remains open and the drive does not appear, use no-password Wi-Fi bootstrap instead; USB alone cannot modify storage that the Kindle has not exported to the computer.

4.3 Every wireless transfer after pairing

1. Put the Kindle and computer on the same trusted Wi-Fi, or on networks that can route to each other.
2. Open KOREader, then start **Tools > SSH server**.
3. In the app, click **Connect / find Kindle**.
4. Drag books into the app or choose them with the file picker.
5. Click **Send books**.

The app always tests a supplied address first, including hostname, IPv4, IPv6, custom port, and routed subnet addresses. It then scans every active private IPv4 interface as a fallback. A candidate is accepted only after authentication and confirmation that `/mnt/us/koreader` exists. Failures distinguish DNS, routing, closed port, timeout, passwordless rejection, and key rejection. Books are placed in `/mnt/us/documents/Books`; SFTP is used when available and SCP is selected automatically as a fallback.

4.4 Platform notes

- **Windows:** open the downloaded .exe. If SmartScreen appears, choose **More info**, then **Run anyway**.
- **Ubuntu/Linux:** extract the archive, allow the application file to run as a program, then open it.
- **macOS:** choose Apple Silicon or Intel on the website. Because the community build is not notarized, Control-click the app and choose **Open** the first time.

If discovery does not succeed, enter the exact address shown when KOREader SSH starts. Guest Wi-Fi and access-point client isolation can block two devices even when the Wi-Fi name is identical. On Windows, the app can request a UAC-approved outbound firewall rule, but that rule cannot repair router isolation or a missing route.

5 Kindle Book Sender 1.3

The desktop sender is available for Windows, macOS, and Linux. Version 1.3 adds an 11-language interface, automatic locale selection, a maximized responsive layout, Kindle storage usage, remembered Kindle addresses, the last book folder, and a persistent recent-transfer history.

On Windows, the packaged application maintains a per-user installed copy under %LOCALAPPDATA%/Programs/LazyingArt/KindleBookSender and creates a Start menu shortcut without administrator access. Use **Add to Start** or **Add to taskbar** inside the application when needed. Windows 11 may block automatic taskbar pinning; if so, right-click the running icon and choose **Pin to taskbar**.

The **Guide & downloads** button opens <https://lazying.art/eink>. The English and Simplified Chinese printable guides remain available directly at:

- <https://lachlanchen.github.io/Kindle/downloads/kindle-koreader-handoff.pdf>
- <https://lachlanchen.github.io/Kindle/downloads/kindle-koreader-handoff-zh-CN.pdf>

6 Send books over Wi-Fi with SSH

6.1 Before connecting

1. Connect the computer and Kindle to the same trusted Wi-Fi network.
2. Open KOREader on the Kindle.
3. Open the top menu, choose **Tools**, then **SSH server**.
4. Start the SSH server and keep KOREader open while transferring.
5. Note the Kindle's IP address. This guide uses 192.168.1.109 as an example; DHCP may assign a different address later.

KOREader's SSH service uses port **2222**, user **root**, and the dedicated key supplied with this package. It is separate from ordinary Windows Remote Desktop and from port 22.

6.2 Open a shell from Windows

Open PowerShell in the Handoff folder and run:

```
.\connect-kindle.cmd 192.168.1.109
```

The equivalent manual command is:

```
ssh -i .\keys\kindle_handoff_rsa -p 2222 root@192.168.1.109
```

The first connection may ask whether the host key is trusted. Confirm only after checking that the address belongs to your Kindle on your own local network.

6.3 Send books wirelessly

Use the supplied PowerShell helper:

```
.\send-books-to-kindle.ps1 -KindleIp 192.168.1.109 "C:\Books\Example Book.pdf"
```

To send several books, add each full path as another quoted argument. The helper creates /mnt/us/documents/Books if needed and uses legacy SCP mode for compatibility with KOREader's Dropbear SSH server.

6.4 Manual SCP command

```
scp -O -i .\keys\kindle_handoff_rsa -P 2222 "C:\Books\Example.pdf" root@192.168.1.109:/mnt/us/documents/Books/
```

SSH uses lowercase `-p`; SCP uses uppercase `-P`. The `-O` option selects the older SCP transfer protocol supported reliably by this Kindle setup.

6.5 Use WinSCP instead of commands

For drag-and-drop transfer, create a WinSCP site with:

Setting	Value
File protocol	SFTP first; if unavailable, select SCP
Host name	Kindle IP, for example 192.168.1.109
Port number	2222
User name	root
Password	Leave empty
Private key	Handoff\keys\kindle_handoff_rsa
Remote folder	/mnt/us/documents/Books

If WinSCP reports that SFTP is unavailable, change the protocol to **SCP**. It is acceptable to let WinSCP convert this dedicated key to PPK format.

7 Where files live

Kindle path	Purpose
/mnt/us/documents/	Books visible to the native library and KOReader
/mnt/us/documents/Books/	Recommended general KOReader book folder
/mnt/us/documents/LinguaLeaf/	Current LinguaLeaf collection
/mnt/us/koreader/	KOReader application; do not casually rename or delete
/mnt/us/koreader/settings/	KOReader preferences and SSH settings
/mnt/us/koreader/settings/SSH/authorized_keys	Public keys allowed to log in
/mnt/us/_DISABLE_KOREADER_AUTOSTART	PW5SE parked regular marker: enabled
/mnt/us/DISABLE_KOREADER_AUTOSTART	PW5SE active regular marker: disabled

The USB drive letter, such as F:, is selected by Windows and can change. The Linux path `/mnt/us` always means the user-visible Kindle storage.

8 Everyday KOReader use

8.1 Open menus and books

- Tap near the **top edge** to open KOReader's top menu.
- Tap near the **bottom edge** to open reading controls.
- In the file browser, enter `documents`, then tap a book.
- Tap the left or right side to move backward or forward.
- Long-press text for highlighting, dictionary lookup, search, or notes.

8.2 Make a PDF easier to read

1. Open the bottom reading menu.
2. Choose a crop mode to remove white margins.
3. Try **Fit width** for ordinary single-column pages.
4. Rotate to landscape when the page is too wide.
5. For text-heavy PDFs, enable **Reflow** so KOREader rearranges text to fit.

Reflow works best when the PDF contains a real text layer. A scan made only from page images may need OCR first. Reflow can disturb tables, equations, footnotes, and complex layouts; turn it off for those pages.

8.3 Useful PDF controls

- **Crop**: removes margins and enlarges print.
- **Fit width**: fills the screen horizontally.
- **Columns**: reads multi-column pages in sequence.
- **Landscape**: gives wide pages more space.
- **Contrast**: darkens faint scans.
- **Dewatermark**: can reduce pale backgrounds.
- **Auto-straighten**: corrects tilted scans.
- **Panel zoom**: helps with comics and image panels.
- **OCR**: supports selection or lookup from image text where available.

8.4 Rotate the screen

Open the reading menu and choose the rotation or orientation icon. Select portrait or landscape. Rotation is stored per book.

8.5 Highlights, notes, and dictionaries

- Long-press and drag across text, then choose **Highlight** or **Add note**.
- Use the bookmark control to mark the current page.
- Use the table of contents, page search, or text search from the top menu.
- Long-press a word for dictionary lookup after dictionaries are installed.
- KOREader stores progress, highlights, and book settings in a nearby folder ending in `.sdr`. Back up each book together with its `.sdr` folder.

Other features include adjustable typography for reflowable books, night mode, warm-light controls when supported, reading statistics, gestures, profiles, collections, OPDS catalogs, Wallabag, calibre wireless access, and cloud-storage plugins.

9 Return to the normal Kindle system

9.1 Normal exit

1. Tap the top edge to open KOREader's menu.
2. Open the main or tools menu.
3. Choose **Exit KOREader**.

This returns to Amazon's native Kindle interface.

9.2 If KOREader is unresponsive

Hold the power button until the device restarts; this can take roughly 40 seconds. On the accepted PW5SE job, a reboot launches KOREader once again unless the active recovery marker has been set. Choose **Exit KOREader** for a clean return without respawn during the current boot.

9.3 Recovery marker

For the accepted PW5SE deployment, disable autostart by renaming this parked regular file at the top level of the drive:

```
_DISABLE_KOREADER_AUTOSTART
```

to the exact active name:

```
DISABLE_KOREADER_AUTOSTART
```

Do not delete or create marker files, and do not guess if the parked file is missing or both names exist. Safely eject, disconnect USB data, and reboot. Re-enable only through the audited manager, which verifies the production job hash before reversing the rename.

10 Dedicated handoff SSH key

This package contains an RSA 3072-bit key pair made only for the owner's paired KOREader Kindles:

Item	Value
Private key	Handoff\keys\kindle_handoff_rsa
Public key	Handoff\keys\kindle_handoff_rsa.pub
Comment	AgInTi-Flow-Kindle-Handoff-ONLY
Fingerprint	SHA256:Q/RgMY4wzHjQYuc3sfHDykwp8ejp9C7wyfAZLE80MJE
Private-file SHA-256	D278BB1D9BB278371B4CFD162C4F6139F64D7AD079584F560B6CED57F4DF3B50
Passphrase	None, for simple appliance-style access

The public key must be present in KOREader's SSH authorization file before this handoff key can connect. Verify it or run the included USB installer. The private key is not a default Windows SSH key; supplied commands select it explicitly with `-i`.

10.1 Important warning

This private key is intentionally exposed in this PDF. Use it only for the owner's paired KOREader Kindles. Never authorize it on Windows, Linux computers, servers, routers, GitHub, cloud accounts, an unrelated Kindle, or any other device. Anyone holding this PDF can access a paired Kindle whenever KOREader SSH is running and reachable.

Copy the private-key file to a trusted computer only when its user should control this Kindle.

10.2 Install the public key again over USB

```
.\install-public-key-usb.ps1
```

The helper locates the mounted Kindle and appends the key only if it is absent.

10.3 Revoke this key

Open `/mnt/us/koreader/settings/SSH/authorized_keys`, delete the line ending in `AgInTi-Flow-Kindle-Handoff-ONLY`, then restart KOREader's SSH server. Deleting one copy of the private key does not revoke other copies; removing the public-key line does.

10.4 Embedded private key

Below is the complete Kindle-only private key. Prefer the separate file because copying from a PDF can alter characters or line endings.

```
-----BEGIN OPENSSH PRIVATE KEY-----
b3BlbnNzaC1rZXktZjEAAAABG5vbmUAAAABm9uZQAAAAAAAAABAAABlWAAAAdzc2gtcn
NhAAAAAwEAAQAAAEAA2neq13LIz1my1v02fc9o18QMvzemiqMYR1m101hP0Xpu+n8yC+Kry
Mu10nSpKt/pv/jiF02YUPFGmncPCefU3dg1GyFJx+D3DpCwacINK4EtK/E2VhMmB9e2fsXT
OzDCOYt3g0S41JyDz3uiHHPJKhcFN8hfh0QZ6CS+KTj1BbjHb9hNlmeckj4ML2nUG+qX
/ipsUvyIkQzQuCEf2uyxqxPL+TePpGdnSXNXY1XkRKfMr1fkWVA251kXFzs2qn9VPALBQf
jf4tktcA1Mu6yak7z0FNBbbGjw932R9JxJh/NrA6TsKzaBGgSaDBVC7eFNwE+yKeeechMM
W+s+JFgG3SXjAwX8x8GHRyW7ZVE3AR+c3gMd3nfiE+A0u1aVQxGgO6Tbs8IrmXbxQgRCMu
G+vwj2a28p0Coh4y7P5KUcU17GerjSD8R7QFb050H2dyM2TUEySU0FNqSjyvE4hMDJD0sW3
vb0hjU5UkNvBZz1Ip5CWtLFtaDnERuoEXksK1nC9AAAFmBvxvFEcb8XxAAAAAB3NzaC1yc2
EAAAGBANp3gtdyM9Zspb9Nn3PaNfEDL83poqjGEZzpdNYT16bvp/Mgviq8jLpTp0qSrf6
Vf44hdNmFdxRjXDwnn1N3YNrshScfg9w6QsGnCD5uBLsvxN1YTJgFxtN7F0zswjme3N4N
EuNscg897ohxzySoXBTfIX4TkGegkvik49QW4x2/YTS5nnICo+DC9p1Bvq1/4qbFL8iJEM
0LNBdrssasTy/k3j6RnZ01zV2JV5ESnzK5X5MFQNuZZFxc7Nqp/VTwCwUH43+LZLXANTL
usmp089BTQW2xicPd9kfScSYfzaw0k7Cs2gRoEmgwVQu3hTCBPsiinnnnITDFvrP1Raht0l
4wMMfMfB62Fu2VRNwEfnN4Dhd534hPgDrpW1UMRoDuk27PCK5128UIEQjLhvsL42tvkda
qIeMuz+SlHFCOxnq40g/Ee0BWzudB9ncptk1BMk1NBtako8rx0ITAyQ9Lf729IY1LFJDb
wWc9SKUglrSxbWg5xEbqBF5LCtZwvAAAAAMBAAEAAAGAKaYsRcw20EFzaJGRZ964sBmyDG
pb18CMCi1hDa+SQgkTCEfm2B102yHbWN8NK5HP/w0rhie5x94MRvG4ZU8I4dYbSw61gbMW
2oFCFoFVi9EdmEcFhqMaiQJA72vBwJiwmnSbXYWfoHwJwf82cvgBGMXfZD31NAfmEAY+Kb
hH1guVPVMvrmvn14A2LEmpMQ2gb/4ssFUd6kPybngseHZ5TF6+2H6Qm9sI3aXvc1/wQ70
WHBTLvQ8fMeEdG6FDr93JF91tgNTrxfciXq+jrjX3qNwXSh5MhGoNnsq7K1OyOga80km
ESYFjYrTLGF3X1KM8NBnTviox4NSuBU+EKrasEmXqo1FXAk5ibTtOUK+KvXxDSYnczkrg
SNPFFtOp/CcCCTG68vtpo3AXoc8rWUeUvGAfQyQ0FTqWEtX0zTa3Yf1j7JnLmOX7FedSR
1HqMFAXL4A9WhqYueABY1bMx1ImH0CC+TqvTGm8p5xHnyAyktFQBNSAcoJZuqMkQ3BAAAA
wGmplWl1+1GoNqCZksCj32gYn3deNGGduwNZmkID1EXdTHN1f5p5A1Wg8pOJtB5H8UBj8R
xd3IKTDPOpEaKQVsvNdqApfTKOhnAabN8owDS9wEJ3KF4VEzZSLVJLADHRfBg85wvkU6ID
brVB3hV7d+KXyrGmNPLGw0XMs0nex8XlWnuV3ysyh9BxeF+vjpPyKR8bIQ1UimUg1DeQ07
1EMwEC1ZVsGQIMKUAR9R24X9vCDUYPXot58cB39++TyW0vqAAAAAMEA+GGadZyQQ0010+aR
jq1kNc3r9g9fESBznfM0ZGw6G8B5YAeFtqhn/Y62X+icwUXq3ZZ8/B/YowwP4EGC15d0
6hkp+8HHCAkUzyJmld/rgbT9Ck+mnkaodGjxhCQUOt/UBu5Fj1RqOdnGg2tMBDTcdpSrV
Gp8fKpA0pCypZMRncytnws8vc/umIt06rmR4z2d15M/7D1I0KgVcOH2zP/nX5eJNyOuqEN
D3D+Hxk1A80i9paW5Woeu2F9kI1S1N1AAAAwQDhKyr3ET44e+X5ly19N9deG8mjzLQpSmId
1CuLE7zRmRj/VwXe4B39fZIA0nE3yGpg1yU1PovG3M9HfPcMePXUSROIIFGuwVUPkk/L03
bne82CvkduM/iUKf4dBpPAVsrw+L7HABVsd/a89CrdZNIjQ1yWlrNRszDdxhrQvBtsb2vR
D6AbewTzzjOPGNg70c0+9abm0stAD27cy9Ji00FdroKuM8IGXwjC6beGq0vtEpgv6I5bJr
A2t1h1p6krVyKAAAAAQWdJb1RpLUZsb3ctS2luZGx1LUhhbmRvZmZyT05MMwQECawQ=
-----END OPENSSH PRIVATE KEY-----
```

11 Troubleshooting

Symptom	Action
Connection timed out	Confirm the same Wi-Fi, current IP, running KOReader SSH, and port 2222.
Connection refused	Start SSH from KOReader and keep KOReader running.
Permission denied	Select the key with -i; reinstall its public key over USB if needed.
Host identification changed	Verify the device first, then run ssh-keygen -R [192.168.1.109]:2222.
SFTP unavailable	Use SCP in WinSCP or add -o to scp.
Book missing	Put it under documents, eject safely, then refresh the file browser.
PDF text tiny	Crop, fit width, rotate to landscape, or try reflow.
Bad reflow	Disable it and use crop, landscape, columns, or OCR.
Need native Kindle	Exit KOReader; the accepted PW5SE job will not respawn it during that boot. For the next boot, activate the recovery marker by rename.

12 Safe maintenance

- Keep airplane mode on when network access is unnecessary.
- Safely eject the Kindle in Windows before unplugging USB.
- Do not delete jailbreak preservation files, koreader, KUAL/KPM components, or unfamiliar top-level files.
- Back up documents, KOReader settings, and all .sdr folders before major changes.

- Do not install Amazon firmware until its jailbreak compatibility is checked.
- Stop KOREader SSH after wireless administration.

13 Package contents

File	Purpose
kindle-koreader-handoff.pdf	Printable guide
kindle-koreader-handoff.tex	XeLaTeX source
connect-kindle.cmd	One-command Windows SSH
send-books-to-kindle.ps1	Wireless book transfer
install-public-key-usb.ps1	Idempotent public-key installer
ssh-config.example	Optional SSH alias template
build-guide.ps1	Rebuilds this PDF
keys/kindle_handoff_rsa	Kindle-only private key
keys/kindle_handoff_rsa.pub	Matching public key

14 References

- KOREader User Guide: https://koreader.rocks/user_guide/
- KOREader source: <https://github.com/koreader/koreader>
- KindleModding KOREader guide: <https://kindlemodding.org/jailbreaking/post-jailbreak/koreader.html>
- Sanctuary documentation: <https://kindlemodding.org/jailbreaking/Sanctuary/>
- AgInTi Flow: <https://flow.lazying.art>
- LazyingArt LLC: <https://lazying.art>

Prepared by AgInTi Flow, LazyingArt LLC

<https://flow.lazying.art> • <https://lazying.art>

Handoff edition dated August 9, 2026