

Release Note

EaseLoc V3.25

<u>Reference</u> :	EG_EaseLoc_V325_RN_001_UK
<u>Revision</u> :	001
<u>Date</u> :	22/01/2021

Document History

Rev.	Modifications	Author	Date	Validation	Date
000	Creation	MRE	09/12/2020	MAI	11/01/2021
001	GenLoc341e platform added after validation	MAI	22/01/2021	MAI	22/01/2021

The main modifications of this document compared to the previous version are easily identifiable on a screen by the blue colour of the text.

CONTENTS

1	GENERAL.....	4
1.1	PREVIOUS VERSION	4
1.2	THIS VERSION.....	4
2	RESOLVED ISSUES	4
3	NEW FEATURES AND FUNCTIONS	4
4	KNOWN ANOMALIES AND LIMITATIONS	4

1 General

The binary files have been built with **GCC arm compiler 4.2.2**.

The objects in the flash memory are NOT compatible with the previous version. The flash memory must be erased to ensure correct operation.

1.1 Previous version

- **EaseLoc_V324_EGM432b5_boot_sdram_izo.bin** is intended to be used with a bootloader on the GenLoc 41e / 341e / 54e / 354e platforms only.

1.2 This version

- **EaseLoc_V325_EGM432_boot_sdram_izo.bin** is intended to be used with a bootloader on the GenLoc [341e](#) / 354e platforms only.

2 Resolved issues

- Removed unsolicited "+UCCELLINFO" messages.
- ID0003637: Problem with the history read index and frame repetition.
- Increased maximum allowed GPS speed from 255kmh to 400kmh to allow use with high-speed trains.
- ID0003824: Application blocking when geo-fencing is active AT+EGGEOF=0,1/2/3 and a request is made to log a gps frame, manual, cyclic.
- ID0003522: No "OK" response is returned if the command AT+EGCMGS="numTel","text" is received via SMS or TCP.
- Fixed AT+EGCMGS command sent from terminal not sending responses to terminal. To display the responses "+CMGS: xx" and "OK" (or "ERROR") then the trace must be disabled with AT+LOCTRC=0.
- ID0003503: The command AT+LOCUTC now manages 15 minutes local time offsets, offset range is "-11:45" to "+12:00" in steps of 15 minutes.

3 New features and functions

- Modified command AT+LOCRST to be able to reset ARM/GSM after a time interval.
- ID0003707: Added command AT+LOGGPSNMEA to send selected GNSS NMEA frames at chosen rate to either the main V24 serial port or the extended serial port 1.
- Added command AT+LOCSIMTKIT to configure the automatic activation of the SIM-toolkit in the GSM module.

4 Known anomalies and limitations

- As this revision has only been validated on the GenLoc 354e and [GenLoc 341e](#), it is intended to be used with a bootloader on [these platforms](#) only.
- Please contact ERCOGENER for further information.
- See the EGM Library User Guide.