Overview

This Host HID dual example is a simple demonstration program based on the MCUXpresso SDK.

The application supports the mouse device for two usb ports simultaneously. The two USB ports are independent. It prints the mouse operation when the mouse device is attached.

System Requirement

Hardware requirements

- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower module/base board, and so on) for a specific device
- Personal Computer (PC)

Software requirements

• The project path is:

<MCUXpresso_SDK_Install>/boards/<board>/usb_examples/usb_host_hid_mouse_dual/<rtos>/<toolchain>.

Note

The <rtos> is Bare Metal or FreeRTOS OS.

Getting Started

Hardware Settings

Note

Set the hardware jumpers (Tower system/base module) to default settings.

Prepare the example

- 1. Download the program to the target board.
- 2. Power off the target board and power on again.
- 3. Connect devices to the board.

Note

For detailed instructions, see the appropriate board User's Guide.

Host hid example doesn't support HID report descriptor analysis, this example assume that the device data are sent by specific order.

For more detail, please refer to the code. For the device list we tested,

please refer to chapter "Peripheral devices tested with the USB Host stack" in "SDK Release Notes xxxx(board name)".

Run the example

- 1. Connect the board UART to the PC and open the COM port in a terminal tool.
- 2. Plug in the HUB or the mouse device to either of the two USB ports. The attached information prints out in the terminal.
- 3. The mouse operation information prints in the terminal when you operate the mouse.

The application prints the mouse operation information in one line. Each line contains the following sequential string: "Left Click", "Middle Click", "Right Click", "Right"/"Left" movement, "UP"/"Down" movement and "Wheel Down"/"Wheel Up" movement. White space replaces the above string if the mouse doesn't have the corresponding operation.

For example, when the mouse moves right and up,

Right UP

prints in the terminal.

The following figure is an example to attach one mouse device for each of two usb ports.

```
host 1 init done
host 2 init done
the host stack version is 1.0.0.
hub attached:level=1 address=1
hid mouse attached:pid=0xc077vid=0x46d address=2
mouse attached
Left Click
                       Right Click
                       Right Click Left Down
                                         UP
                                         UP
                                         UP
                                   Right UP
                                   Right UP
                                         UP
                                         UP
hid mouse attached:pid=0x2510vid=0x93a address=1
mouse attached
                                   Right Down
                                   Right Down
                                   Right
                                   Right Down
                                   Right
                                   Right Down
```

Figure 1: Attach mouse