BPS C1F Calibration

- 1. Turn off BPS C1. Turn it on again and while machine is loading keep pressed **CUR** and **INFO** buttons while you will see maintenance mode on the screen, release the buttons and wait while machine loads on maintenance mode.
- 2. Enter password **000000** and confirm it with button (▶).
- 3. At the next window select (4. Calibration mode) and confirm it with button (▶).
- 4. Select (Initialize (ERASE) and confirm it with button (▶) 2 times. This step is required to delete old calibration data.
- 5. Select (2. Ver2-[c]CIS 100 100) and press button (▶) 2 times.
- 6. Open upper BPS C1 module and insert calibration media (**picture 1**), with written numbers on the down side (**picture 2**).
- 7. Close upper BPS C1 module and press button (▶), to calibrate the image sensor.
- 8. When the calibration finish, you should see green confirmation sign \checkmark , otherwise please contact us.
- 9. Open upper BPS C1 module, remove calibration media and close the upper BPS C1 module.
- 10. Select (1. VER1 All) and press button (►) 2 times.
- 11. Insert blank papers in machine singler (same as counting money) and wait while machine calibrates all other sensors.
 - a. If calibration is successful you should see OK in the blue screen.
 - b. If calibration is not successful and there are no **OK** sign please feed all calibration papers again until you will see **OK** sign.
- 12. Remove calibration papers from the pocket and from the singler and go back to the menu by pressing button (C).
- 13. Select (**EXIT**) and confirm it with button (▶).
- 14. Turn off the machine.
- 15. Turn it on normally by pressing power button.

Calibration is successful

Calibration media (Picture 1)



Inserted calibration media (Picture 2)

