

MOTOR STARTER CONTROL

The diagram illustrates five parallel motor control circuits, each for a different hydromotor (M1A to M5). Each circuit is connected to a common power supply at the top and a common ground at the bottom, labeled "NO? NC".

Components in each circuit:

- Breaker (CB):** CB1, CB2, CB3, CB4, and CB5 are located at the top of each branch.
- Overload Relay (OL):** OL1B, OL2, OL3, OL4, and OLR5 are connected in series with the breakers.
- Stop Button (PB):** PB1E, PB2, PB3, PB4, and PB5 are normally closed stop buttons.
- Start Button (PB):** PB1E2, PB1E4, PB1E5, and PB1E6 are normally open start buttons. Each start button is interlocked with a normally closed contact (M5-13, 14) of the motor it controls.
- Motor (M):** M1A, M2, M3, M4, and M5 are the hydromotors, represented by circles with terminals A1 and A2.

Wiring: The power line at the top connects to the breakers. The ground line at the bottom connects to the motors. The stop buttons are wired in series with the start buttons. The interlocking contacts are wired in series with the start buttons.

C:\USERS\ADMIN\DOCUMENTS\ACADE 2016\AEDATA\PROV\LUCKY TEMPLATE\4592.DWG

[illegible]