


Busch Microtronic 2090 — a programmer's guide

How to operate and program the 1981 Busch Microtronic 2090, written for the [browser emulator](#), which runs the machine's original firmware. Everything described here was tried on that firmware. This is an independent guide in its own words. The original manuals, with many more programs and experiments, are available [in English translation](#).

1. The machine

The Microtronic is a 4-bit teaching computer. Inside, a TMS1600 microcontroller runs a fixed program, the firmware, which makes the box behave like a simple imaginary computer with its own instruction set. That imaginary computer is what you program. Everything in it is a single hexadecimal digit, 0 to F: one *nibble*, four bits.



The Microtronic console in the emulator. Top right: the computer board with outputs, reset key, inputs and clock. Bottom: flag LEDs, display and keypad.

- **Program memory.** 256 places, addresses 00 to FF. Each holds one instruction of three hex digits, such as 510.
- **Sixteen working registers,** 0 to F. Each holds one hex digit. This is where a program keeps its numbers; there is no other data memory.
- **Sixteen memory registers,** a second bank of the same size. A program cannot work on them directly, only copy to them and swap them with the working registers.
- **Two flags,** carry and zero, each with an LED. Instructions set them as a side effect, and two jump instructions test them.
- **A six-digit display,** which shows registers, never memory, while a program runs.
- **Four outputs and four inputs,** a 1 Hz clock signal, and two red push buttons, G and H, that can be wired to inputs.

Programs cannot change the program memory, and data cannot be executed: instructions and numbers live in separate worlds.

Add-ons


The Microtronic was sold with a few companions, and many experiments in its manuals add small circuits to its terminals. The emulator draws or offers these:

Add-on	What it is	In the emulator
2095 cassette interface	A board that plugs in beside the computer and saves programs to, and loads them from, an audio cassette ((PGM 2) and (PGM 1)).	Drawn for completeness, but it does nothing: its start key is inert, and PGM 1 or PGM 2 waits for a tape forever (press reset). Use the Save and Open buttons instead.
Piezo buzzer	A small sounder wired between an output and ground. It beeps while that output is on.	The "Piezosummer" block, wired to output 1, 2, 3 or 4 (most of the manuals' games use output 1).
Tone circuit	A two-transistor oscillator (astable multivibrator) built from parts of the Busch electronics kits, wired to all four outputs. The value on the outputs sets the pitch.	The "Tongenerator / Multivibrator" block, switched on in the Sound panel. Values 4–F give twelve tones, 0–3 silence.
Red keys G and H	Two push buttons on the front panel, not connected to anything until you wire them to inputs (through a resistor from the supply).	Wired to an input of your choice; the wires and the 4.7 kΩ resistor are drawn.
Patch cables	Wires between terminals: most often the 1 Hz clock to input 4 (needed by the built-in clock), or an output to an input.	Both, selectable in the Patch cable panel.
PicoRAM 2090	A modern replacement for the program memory chip, with storage and extra functions such as sound.	Only its sound instruction (50D) is emulated.

Loading a program from the emulator's library wires up what that program needs.

2. Operating it

When the machine is not running a program, the display shows an address at the left and the instruction stored there at the right: **00 F10** means address 00 holds F10.



The front panel: red keys G and H, carry and zero LEDs, display, hex keys and function keys.

Keys	What happens
HALT NEXT then two hex digits	Go to that address. HALT NEXT 0 0 goes to the start.
three hex digits, NEXT	Stores the instruction at the address shown and moves to the next address.
NEXT alone	Moves to the next address without changing anything: use it to read a program back.
C/CE	Deletes the last digit you typed. NEXT only stores once three digits are there.
RUN	Runs the program from the address shown.
HALT	Stops a running program. RUN then continues from where it stopped.
STEP	Carries out one instruction and stops.
REG then a hex digit	Shows that working register, e.g. 1 9 : register 1 holds 9. A further hex digit changes its value. HALT returns.
BKP then two hex digits	Sets a breakpoint: a running program stops when it reaches that address. BKP 0 0 removes it.
PGM then a digit	Calls a built-in function; see section 11 .
the green reset key	Restarts the firmware. The program stays in memory; the registers and the clock are cleared.

Entering a program: **HALT** **NEXT** 0 0, then three digits and **NEXT** for each instruction.
Starting it: **HALT** **NEXT** 0 0 **RUN**.

In the emulator you can skip the typing: pick a program and press **Load & run**, or click a line in the **Inside** panel and edit it. The whole keypad is also on the PC keyboard: **H** **HALT**, **N** **NEXT**, **R** **RUN** and so on, so **H N 0**

0 R starts a program.

3. The instructions

An instruction is three hex digits. The first says what to do; the other two say with what. In the table, *s* and *d* are register numbers (source and destination), *n* is a constant 0–F, and *aa* is a two-digit address.

Code	Name	What it does
0sd	MOV <i>s,d</i>	Copy register <i>s</i> to register <i>d</i> .
1nd	MOVI <i>n,d</i>	Put the constant <i>n</i> into register <i>d</i> .
2sd	AND <i>s,d</i>	$d := d \text{ AND } s$, bit by bit.
3nd	ANDI <i>n,d</i>	$d := d \text{ AND } n$.
4sd	ADD <i>s,d</i>	$d := d + s$.
5nd	ADDI <i>n,d</i>	$d := d + n$.
6sd	SUB <i>s,d</i>	$d := d - s$.
7nd	SUBI <i>n,d</i>	$d := d - n$.
8sd	CMP <i>s,d</i>	Compare register <i>s</i> with register <i>d</i> ; only the flags change.
9nd	CMPI <i>n,d</i>	Compare the constant <i>n</i> with register <i>d</i> ; only the flags change.
Asd	OR <i>s,d</i>	$d := d \text{ OR } s$, bit by bit.
Baa	CALL <i>aa</i>	Jump to the subroutine at <i>aa</i> , remembering where to come back to.
Caa	GOTO <i>aa</i>	Jump to <i>aa</i> .
Daa	BRC <i>aa</i>	Jump to <i>aa</i> if the carry flag is set.
Eaa	BRZ <i>aa</i>	Jump to <i>aa</i> if the zero flag is set.

Codes beginning with F are a second family without a source register:

Code	Name	What it does
F00	HALT	Stop the program.
F01	NOP	Do nothing.
F02	DISOUT	Switch the display off.
F03	HXDZ	Convert the hex number in registers D, E, F to decimal digits (section 7).
F04	DZHX	The reverse: decimal digits in D, E, F to a hex number.
F05	RND	Put random digits into registers D, E, F.
F06	TIME	Copy the clock into registers A to F.
F07	RET	Return from a subroutine.
F08	CLEAR	Set all working registers to 0.
F09	STC	Set the carry flag.
F0A	RSC	Clear the carry flag.
F0B	MULT	Decimal multiplication (section 7).
F0C	DIV	Decimal division.
F0D	EXRL	Swap working registers 0–7 with memory registers 0–7.
F0E	EXRM	Swap working registers 8–F with memory registers 8–F.
F0F	EXRA	Swap all sixteen.
Fnd	DISP n,d	For n = 1 to 6: show n registers on the display, starting with register d at the right.
F7d	MAS d	Copy working register d to memory register d.
F8d	INV d	Invert all four bits of register d.
F9d	SHR d	Shift register d one bit to the right; the bit pushed out goes to the carry flag.
FAd	SHL d	Shift register d one bit to the left; the bit pushed out goes to the carry flag.
FBd	ADC d	Add the carry flag to register d.
FCd	SUBC d	Subtract the carry flag from register d.
FDd	DIN d	Read the four inputs into register d.
FEd	DOT d	Put register d on the four outputs.
FFd	KIN d	Wait for a hex key and put it into register d.

4. First programs

The programs below are in the emulator's library under "Examples from the guide". They are written as address, code and name.

Show a number

```
00 150  MOVI 5,0    register 0 := 5
01 F10  DISP 1,0    show one register, register 0
02 C02  GOTO 02      stay here
```

The display shows 5 in its right-hand digit. Nothing appears until a program says what to show: **DISP** is a switch that stays set, so one DISP at the start is enough, and the display then follows the registers by itself. The last line is a loop on the spot. If a program ends with HALT instead, the display goes back to showing address and instruction, and you would look at the result with **REG**. [Try it](#)

A counter

```
00 F10  DISP 1,0
01 FE0  DOT 0        register 0 to the four output LEDs
02 B08  CALL 08       wait a moment (subroutine)
03 510  ADDI 1,0      register 0 := register 0 + 1
04 C01  GOTO 01
```

Register 0 counts 0, 1, 2 ... 9, A, B ... F and then starts again at 0, because a register only has four bits. The output LEDs show the same value in binary: output 1 counts 1, output 2 counts 2, output 3 counts 4, output 4 counts 8. The wait is explained in [section 8](#). [Try it](#)

Reading the keyboard

```
00 F10  DISP 1,0
01 FF0  KIN 0         wait for a key, put it in register 0
02 FE0  DOT 0
03 C01  GOTO 01
```

KIN stops the program until a hex key is pressed. [Try it](#)

5. Carry, zero and decisions

The only way a program can decide anything is by the two flags. Their LEDs sit next to the display, so you can watch them.

After...	Carry is set when...	Zero is set when...
ADD, ADDI, ADC	the sum went past F	the result is 0
SUB, SUBI, SUBC	the result went below 0 (a borrow)	the result is 0
CMP s,d	register s is smaller than register d	they are equal
CMPI n,d	register d is greater than n	register d equals n
SHR, SHL	the bit shifted out was 1	the result is 0
AND, ANDI, OR, INV	(always cleared)	the result is 0
MOV, MOVI	(left as it was)	the value is 0

A result that goes past F simply wraps round: $9 + 9$ leaves 2 with carry set ($18 = 16 + 2$), and $3 - 5$ leaves E with carry set.

A decimal counter

```
00 F20  DISP 2,0    show registers 1 and 0 as tens and units
01 B10  CALL 10     wait
02 510  ADDI 1,0     units + 1
03 9A0  CMPI A,0     have the units reached ten?
04 E06  BRZ 06       yes: carry over
05 C01  GOTO 01
06 100  MOVI 0,0     units := 0
07 511  ADDI 1,1     tens + 1
08 9A1  CMPI A,1     have the tens reached ten?
09 E0B  BRZ 0B
0A C01  GOTO 01
0B 101  MOVI 0,1     tens := 0
0C C01  GOTO 01
```


A register happily counts to F, so a decimal counter has to notice the ten itself and carry over by hand. Compare, then branch on the flag: that pair is the pattern behind every decision. Note that DISP 2,0 puts register 0 at the right and register 1 to its left. [Try it](#)

Dice

```
00 F1D  DISP 1,D
01 FF0  KIN 0      wait for any key
02 F05  RND        random digits into D, E, F
03 95D  CMPI 5,D   is D greater than 5?
04 D02  BRC 02     yes: try again
05 51D  ADDI 1,D   0-5 becomes 1-6
06 C01  GOTO 01
```

Random digits come as 0 to F. Throwing away everything above 5 and adding one gives a fair die. The randomness comes from how long you take to press the key. [Try it](#)

6. Inputs and outputs



The terminal strip of the computer board: outputs 1–4 with their LEDs, the reset key, inputs 1–4, the 1 Hz clock.

DOT d puts the four bits of register d on outputs 1 to 4; an LED lights for each 1. **DIN d** reads inputs 1 to 4 into register d. An input with nothing connected reads 0; connecting it to a positive voltage makes it 1.

```
00 F10  DISP 1,0
01 FD0  DIN 0      inputs to register 0
02 FE0  DOT 0      register 0 to outputs
03 C01  GOTO 01
```

In the emulator there are three ways to feed an input: click an input jack to plug in a high level; hold the red keys **G** and **H**, which are wired to inputs of your choice; or run a patch cable from an output or from the 1 Hz clock.

[Try it](#)

To test one input, mask the others away: **FD0** then **310** (**ANDI 1,0**) leaves only input 1, and the zero flag tells you whether it is off.

The clock

The firmware keeps a clock, but it only counts if the 1 Hz output is connected to input 4. **TIME** copies it into registers A to F: seconds in A and B, minutes in C and D, hours in E and F.

```
00 F6A  DISP 6,A    show registers F...A
01 F06  TIME
02 C01  GOTO 01
```

The clock starts at 00 00 00 when the machine is switched on; set it with **PGM** **3**. [Try it](#)

7. Decimal numbers and arithmetic

One register is one digit, so a longer number is spread over several registers, lowest digit in the lowest register. DISP shows them the right way round.

Hex to decimal

HXDZ takes the hex number in registers F, E, D (D is the lowest digit) and replaces it with its decimal digits. FF becomes 2, 5, 5. A number above 999 does not fit: the registers become 0 and the zero flag is set. **DZHX** goes the other way.

```
00 F08 CLEAR
01 F2D DISP 2,D
02 FF0 KIN 0      first key
03 FFD KIN D      second key
04 10E MOVI 0,E
05 10F MOVI 0,F
06 40D ADD 0,D    D := D + register 0
07 FBE ADC E      a carry goes into the next digit
08 F03 HXDZ       hex to decimal
09 F2D DISP 2,D
0A C02 GOTO 02
```

Press 9 and 8 and the display shows 17; F and F give 30. The ADC is how numbers longer than one digit are added: add the low digits, then add the carry into the next one. [Try it](#)

MULT and DIV

Both work on decimal numbers of up to six digits, one in working registers 0–5 and the other in memory registers 0–5, and leave the result in the working registers.

- **MULT**: $\text{working} := \text{working} \times \text{memory}$.
- **DIV**: the number in the memory registers is divided by the number in the working registers. The quotient lands in the working registers, the remainder in the memory registers. The zero flag is set when there is a remainder. DIV handles up to four digits; dividing by zero fills the registers with E and sets carry.

```
00 F08 CLEAR
01 170 MOVI 7,0
02 F70 MAS 0      memory register 0 := 7
03 180 MOVI 8,0   working register 0 := 8
04 F0B MULT
05 F20 DISP 2,0   shows 56
06 C06 GOTO 06
```

Both are done by the firmware through repeated adding and subtracting, so large numbers take noticeably long.
Note that CLEAR clears only the working registers. [Try it](#)

8. Subroutines and delays

CALL aa jumps to a piece of program and **RET** comes back to the instruction after the **CALL**. Only one return address is remembered, so a subroutine cannot call another subroutine. The emulator's Inside panel shows the address **RET** would return to.

The Microtronic runs about 60 instructions a second, and there is no wait instruction. A pause is a counting loop:

```
08 18F  MOVI 8,F    start value
09 51F  ADDI 1,F    count up
0A D0C  BRC 0C      past F: done
0B C09  GOTO 09
0C F07  RET
```

Each round takes three instructions. Starting at 8 gives 8 rounds, about 0.4 seconds; starting at 0 gives 16 rounds, about 0.8 seconds. For longer pauses, nest two such loops. Because the machine is this slow, it pays to count instructions in anything that should feel responsive.

9. Sound

The Microtronic has no sound of its own. The emulator offers the three add-ons that were used with it (see also the [add-ons table](#)):

- **The piezo buzzer**, connected to an output of your choice. It sounds as long as that output is on. A beep is DOT, a pause, DOT with 0.
- **The tone circuit**, a small two-transistor oscillator connected to all four outputs. The value on the outputs sets the pitch: 4 to F give twelve tones, 0 to 3 give silence. With it, DOT plays a note. The emulator's pitches are tuned so that 4, 6, 8, A and C sound c, d, e, f and g. [Try the twelve tones](#)
- **PicoRAM 2090 notes**. The modern PicoRAM memory expansion plays notes on the instruction 50D, followed by octave and note. See the "Sound" programs in the library.

The **Sound off** button silences whatever is sounding.

10. Finding mistakes

- **Read it back.** **HALT** **NEXT** **0** **0** and then **NEXT** repeatedly shows each address with its instruction.
- **Single-step.** **STEP** carries out one instruction at a time; the display shows where you are.
- **Look at registers.** **REG** and a register number, at any stop. You can also change the value there.
- **Breakpoint.** **BKP** and an address lets the program run at full speed up to that point.
- **In the emulator,** the Inside panel shows all of this at once while the program runs: the current address, both register banks, the flags, inputs and outputs.

Two classic mistakes: confusing MOV (copy a register) with MOVI (put in a constant), and forgetting that SUB and CMP take their operands in the order shown in the tables above.

11. Built-in functions

HALT **PGM** and a digit calls a function that is part of the firmware:

PGM	Function
0	Self-test of display, keys and ports.
1, 2	Load from and save to cassette. Not available in the emulator (they wait for the cassette interface; press reset).
3	Set the clock: type hours and minutes, then HALT .
4	Show the clock.
5	Clear the program memory (every address becomes 000).
6	Fill the program memory with NOP (F01).
7	Load the built-in game Nim into memory; start it with HALT NEXT 0 0 RUN .

12. About the emulator

The [emulator](#) runs the Microtronic's original TMS1600 firmware, with the program memory chip, the display, the keypad and the ports modelled around it at the level of the individual pins. What it adds for convenience:

- **Programs:** a library, loading and saving .MIC files, and **Load & run**. Loading a library program also wires up what it needs.
- **Inside:** address, flags, both register banks, inputs, outputs, the return address, and the whole program with instruction names; click a line to change it.
- **Speed:** from a quarter of the original to a hundred times faster.
- **Wiring:** the red keys, the piezo buzzer, the tone circuit, the clock cable and an output-to-input cable ([section 1](#)).

A .MIC file is plain text with one three-digit instruction per line; @ 20 continues at address 20, and text after # is a comment.

Quick reference

Code	Name	Code	Name	Code	Name	Code	Name
0sd	MOV	8sd	CMP	F00	HALT	F08	CLEAR
1nd	MOVI	9nd	CMPI	F01	NOP	F09	STC
2sd	AND	Asd	OR	F02	DISOUT	F0A	RSC
3nd	ANDI	Baa	CALL	F03	HXDZ	F0B	MULT
4sd	ADD	Caa	GOTO	F04	DZHX	F0C	DIV
5nd	ADDI	Daa	BRC	F05	RND	F0D	EXRL
6sd	SUB	Eaa	BRZ	F06	TIME	F0E	EXRM
7nd	SUBI	Fnd	DISP (n = 1–6)	F07	RET	F0F	EXRA
F7d	MAS	F8d	INV	F9d	SHR	FAd	SHL
FBd	ADC	FCd	SUBC	FDd	DIN	FEd	DOT
FFd	KIN						

Keys: **HALT** **NEXT** address · three digits **NEXT** stores · **RUN** · **HALT** · **STEP** · **REG** register · **BKP** address · **PGM** digit · **C/CE** deletes a digit.

Written with Claude Opus 5.5 (Claude Code) for the [Microtronic emulator](#) by Michael Wessel.
The Microtronic and its firmware are © Busch GmbH. This guide is an independent description;
for the original manuals see the [English translation](#).