Package 'rLakeAnalyzer'

June 9, 2019

Title Lake Physics Tools
Maintainer Luke Winslow <lawinslow@gmail.com></lawinslow@gmail.com>
Version 1.11.4.1
Author Luke Winslow, Jordan Read, Richard Woolway, Jennifer Brentrup, Taylor Leach, Jake Zwart, Sam Albers, Doug Collinge
Description Standardized methods for calculating common important derived physical features of lakes including water density based based on temperature, thermal layers, thermocline depth, lake number, Wedderburn number, Schmidt stability and others.
Depends R (>= 2.10)
Imports plyr, stats, graphics, utils, grDevices
Suggests testthat, knitr, rmarkdown
License GPL (>= 2)
Repository CRAN
BugReports https://github.com/GLEON/rLakeAnalyzer/issues
Date/Publication 2019-06-09 18:45:46 UTC
RoxygenNote 6.0.1
VignetteBuilder knitr
NeedsCompilation no
•
R topics documented:
approx.bathy
buoyancy.freq
center.buoyancy
depth.filter depth.filter drop.datetime depth.filter
epi.temperature
get.datetime
get.offsets
hypo.temperature

2 approx.bathy

ex		41
	wtr.plot.temp	
	wtr.layer	
	wtr.heatmap.layers	
	•	
	wtr.heat.map	
	whole.lake.temperature	
	wedderburn.number	
	water.density	
	uStar	
	ts.wedderburn.number	
	ts.uStar	
	ts.thermo.depth	
	ts.schmidt.stability	
	ts.meta.depths	
	ts.layer.temperature	
	ts.lake.number	
	ts.internal.energy	
	ts.center.buoyancy	
	ts.buoyancy.freq	
	thermo.depth	
	schmidt.stability	
	schmidt.plot	
	rLakeAnalyzer	
	meta.depths	
	load.ts	
	load.bathy	
	layer.temperature	
	layer.density	
	latesummer	
	lake.number.plot	
	lake.number	
	infernal energy	<u> </u>

Description

Estimates a depth-area curve for a lake using lake surface area, maximum depth and mean depth. Two methods for estimating the curve are available; 'cone' assumes the lake is shaped as a cone and requires only surface area and maximum depth; "voldev" uses the volume development (Vd) parameter from Hakanson (1981) and Johansson et al. (2007). Vd is a dimensionless parameter that describes lake basin shape in relation to the volume of cone whose base area and height equal the surface area and maximum lake depth, it is estimated as Vd = Zmean/Zmax (Hakanson et al. 2000). Method "voldev' requires lake surface area, mean and maximum depth. Depths at which the area is estimated can be set by as a numeric vector or as a regularly spaced sequence.

approx.bathy 3

Usage

```
approx.bathy(Zmax, lkeArea, Zmean = NULL, method = "cone", zinterval = 1,
  depths = seq(0, Zmax, by = zinterval))
```

Arguments

Zmax a single value of the maximum depth of the lake (in m)

lkeArea a single value of the surface area of the lake (in m^2)

Zmean a single value of the mean depth of the lake (in m)

method specifies the method used to estimate depth-area relationship, can be "cone" (default)

or "voldev". Method "voldev" requires Zmean. See notes for details.

zinterval a single value defining the depth interval at which volumes should be calculated,

default is 1 m.

depths a numeric vector of depths (in m) at which areas are estimated. If not specified

depths is regularly spaced sequence of values with the interval set by zinterval.

Value

a dataframe which defines the lake area for each depth. Columns are depths (m) and Area.at.z (m^2) . Area at 0 m should equal the user entered lkeArea.

References

Hakanson, L. (1981). On lake bottom dynamics - the energy- topography factor. Canadian Journal of Earth Sciences, 18, 899-909. Johansson, H., A. A. Brolin, and L. Hakanson. 2007. New approaches to the modelling of lake basin morphometry. Environ. Model. Assess. 12: 213-228.

```
Voldev.ex = approx.bathy(Zmax = 25, Zmean = 12, lkeArea = 39400000, method = "voldev")
Voldevshallow.ex = approx.bathy(Zmax = 25, Zmean = 6, lkeArea = 39400000, method = "voldev")
Cone.ex = approx.bathy(Zmax = 25, lkeArea = 39400000, method = "cone")

# plot depth-area curves
   plot(Cone.ex$depths ~ Cone.ex$Area.at.z, xlab = "Area (m^3)", ylab = "Depth (m)")
   points(Voldev.ex$depths ~ Voldev.ex$Area.at.z, col = "red")
   points(Voldevshallow.ex$depths ~ Voldevshallow.ex$Area.at.z, col = "blue")
```

4 buoyancy.freq

buoyancy.freq

Calculates buoyancy frequency.

Description

Calculate the buoyancy frequency (Brunt-Vaisala frequency) for a temperature profile.

Usage

```
buoyancy.freq(wtr, depths)
```

Arguments

wtr a numeric vector of water temperature in degrees C

depths a numeric vector corresponding to the depths (in m) of the wtr measurements

Value

Returns a vector of buoyancy frequency in units sec^-2. Return value has attribute "depths" which define buoyancy frequency depths (which differ from supplied depths).

See Also

```
thermo.depth, ts.buoyancy.freq
```

```
# A vector of water temperatures
wtr = c(22.51, 22.42, 22.4, 22.4, 22.4, 22.36, 22.3, 22.21, 22.11, 21.23, 16.42,
15.15, 14.24, 13.35, 10.94, 10.43, 10.36, 9.94, 9.45, 9.1, 8.91, 8.58, 8.43)

#A vector defining the depths
depths = c(0, 0.5, 1, 1.5, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16,
17, 18, 19, 20)

b.f = buoyancy.freq(wtr, depths)

plot(b.f, attr(b.f, 'depths'), type='b',
ylab='Depth', xlab='Buoyancy Frequency', ylim=c(max(depths), min(depths)))
```

center.buoyancy 5

center.buoyancy

Calculates the center of buoyancy.

Description

Calculate the center of buoyancy using buoyancy frequency with a center of mass analysis. Brunt-Vaisala frequency is used for a temperature profile. Negative values for N2 are set to 0 (as they represent transient instabilities or sensor calibration issues) for this calculation.

Usage

```
center.buoyancy(wtr, depths)
```

Arguments

wtr a numeric vector of water temperature in degrees C

depths a numeric vector corresponding to the depths (in m) of the wtr measurements

Value

Returns a value for the center of buoyancy.

See Also

```
buoyancy.freq, ts.buoyancy.freq, center.buoyancy
```

```
# A vector of water temperatures wtr = c(22.51, 22.42, 22.4, 22.4, 22.4, 22.4, 22.36, 22.3, 22.21, 22.11, 21.23, 16.42, 15.15, 14.24, 13.35, 10.94, 10.43, 10.36, 9.94, 9.45, 9.1, 8.91, 8.58, 8.43) #A vector defining the depths depths = <math>c(0, 0.5, 1, 1.5, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20) c.b = center.buoyancy(wtr, depths)
```

6 drop.datetime

depth	fil	tor
uen ili		LEI

Data filter to remove soak, heave and upcast

Description

- Soak period: water profiling instruments typically require a soak period where you let the
 instrument rest submerged at the surface. While it is "soaking" it is collecting data. We don't
 want that data
- Upcast versus downcast: typically instruments are turned on before you put them in the water and turn them off once you pull them out. The data consequence of that is that you collect both the "downcast" and the "upcast". In some case the upcast is of interest but usually it isn't. And because we would prefer increasing depth data it is better to remove an upcast if it is present.
- Heave: when lowering the instrument in rough weather a boat will heave side to side. Sometimes it will heave enough that you get small data groupings where the decreases a little while the boat heaves then go down. The overall trend is still down but those slight upticks in depth cause problems for our algorithm.

Usage

```
depth.filter(z0, run_length = 20, index = FALSE)
```

Arguments

z0 depth vector

run_length Length of run upon which to start the soak removal

index Logical: Should the function return an index value or actual value?

Value

index values of z0 of filtered data. Will return a warning if the function removed more than 10

drop.datetime

Find and drop the datetime column from the datatable

Description

Liberally looks for a datetime column and drops it, returning a data.frame with only water temperature. Errors if datetime column is ambiguous. Warns if there is no match.

Usage

```
drop.datetime(data, error = FALSE)
```

epi.temperature 7

Arguments

data arg

error defaults to FALSE

Value

A data frame with only the data, after datetime has been dropped

epi.temperature

Get volumetrically averaged epilimnion temp

Description

Calculates volumetrically weighted average epilimnetic temperature using the supplied water temperature timeseries. If the lake is not stratified, the bottom of the epilimnion is calculated as the full depth of the lake.

Usage

```
epi.temperature(wtr, depths, bthA, bthD)
```

Arguments

wtr a numeric vector of water temperature in degrees C.

depths a numeric vector corresponding to the depths (in m) of the wtr measurements bthA a numeric vector of cross sectional areas (m^2) corresponding to bthD depths bthD a numeric vector of depths (m) which correspond to areal measures in bthA

See Also

hypo.temperature whole.lake.temperature

get.datetime

Search for and return the datetime column from a ts data.frame

Description

Warns if unavailable then returns NULL.

Usage

```
get.datetime(data, error = FALSE)
```

Arguments

data data arg

error defaults to FALSE

get.offsets

get.offsets

Gets depths from data frame containing profile info.

Description

Extracts the depth information from a data frame containing multi-depth observation data. Relies on the format of the header to get information and may fail if your file format is incorrect. Please follow 'VAR_##.#' format, where ##.# is the depth of data for that column. VAR is typically 'wtr' to indicate water temperature.

Usage

```
get.offsets(data)
```

Arguments

data

Data frame returned from load.ts.

Value

A numeric vector of depth values. Should be the ncol(data) -1 in length as the first column contains date/time data.

See Also

load.ts

```
#Get the path for the package example file included
exampleFilePath <- system.file('extdata', 'Sparkling.wtr', package="rLakeAnalyzer")
#Load
sparkling.temp = load.ts(exampleFilePath)
#get the lake depths associated with each column
depths = get.offsets(sparkling.temp)
print(depths)</pre>
```

hypo.temperature 9

hypo.temperature	Get volumetrically averaged hypolimnion temp	

Description

Calculates volumetrically weighted average hypolimnetic temperature using the supplied water temperature timeseries. If the lake is not stratified, an NA value is returned.

Usage

```
hypo.temperature(wtr, depths, bthA, bthD)
```

Arguments

wtr	a numeric vector of water temperature in degrees C.
depths	a numeric vector corresponding to the depths (in m) of the wtr measurements
bthA	a numeric vector of cross sectional areas (m^2) corresponding to bthD depths

bthD a numeric vector of depths (m) which correspond to areal measures in bthA

See Also

```
epi.temperature, whole.lake.temperature
```

internal.energy Internal energy function (Joules)

Description

Calculates the internal energy of the water column with temperature and hypsography Internal energy is the thermal energy in the water column, which is calculated by multiplying the specific heat of water (J kg-1 K-1) by the temperature and mass of the water in the lake.

Usage

```
internal.energy(wtr, depths, bthA, bthD)
```

Arguments

wtr	a numeric vector of water temperature in degrees C
depths	a numeric vector corresponding to the depths (in m) of the wtr measurements
bthA	a numeric vector of cross sectional areas (m^2) corresponding to bthD depths
bthD	a numeric vector of depths (m) which correspond to areal measures in bthA

10 lake.number

Value

internal energy in Joules m-2. (Currently not vectorized..)

Examples

```
bthA <-c(1000,900,864,820,200,10)
bthD <-c(0,2.3,2.5,4.2,5.8,7)
wtr <-c(28,27,26.4,26,25.4,24,23.3)
depths <-c(0,1,2,3,4,5,6)
cat('Internal Energy for input is: ')
cat(internal.energy(wtr, depths, bthA, bthD))
```

lake.number

Calculate Lake Number

Description

The Lake Number, defined by Imberger and Patterson (1990), has been used to describe processes relevant to the internal mixing of lakes induced by wind forcings. Lower values of Lake Number represent a higher potential for increased diapycnal mixing, which increases the vertical flux of mass and energy across the metalimnion through the action of non-linear internal waves. Lake Number is a dimensionless index.

Lake Number has been used, for example, to estimate the flux of oxygen across the thermocline in a small lake (Robertson and Imberger, 1994), and to explain the magnitude of the vertical flux of ammonium in a lake (Romero et al., 1998).

Usage

```
lake.number(bthA, bthD, uStar, St, metaT, metaB, averageHypoDense)
```

Arguments

bthA	a numeric vector of cross sectional areas (m2) corresponding to bthD depths, hypsographic areas
bthD	a numeric vector of depths (m) which correspond to areal measures in bthA, hypsographic depths
uStar	a numeric array of u* (m/s), water friction velocity due to wind stress
St	a numeric array of Schmidt stability (J/m2), as defined by Idso 1973
metaT	a numeric array of the top of the metalimnion depth (m from the surface)
metaB	a numeric array of the bottom of the metalimnion depth (m from the surface)
averageHypoDen	se
	a numeric array of the average density of the hypolimnion (kg/m3)

lake.number.plot

Value

A numeric vector of Lake Number [dimensionless]

References

Imberger, J., Patterson, J.C., 1990. *Physical limnology*. Advances in Applied Mechanics 27, 303-475.

Idso, S.B., 1973. On the concept of lake stability. Limnology and Oceanography 18, 681-683.

See Also

```
ts.lake.number wedderburn.number
```

Examples

```
bthA <-c(1000,900,864,820,200,10)
bthD <-c(0,2.3,2.5,4.2,5.8,7)
uStar <-c(0.0032,0.0024)
St <-c(140,153)
metaT <-c(1.34,1.54)
metaB <-c(4.32,4.33)
averageHypoDense <-c(999.3,999.32)
cat('Lake Number for input vector is: ')
cat(lake.number( bthA, bthD, uStar, St, metaT, metaB, averageHypoDense) )
```

lake.number.plot

Plots time series of Lake Number

Description

Generates a time series plot of Lake Number for appropriately formatted data. See lake.number for more details on Lake Number and reference.

Usage

```
lake.number.plot(wtr, wnd, wh, bth)
```

Arguments

wtr	Data frame of water temperature loaded with load. ts
wnd	A data frame containing hypsometric data. Loaded using load.bathy
wh	A value indicating the height of the anemometer above lake surface in meters. This value must be specified, there is no default.
bth	A data frame containing hypsometric data. Loaded using load.bathy

12 latesummer

See Also

```
wtr.lineseries
```

Examples

```
#Get system data file paths
wtr.path <- system.file('extdata', 'Sparkling.wtr', package="rLakeAnalyzer")
bth.path <- system.file('extdata', 'Sparkling.bth', package="rLakeAnalyzer")
wnd.path <- system.file('extdata', 'Sparkling.wnd', package="rLakeAnalyzer")
#Load data for example lake, Sparkilng Lake, Wisconsin.
wtr = load.ts(wtr.path)
wnd = load.ts(wnd.path)
bth = load.bathy(bth.path)
wh = 1 # user specified, here as 1 m.
    ## Not run:
    #generate default plot
lake.number.plot(wtr,wnd,wh,bth)
## End(Not run)</pre>
```

latesummer

Late Summer Profile

Description

Late summer water profile taken from Quesnel Lake, British Columbia, Canada. Profile taken with Sea-Bird SBE19plus.

```
depth Depth, m

temper Temperature, degC

salinity Salinity, PSU

oxygen Oxygen, ml/l

oxygen.sat Oxygen saturation, percent saturation
density Density, kg/m^3 ...
```

Usage

latesummer

Format

An object of class data. frame with 881 rows and 6 columns.

layer.density 13

layer.density	Returns the average density of a layer between two depths.	

Description

This function calculates the average density of a layer of water between two depths.

Usage

```
layer.density(top, bottom, wtr, depths, bthA, bthD, sal = wtr \star 0)
```

Arguments

top	Numeric value of the depth (m) of the top of the layer from the water surface
bottom	Numeric value of the depth (m) of the bottom of the layer from the water surface
wtr	Numeric vector of water temperature in degrees C
depths	Numeric vector of depths (m) corresponding to water temperature vector
bthA	Numeric vector of water body cross sectional area (m2) corresponding to bthD depths
bthD	Numeric vector of water body bathymetric depths (m) corresponding to areal bthA values
sal	Optional numeric vector of salinity in Practical Salinity Units corresponding to water temperature vector. If left blank, salinity is set to be zero

Value

Numeric value of average water density for bounded layer in kg/m³

See Also

```
water.density
```

```
top <- 2
bottom <- 6
wtr <- c(25.2,25.1,24.1,22.0,19.8,15.3,12.0,11.1)
depths <- c(0,1,2,3,4,5,6,7)
bthA <- c(10000,8900,5000,3500,2000,1000,300,10)
bthD <- c(0,1,2,3,4,5,6,7)
layer.density(top,bottom,wtr,depths,bthA,bthD)</pre>
```

14 layer.temperature

layer.temperature	Returns the average temperature of a layer between two depths.
2a, 0. 1 compo. a ca. c	neum is the area age temperature of a tayer correct the aepits.

Description

This function calculates the average temperature of a layer of water between two depths.

Usage

```
layer.temperature(top, bottom, wtr, depths, bthA, bthD)
```

Arguments

top	Numeric value of the depth (m) of the top of the layer from the water surface
bottom	Numeric value of the depth (m) of the bottom of the layer from the water surface
wtr	Numeric vector of water temperature in degrees C
depths	Numeric vector of depths (m) corresponding to water temperature vector
bthA	Numeric vector of water body cross sectional area (m2) corresponding to bthD depths
bthD	Numeric vector of water body bathymetric depths (m) corresponding to areal bthA values

Value

Numeric value of average water temperature

See Also

```
layer.density
```

```
# Supply input data top <- 2 bottom <- 6 wtr <- c(25.2,25.1,24.1,22.0,19.8,15.3,12.0,11.1) depths <- c(0,1,2,3,4,5,6,7) bthA <- c(10000,8900,5000,3500,2000,1000,300,10) bthD <- c(0,1,2,3,4,5,6,7) #Return the average temperature of the water column between 2 and 6 meters. layer.temperature(top,bottom,wtr,depths,bthA,bthD)
```

load.bathy 15

load.bathy

Import lake bathymetry data.

Description

Imports lake bathymetry data. Bathymetric data file must be a 2 column array where depth (in meters) and area (in meters^2) information are provided in columns with headers containing the words "depths" and "areas" respectively.

Usage

```
load.bathy(fPath)
```

Arguments

fPath

File path to the bathymetry file.

Value

data.frame of depth and area for given lake.

See Also

load.ts

```
#Get the path for the package example file included
exampleFilePath <- system.file('extdata', 'Sparkling.bth', package="rLakeAnalyzer")
#Load and plot the hypsometric curve
sparkling.bathy = load.bathy(exampleFilePath)
#If successful, there will be two colums. "depths", and "areas".
plot(sparkling.bathy$areas, sparkling.bathy$depths, type='l', ylim=c(20,0),
    ylab='Depths (m)', xlab='Areas (m^2)')</pre>
```

16 load.ts

load.ts

Load timeseries from properly formatted text file.

Description

A convenience function to load timeseries data into R based on the standardized format used by Lake Analyzer.

Timeseries files must follow a common format. The first column must have the label 'datetime' and be of the format *yyyy-mm-dd HH:MM:SS* (ISO 8601 without the "T" delimiter). The second can be skipped if not using sub-minute data.

Usage

```
load.ts(fPath, tz = "GMT")
```

Arguments

fPath The file path as a string.

tz Timezone string to be supplied to as . POSIXct. Defaults to GMT (UTC-0). This

often can be left to the default unless timezone support is specifically required.

Value

A data frame in the required format for use with other rLakeAnalyzer timeseries functions.

See Also

```
For dataloading ts.meta.depths,
For analyzing timeseries data, see ts.meta.depths, ts.thermo.depth, ts.schmidt.stability,
ts.lake.number.
```

```
#Get the path for the package example file included
exampleFilePath <- system.file('extdata', 'Sparkling.wtr', package="rLakeAnalyzer")
#Load
sparkling.temp = load.ts(exampleFilePath)
#calculate and plot the thermocline depth
t.d = ts.thermo.depth(sparkling.temp)
plot(t.d$datetime, t.d$thermo.depth, type='l', ylab='Thermocline Depth (m)', xlab='Date')</pre>
```

meta.depths 17

meta.depths Calculate the Top and Bottom Depths of the Metalimnion
meta.depths Calculate the Top and Bottom Depths of the Metalimnion

Description

Calculates the top and bottom depths of the metalimnion in a stratified lake. The metalimnion is defined as the water stratum in a stratified lake with the steepest thermal gradient and is demarcated by the bottom of the epilimnion and top of the hypolimnion.

Usage

```
meta.depths(wtr, depths, slope = 0.1, seasonal = TRUE, mixed.cutoff = 1)
```

Arguments

wtr	a numeric vector of water temperature in degrees C
depths	a numeric vector corresponding to the depths (in m) of the wtr measurements
slope	a numeric vector corresponding to the minimum slope
seasonal	a logical value indicating whether the seasonal thermocline should be returned. This is fed to thermo.depth, which is used as the starting point. The seasonal thermocline is defined as the deepest density gradient found in the profile. If FALSE, the depth of the maximum density gradient is used as the starting point.
mixed.cutoff	A cutoff (deg C) where below this threshold, thermo.depth and meta.depths are not calculated (NaN is returned). Defaults to 1 deg C.

Value

A numeric vector of the top and bottom metalimnion depths in meters. Returns the bottom depth if no distinct metalimion top and bottom found.

References

Wetzel, R. G. 2001. Limnology: Lake and River Ecosystems, 3rd ed. Academic Press.

See Also

```
ts.meta.depths, thermo.depth
```

```
wtr = c(22.51, 22.42, 22.4, 22.4, 22.4, 22.36, 22.3, 22.21, 22.11, 21.23, 16.42, 15.15, 14.24, 13.35, 10.94, 10.43, 10.36, 9.94, 9.45, 9.1, 8.91, 8.58, 8.43)
depths = c(0, 0.5, 1, 1.5, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20)
```

18 schmidt.plot

```
m.d = meta.depths(wtr, depths, slope=0.1, seasonal=FALSE)
cat('The top depth of the metalimnion is:', m.d[1])
cat('The bottom depth of the metalimnion is:', m.d[2])
```

rLakeAnalyzer

Lake Physics Tools

Description

Standardized methods for calculating common important derived physical features of lakes including water density based based on temperature, thermal layers, thermocline depth, lake number, Wedderburn number, Schmidt stability and others.

schmidt.plot

Creates a time series plot of Schmidt's stability

Description

Generates a time series of Schmidt's stability where each value represents water column stability for each time step of data. See schmidt.stability for more details and reference.

Usage

```
schmidt.plot(wtr, bth)
```

Arguments

wtr Data frame of water temperature loaded with load.ts

bth A data frame containing hypsometric data. Loaded using load.bathy

References

```
See schmidt.stability
```

See Also

```
schmidt.stability
```

schmidt.stability 19

Examples

```
# Get system data file paths
   wtr.path <- system.file('extdata', 'Sparkling.wtr', package="rLakeAnalyzer")
bth.path <- system.file('extdata', 'Sparkling.bth', package="rLakeAnalyzer")

# Load data for example lake, Sparkilng Lake, Wisconsin.
wtr = load.ts(wtr.path)
bth = load.bathy(bth.path)

## Not run:
   # Generate default plot
   schmidt.plot(wtr,bth)

## End(Not run)</pre>
```

schmidt.stability

Calculate the Schmidt stability

Description

Schmidt stability, or the resistance to mechanical mixing due to the potential energy inherent in the stratification of the water column.

Schmidt stability was first defined by Schmidt (1928) and later modified by Hutchinson (1957). This stability index was formalized by Idso (1973) to reduce the effects of lake volume on the calculation (resulting in a mixing energy requirement per unit area).

Usage

```
schmidt.stability(wtr, depths, bthA, bthD, sal = 0)
```

Arguments

wtr	a numeric vector of water temperature in degrees C
depths	a numeric vector corresponding to the depths (in m) of the wtr measurements
bthA	a numeric vector of cross sectional areas (m^2) corresponding to bthD depths
bthD	a numeric vector of depths (m) which correspond to areal measures in bthA
sal	a numeric vector of salinity in Practical Salinity Scale units

Value

```
a numeric vector of Schmidt stability (J/m^2)
```

20 thermo.depth

References

Schmidt, W., 1928. *Ueber Temperatur and Stabilitaetsverhaltnisse von Seen*. Geo- graphiska Annaler 10, 145-177.

Hutchinson, G.E., 1957. *A Treatise on Limnology*, vol. 1. John Wiley & Sons, Inc., New York. Idso, S.B., 1973. *On the concept of lake stability*. Limnology and Oceanography 18, 681-683.

See Also

```
ts.schmidt.stability lake.number wedderburn.number
```

Examples

```
bthA <-c(1000,900,864,820,200,10)
bthD <-c(0,2.3,2.5,4.2,5.8,7)
wtr <-c(28,27,26.4,26,25.4,24,23.3)
depths <-c(0,1,2,3,4,5,6)
cat('Schmidt stability for input is: ')
cat(schmidt.stability(wtr, depths, bthA, bthD))
```

thermo.depth

Calculate depth of the thermocline from a temperature profile.

Description

This function calculates the location of the thermocline from a temperature profile. It uses a special technique to estimate where the thermocline lies even between two temperature measurement depths, giving a potentially finer-scale estimate than usual techniques.

Usage

```
thermo.depth(wtr, depths, Smin = 0.1, seasonal = TRUE, index = FALSE,
  mixed.cutoff = 1)
```

Arguments

wtr a numeric vector of water temperature in degrees C

depths a numeric vector corresponding to the depths (in m) of the wtr measurements

Smin Optional paramter defining minimum density gradient for thermocline

seasonal a logical value indicating whether the seasonal thermocline should be returned.

This is fed to thermo.depth, which is used as the starting point. The seasonal thermocline is defined as the deepest density gradient found in the profile. If FALSE, the depth of the maximum density gradient is used as the starting point.

ts.buoyancy.freq 21

index Boolean value indicated if index of the thermocline depth, instead of the depth

value, should be returned.

mixed.cutoff A cutoff (deg C) where below this threshold, thermo.depth and meta.depths are

not calculated (NaN is returned). Defaults to 1 deg C.

Value

Depth of thermocline. If no thermocline found, value is NaN.

See Also

```
ts.thermo.depth, water.density
```

Examples

ts.buoyancy.freq

Calculate the buoyancy (Brunt-Vaisala) frequency for a temperature profile.

Description

Function for simplifying the calculation of buoyancy frequency. Can usually be called directly on data loaded directly using load.ts and load.bathy.

Usage

```
ts.buoyancy.freq(wtr, at.thermo = TRUE, na.rm = FALSE, ...)
```

Arguments

wtr A data frame of water temperatures (in Celsius). Loaded using load. ts

at.thermo Boolean indicating if only buoyancy frequency at the thermocline should be

returned. If false, full profile is returned.

22 ts.center.buoyancy

supply would be seasonal and slope.

na.rm	Boolean indicated if step-by-step removal of NA's should be tried. If false, a timestep with any NA values will likely return an NA value. If true, best effort
	will be made to calculate indices despite NA values.
	Additional parameters will be passed on to thermo.depth function when ex-
	tracting buoyancy frequency at only the thermocline. Common parameters to

Value

Returns a data frame with the timeseries of buoyancy frequency in units sec^-2. Includes a 'date-time' column.

References

Imberger, J., Patterson, J.C., 1990. *Physical limnology*. Advances in Applied Mechanics 27, 353-370.

See Also

```
buoyancy.freq
```

Examples

```
#Get the path for the package example file included
wtr.path <- system.file('extdata', 'Sparkling.daily.wtr', package="rLakeAnalyzer")
#Load data for example lake, Sparkilng Lake, Wisconsin.
sp.wtr = load.ts(wtr.path)

N2 = ts.buoyancy.freq(sp.wtr, seasonal=FALSE)
SN2 = ts.buoyancy.freq(sp.wtr, seasonal=TRUE)

plot(N2, type='l', ylab='Buoyancy Frequency', xlab='Date')
lines(SN2, col='red')</pre>
```

ts.center.buoyancy

Calculates the center of buoyancy for multiple temperature profiles.

Description

Function for simplifying the calculation of the center of buoyancy. Can usually be called directly on data loaded directly using load.ts and load.bathy.

Usage

```
ts.center.buoyancy(wtr, na.rm = FALSE)
```

ts.center.buoyancy 23

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts
na.rm	Boolean indicated if step-by-step removal of NA's should be tried. If false, a timestep with any NA values will return an NA value. If true, best effort will be made to calculate indices despite NA values.

Value

Returns a data frame with the timeseries of the center of buoyancy frequency. Includes a 'datetime' column.

References

Imberger, J., Patterson, J.C., 1990. *Physical limnology*. Advances in Applied Mechanics 27, 353-370.

See Also

```
center.buoyancy, load.bathy, load.ts
```

```
#Get the path for the package example file included
wtr.path <- system.file('extdata', 'Sparkling.daily.wtr', package="rLakeAnalyzer")
#Load data for example lake, Sparkilng Lake, Wisconsin.
sp.wtr = load.ts(wtr.path)

#calculate and plot the thermocline depth
t.d = ts.thermo.depth(sp.wtr)

center.N2 = ts.center.buoyancy(sp.wtr)

plot(center.N2, type='l', ylab='Depth (m)', xlab='Date', ylim=c(19,0), lwd = 1.5)
lines(t.d, type='l', col='red', lwd = 1.5)
legend(x = t.d[3,1], y = .25,
    c('center of buoyancy', 'thermocline depth'),
    lty=c(1,1),
    lwd=c(1.5,1.5),col=c("black","red"), bty = "n")</pre>
```

24 ts.internal.energy

ts.internal.energy	Calculate physical indices for a timeseries.	

Description

Functions for simplifying the calculation of physical indices for a timeseries of observation data. Can usually be called directly on data loaded directly using load.ts and load.bathy.

These are wrapper functions that accept a timeseries of data and call the core physical metric functions (like schmidt.stability) on each timestep.

Usage

```
ts.internal.energy(wtr, bathy, na.rm = FALSE)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts. Must have columns datetime, wtr_##.# where ##.# is depth in meters.
bathy	A data frame containing hypsometric data. Loaded using load.bathy
na.rm	Boolean indicated if step-by-step removal of NA's should be tried. If false, a timestep with any NA values will return an NA value. If true, best effort will be made to calculate indices despite NA values.

Value

Returns a data frame with the timeseries of calculated derivatives. All include a 'datetime' column, but derivative columns differ between functions.

See Also

For loading input data load.ts, load.bathy.

For the underlying functions operating at each timestep meta.depths, thermo.depth, schmidt.stability, lake.number, internal.energy.

 $Other\ Time series\ functions\ for\ r\ Lake\ Analyzer:\ ts.lake.number,\ ts.meta.depths,\ ts.schmidt.stability,\ ts.thermo.depth,\ ts.uStar$

ts.lake.number 25

ts.lake.number	Calculate physical indices for a timeseries.
----------------	--

Description

Functions for simplifying the calculation of physical indices for a timeseries of observation data. Can usually be called directly on data loaded directly using load.ts and load.bathy.

These are wrapper functions that accept a timeseries of data and call the core physical metric functions (like schmidt.stability) on each timestep.

Usage

```
ts.lake.number(wtr, wnd, wnd.height, bathy, seasonal = TRUE)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts. Must have columns datetime, wtr_##.# where ##.# is depth in meters.
wnd	A data frame of wind speeds (in m/s). Loaded using load.ts
wnd.height	Height of the anemometer above the lake surface in meters
bathy	A data frame containing hypsometric data. Loaded using load.bathy
seasonal	Boolean indicating if seasonal thermocline should be used in calculation.

Value

Returns a data frame with the timeseries of calculated derivatives. All include a 'datetime' column, but derivative columns differ between functions.

See Also

For loading input data load.ts, load.bathy.

For the underlying functions operating at each timestep meta.depths, thermo.depth, schmidt.stability, lake.number, internal.energy.

 $Other\ Time series\ functions\ for\ r\ Lake\ Analyzer:\ ts.internal.energy,\ ts.meta.depths,\ ts.schmidt.stability,\ ts.thermo.depth,\ ts.uStar$

26 ts.layer.temperature

ts.layer.temperature	Calculate volume-weighted average water temperature across a range
	of depths for a timeseries.

Description

Function for simplifying the calculation of Wedderburn Number. Can usually be called directly on data loaded directly using load.ts and load.bathy.

Usage

```
ts.layer.temperature(wtr, top, bottom, bathy, na.rm = FALSE)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts
top	Either a single numeric depth value to be used across the entire timeseries, or a vector of same length as the timeseries (e.g., nrow(wtr)). This is useful when calculating a time-varying layer average, like average epilimnion temperature.
bottom	Either a single numeric depth value to be used across the entire timeseries, or a vector of same length as the timeseries (e.g., nrow(wtr)). This is useful when calculating a time-varying layer average, like average epilimnion temperature.
bathy	A data frame containing hypsometric data. Loaded using load.bathy
na.rm	Boolean indicated if step-by-step removal of NA's should be tried. If false, a timestep with any NA values will return an NA value. If true, best effort will be made to calculate indices despite NA values.

Value

Returns a data frame with the timeseries of the average layer temperature. Includes 'datetime' and 'layer.temp' columns.

See Also

```
layer.temperature
```

```
#Get the path for the package example file included
wtr.path <- system.file('extdata', 'Sparkling.daily.wtr', package="rLakeAnalyzer")
bathy.path <- system.file('extdata', 'Sparkling.bth', package="rLakeAnalyzer")

#Load data for example lake, Sparkilng lake, in Wisconsin.
sp.wtr = load.ts(wtr.path)
sp.bathy = load.bathy(bathy.path)</pre>
```

ts.meta.depths 27

ts.meta.depths

Calculate physical indices for a timeseries.

Description

Functions for simplifying the calculation of physical indices for a timeseries of observation data. Can usually be called directly on data loaded directly using load.ts and load.bathy.

These are wrapper functions that accept a timeseries of data and call the core physical metric functions (like schmidt.stability) on each timestep.

Usage

```
ts.meta.depths(wtr, slope = 0.1, na.rm = FALSE, ...)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts. Must have columns datetime, wtr_##.# where ##.# is depth in meters.
slope	The minimum density gradient (kg/m^3/m) that can be called the thermocline
na.rm	Boolean indicated if step-by-step removal of NA's should be tried. If false, a timestep with any NA values will return an NA value. If true, best effort will be made to calculate indices despite NA values.
•••	Additional parameters passed to underlying base function (e.g., index=TRUE for thermo.depth)

Value

Returns a data frame with the timeseries of calculated derivatives. All include a 'datetime' column, but derivative columns differ between functions.

See Also

For loading input data load.ts, load.bathy.

For the underlying functions operating at each timestep meta.depths, thermo.depth, schmidt.stability, lake.number, internal.energy.

 $Other\ Time series\ functions\ for\ r\ Lake\ Analyzer:\ ts.internal.energy,\ ts.lake.number,\ ts.schmidt.stability,\ ts.thermo.depth,\ ts.uStar$

28 ts.schmidt.stability

Examples

```
#Get the path for the package example file included
exampleFilePath <- system.file('extdata', 'Sparkling.daily.wtr', package="rLakeAnalyzer")
#Load
sparkling.temp = load.ts(exampleFilePath)
#calculate and plot the metalimnion depths
m.d = ts.meta.depths(sparkling.temp)

plot(m.d$datetime, m.d$top, type='l', ylab='Meta Depths (m)', xlab='Date', col='blue')
lines(m.d$datetime, m.d$bottom, col='red')</pre>
```

ts.schmidt.stability Calculate physical indices for a timeseries.

Description

Functions for simplifying the calculation of physical indices for a timeseries of observation data. Can usually be called directly on data loaded directly using load.ts and load.bathy.

These are wrapper functions that accept a timeseries of data and call the core physical metric functions (like schmidt.stability) on each timestep.

Usage

```
ts.schmidt.stability(wtr, bathy, na.rm = FALSE)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts. Must have columns datetime, wtr_##.# where ##.# is depth in meters.
bathy	A data frame containing hypsometric data. Loaded using load.bathy
na.rm	Boolean indicated if step-by-step removal of NA's should be tried. If false, a timestep with any NA values will return an NA value. If true, best effort will be made to calculate indices despite NA values.

Value

Returns a data frame with the timeseries of calculated derivatives. All include a 'datetime' column, but derivative columns differ between functions.

ts.thermo.depth 29

See Also

For loading input data load.ts, load.bathy.

For the underlying functions operating at each timestep meta.depths, thermo.depth, schmidt.stability, lake.number, internal.energy.

Other Timeseries functions for r Lake Analyzer: ts.internal.energy, ts.lake.number, ts.meta.depths, ts.thermo.depth, ts.uStar

ts.thermo.depth

Calculate physical indices for a timeseries.

Description

Functions for simplifying the calculation of physical indices for a timeseries of observation data. Can usually be called directly on data loaded directly using load.ts and load.bathy.

These are wrapper functions that accept a timeseries of data and call the core physical metric functions (like schmidt.stability) on each timestep.

Usage

```
ts.thermo.depth(wtr, Smin = 0.1, na.rm = FALSE, ...)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts. Must have columns datetime, wtr_##.# where ##.# is depth in meters.
Smin	The minimum density gradient cutoff (kg/m^3/m) defining the metalimion
na.rm	Boolean indicated if step-by-step removal of NA's should be tried. If false, a timestep with any NA values will return an NA value. If true, best effort will be made to calculate indices despite NA values.
	Additional parameters passed to underlying base function (e.g., index=TRUE for thermo.depth)

Value

Returns a data frame with the timeseries of calculated derivatives. All include a 'datetime' column, but derivative columns differ between functions.

See Also

For loading input data load.ts, load.bathy.

For the underlying functions operating at each timestep meta.depths, thermo.depth, schmidt.stability, lake.number, internal.energy.

 $Other\ Time series\ functions\ for\ r\ Lake\ Analyzer:\ ts.internal.energy,\ ts.lake.number,\ ts.meta.depths,\ ts.schmidt.stability,\ ts.uStar$

30 ts.uStar

Examples

```
#Get the path for the package example file included
exampleFilePath <- system.file('extdata', 'Sparkling.daily.wtr', package="rLakeAnalyzer")
#Load
sparkling.temp = load.ts(exampleFilePath)

#calculate and plot the thermocline depth
t.d = ts.thermo.depth(sparkling.temp)
plot(t.d$datetime, t.d$thermo.depth, type='l', ylab='Thermocline Depth (m)', xlab='Date')</pre>
```

ts.uStar

Calculate physical indices for a timeseries.

Description

Functions for simplifying the calculation of physical indices for a timeseries of observation data. Can usually be called directly on data loaded directly using load.ts and load.bathy.

These are wrapper functions that accept a timeseries of data and call the core physical metric functions (like schmidt.stability) on each timestep.

Usage

```
ts.uStar(wtr, wnd, wnd.height, bathy, seasonal = TRUE)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load.ts. Must have columns datetime, wtr_##.# where ##.# is depth in meters.
wnd	A data frame of wind speeds (in m/s). Loaded using load.ts
wnd.height	Height of the anemometer above the lake surface in meters
bathy	A data frame containing hypsometric data. Loaded using load.bathy
seasonal	Boolean indicating if seasonal thermocline should be used in calculation.

Value

Returns a data frame with the timeseries of calculated derivatives. All include a 'datetime' column, but derivative columns differ between functions.

ts.wedderburn.number 31

See Also

For loading input data load.ts, load.bathy.

For the underlying functions operating at each timestep meta.depths, thermo.depth, schmidt.stability, lake.number, internal.energy.

Other Timeseries functions for r Lake Analyzer: ts.internal.energy, ts.lake.number, ts.meta.depths, ts.schmidt.stability, ts.thermo.depth

ts.wedderburn.number Calculate Wedderburn number for a timeseries.

Description

Function for simplifying the calculation of Wedderburn Number. Can usually be called directly on data loaded directly using load.ts and load.bathy.

Usage

```
ts.wedderburn.number(wtr, wnd, wnd.height, bathy, Ao, seasonal = TRUE)
```

Arguments

wtr	A data frame of water temperatures (in Celsius). Loaded using load. ts
wnd	A data frame of wind speeds (in m/s). Loaded using load.ts

wnd.height Height of the anemometer above the lake surface in meters

A data frame containing hypsometric data. Loaded using load.bathy

Numeric value for the water body surface area (m^2) at zero meters depth

Boolean indicating if seasonal thermocline should be used in calculation.

Value

Returns a data frame with the timeseries of Wedderburn number. Includes a 'datetime' column.

References

Imberger, J., Patterson, J.C., 1990. *Physical limnology*. Advances in Applied Mechanics 27, 353-370.

See Also

wedderburn.number,ts.lake.number

32 uStar

Examples

```
#Get the path for the package example file included
wtr.path <- system.file('extdata', 'Sparkling.daily.wtr', package="rLakeAnalyzer")
wnd.path <- system.file('extdata', 'Sparkling.daily.wnd', package="rLakeAnalyzer")
bathy.path <- system.file('extdata', 'Sparkling.bth', package="rLakeAnalyzer")

#Load data for example lake, Sparkilng lake, in Wisconsin.
sp.wtr = load.ts(wtr.path)
sp.wnd = load.ts(wnd.path)
sp.bathy = load.bathy(bathy.path)

sp.area = 64e4  #Area of Sparkling lake in m^2
wnd.height = 2  #Height of Sparkling lake anemometer

w.n = ts.wedderburn.number(sp.wtr, sp.wnd, wnd.height, sp.bathy, sp.area)
plot(w.n$datetime, w.n$wedderburn.number, type='l', ylab='Wedderburn Number', xlab='Date')</pre>
```

uStar

Calculates the water friction velocity, uStar

Description

uStar is the water friction velocity due to wind stress at the lake surface, it is calculated following the methods of Imberger (1985) as a function of the shear stress of air (Fischer et al., 1979), drag coefficient for momentum (Hicks, 1972), and a dimensionless constant (von Karman constant) that decribes the logarithmic velocity profile at the air-water interface

Usage

```
uStar(wndSpeed, wndHeight, averageEpiDense)
```

Arguments

```
wndSpeed a numeric vector of wind speed in m s-1
wndHeight a numeric vector of wind measurement height in m
averageEpiDense
a numeric vector of epilimnion density in kg m-3
```

Value

a numeric vector of uStar

water.density 33

References

Hicks, B.B., 1972. A procedure for the formulation of bulk transfer coefficients over water bodies of different sizes. Boundary-Layer Meterology 3: 201-213.

Amorocho, J., DeVries, J.J., 1980. A new evaluation of the wind stress coefficient over water surfaces. Journal of Geophysical Research 85: 433-442.

Fischer, H.B., List, E.J., Koh, R.C.Y., Imberger, J., Brooks, N.H., 1979. *Mixing in inland and coastal waters*. Academic Press.

Imberger, J., 1985. The diurnal mixed layer. Limnology and Oceanography 30: 737-770.

See Also

```
ts.uStar layer.density
```

Examples

```
wndSpeed <- c(5.1,6.3,6.3,5.2,7,7.2)
wndHeight <-2
averageEpiDense <- c(14,15,14.2,13,12,12)

cat('uStar for input vector is: ')
cat(uStar(wndSpeed,wndHeight,averageEpiDense))</pre>
```

water.density

Estimate Water Density

Description

Density of water from temperature and salinity

Usage

```
water.density(wtr, sal = wtr * 0)
```

Arguments

wtr a numeric vector of water temperature in degrees Celsius sal a numeric vector of salinity in Practical Salinity Scale units

Value

A numeric vector of water densities in kg/m³.

34 wedderburn.number

References

Martin, J.L., McCutcheon, S.C., 1999. Hydrodynamics and Transport for Water Quality Modeling. Lewis Publications, Boca Raton, FL, 794pp.

Millero, F.J., Poisson, A., 1981. International one-atmosphere equation of state of seawater. UN-ESCO Technical Papers in Marine Science. No. 36.

Examples

```
#Plot water density for water between 1 and 30 deg C
dens = water.density(1:30)
plot(1:30, dens, xlab="Temp(deg C)", ylab="Density(kg/m^3)")
```

wedderburn.number

Calculates Wedderburn Number for a lake.

Description

Wedderburn Number (Wn) is a dimensionless parameter measuring the balance between wind stress and bouyancy force and is used to estimate the amount of upwelling occuring in a lake. When Wn is much greater than 1, the bouyancy force is much greater than the wind stress and therefore there is a strong vertical stratification with little horizontal variation in the stratification. When Wn is much less than 1, the wind stress is much greater than the bouyancy force and upwelling is likely occuring at the upwind end of the lake. When Wn is near 1, the bouyance force and wind stress are nearly equal and horizontal mixing is considered important

Usage

```
wedderburn.number(delta_rho, metaT, uSt, Ao, AvHyp_rho)
```

Arguments

delta_rho	Numeric value for the water density difference between the epilimnion and hy-
	polimnion (kg/m^3)
metaT	Numeric value for the thickness of the water body's surface layer (m)

uSt Numeric value for the water friction velocity due to wind stress (m/s) Numeric value for the water body surface area (m^2) at zero meters depth Aο AvHyp_rho Numeric value for the average water density of the hypolimnion layer (kg/m³)

Value

The dimensionless numeric value of Wedderburn Number

References

Imberger, J., Patterson, J.C., 1990. Physical limnology. Advances in Applied Mechanics 27, 353-370.

whole.lake.temperature 35

See Also

```
ts.wedderburn.number lake.number
```

Examples

```
delta_rho <- c(3.1,1.5)
metaT <- c(5.5,2.4)
uSt <- c(0.0028,0.0032)
Ao <- c(80300,120000)
AvHyp_rho <- c(999.31,999.1)
wedderburn.number(delta_rho, metaT, uSt, Ao, AvHyp_rho)</pre>
```

```
whole.lake.temperature
```

Get volumetrically averaged whole lake temperature

Description

Calculates volumetrically weighted average whole lake temperature using the supplied water temperature timeseries.

Usage

```
whole.lake.temperature(wtr, depths, bthA, bthD)
```

Arguments

wtr	a numeric vector of water temperature in degrees C.
depths	a numeric vector corresponding to the depths (in m) of the wtr measurements
bthA	a numeric vector of cross sectional areas (m^2) corresponding to bthD depths
bthD	a numeric vector of depths (m) which correspond to areal measures in bthA

See Also

```
hypo.temperature, epi.temperature
```

36 wtr.heatmap.layers

wtr.heat.map

Plots a heat-map of water temperature.

Description

This creates a simple, default heatmap of water temperature.

Usage

```
wtr.heat.map(wtr, ...)
```

Arguments

wtr Data frame of water temperature loaded with load.ts.

... Additional parameters supplied to filled.contour to modify defaults. Common examples include zlim and plot.title.

See Also

load.ts

Examples

```
#Get the path for the package example file included
wtr.path <- system.file('extdata', 'Sparkling.daily.wtr', package="rLakeAnalyzer")
#Load data for example lake, Sparkilng Lake, Wisconsin.
sp.wtr = load.ts(wtr.path)
#Plot default figure
wtr.heat.map(sp.wtr)
#Change defaults supplied to filled.contour
wtr.heat.map(sp.wtr, zlim=c(0,15), plot.title="Sparkling Water Temp (C)")</pre>
```

wtr.heatmap.layers

Plots water temperature heatmap with major limnetic layers indicated

Description

This creates a heat map of water temperature similar to wtr.heat.map with additional lines drawn to denote the thermocline, and the top and bottom of the metalimnion as calculated using ts.meta.depths and thermo.depth.

wtr.layer 37

Usage

```
wtr.heatmap.layers(wtr, ...)
```

Arguments

wtr Data frame of water temperature loaded with load.ts.
... Additional parameters supplied to filled.contour to modify defaults. Common examples include zlim and plot.title.

Note

This plot cannot be used in customized multi-panel figures usinglayout as layout is already used in the filled.contour plotting function.

See Also

```
wtr.heat.map load.ts ts.meta.depths ts.thermo.depth
```

Examples

```
#Get the path for the package example file included
wtr.path <- system.file('extdata', 'Sparkling.wtr', package="rLakeAnalyzer")

#Load data for example lake, Sparkilng Lake, Wisconsin.
wtr = load.ts(wtr.path)

# generate default plot
## Not run:
wtr.heatmap.layers(wtr)

## End(Not run)</pre>
```

wtr.layer

Exploration of lake water column layers

Description

Extract water column parameters of a given parameter from a profile using the split-and-merge algorithm. The cline is defined as the midpoint of the layer of water where the physical property change in the greatest over a small difference. The exact cline depends on the specification of measure. For example if temperature is specified, then we can expect cline to output the thermocline.

Usage

```
wtr.layer(data, depth, measure, thres = 0.1, z0 = 2.5, zmax = 150,
   nseg = "unconstrained")
```

38 wtr.lineseries

Arguments

data	data supplied as a bare (unquoted) value
depth	depth in metres; should be an increasing vector; supplied as a bare (unquoted)

value

measure parameter measured in the water column profile; supplied as a bare (unquoted)

value

thres error norm; defaults to 0.1

z0 initial depth in metres. Defaults to 2.5m
zmax maximum depth in metres: defaults to 150m

nseg optional parameter to define the number of segments a priori; defaults to an un-

constrained approach whereby the algorithm determines segmentations by min-

imzing the error norm over each segment

Value

a dataframes with a list column. This includes: nseg (number of segments), mld (mix layer depth), cline (the midpoint of the segment connecting inflection points that has the maximum slope; thermocline for temperature measures) and segments calculated by the sm algorithm.

References

Thomson, R. and I. Fine. 2003. Estimating Mixed Layer Depth from Oceanic Profile Data. Journal of Atmospheric and Oceanic Technology. 20(2), 319-329.

Examples

```
data("latesummer")
df1 <- wtr.layer(depth=latesummer$depth, measure = latesummer$temper)
df1$mld
df1$segments
wtr.layer(data = latesummer, depth=depth, measure = temper, nseg=4)</pre>
```

wtr.lineseries

Creates a line based plot of temperature profile time series

Description

A non-heat map approach to visualizing a water temperature profile useful for identify temperature trends over time at discrete depths and diagnosing issues with data.

Usage

```
wtr.lineseries(wtr, ylab = "Temperature C", ...)
```

wtr.plot.temp 39

Arguments

wtr Data frame of water temperature loaded with load.ts.
ylab y axis title
... Additional parameters supplied to the plot function

See Also

```
See load.ts and wtr.heat.map
```

Examples

```
exampleFilePath <- system.file('extdata', 'Sparkling.wtr', package="rLakeAnalyzer")
wtr= load.ts(exampleFilePath)
## Not run:
wtr.lineseries(wtr, ylab = "Temperature C")
## End(Not run)</pre>
```

wtr.plot.temp

Creates a time series plot of the thermocline and top and bottom of the metalimnion

Description

A line based plot of calculated depths of the thermocline, and top and bottom of the metalimnion from a temperature profile time series.

Usage

```
wtr.plot.temp(wtr, ...)
```

Arguments

wtr Data frame of water temperature loaded with load.ts.

... Additional paramters supplied to ts.meta.depths and ts.thermo.depth

See Also

```
load.ts and wtr.lineseries
```

40 wtr.plot.temp

```
wtr.path <- system.file('extdata', 'Sparkling.wtr', package="rLakeAnalyzer")
#Load data for example lake, Sparkilng Lake, Wisconsin.
wtr = load.ts(wtr.path)
## Not run:
wtr.plot.temp(wtr)
## End(Not run)</pre>
```

Index

*Topic arith	buoyancy.freq,4
buoyancy.freq,4	center.buoyancy, 5
center.buoyancy, 5	center .buoyancy, 3
schmidt.stability, 19	depth.filter,6
ts.buoyancy.freq, 21	drop.datetime, 6
ts.center.buoyancy, 22	ar op. ad to time, o
ts.layer.temperature, 26	epi.temperature, 7, 9, 35
ts.wedderburn.number,31	
water.density, 33	filled.contour, 36, 37
wedderburn.number, 34	
*Topic datasets	get.datetime,7
latesummer, 12	get.offsets,8
*Topic file	hype temperature 7.0.25
load.bathy, 15	hypo.temperature, $7, 9, 35$
load.ts, 16	internal.energy, 9, 24, 25, 27, 29, 31
*Topic hplot	2.1001.1102.101.101.101.101.101.101.101.
lake.number.plot, 11	lake.number, 10, 11, 20, 24, 25, 27, 29, 31, 35
schmidt.plot, 18	lake.number.plot, 11
wtr.heat.map,36	latesummer, 12
wtr.heatmap.layers, 36	layer.density, 13, 33
wtr.lineseries,38	layer.temperature, 14
wtr.plot.temp,39	layout, <i>37</i>
*Topic manip	load.bathy, 11, 15, 18, 21, 22, 24–31
get.offsets, 8	load.ts, 8, 11, 15, 16, 18, 21–31, 36, 37, 39
lake.number, 10	
layer.density, 13	meta.depths, 17, 24, 25, 27, 29, 31
layer.temperature, 14	
meta.depths, 17	rLakeAnalyzer, 18
thermo.depth, 20	rLakeAnalyzer-package (rLakeAnalyzer),
ts.internal.energy, 24	18
ts.lake.number, 25	schmidt.plot, 18
ts.meta.depths, 27	schmidt.stability, 18, 19, 24, 25, 27–31
ts.schmidt.stability, 28	Scimilat. Stability, 10, 17, 24, 25, 27–31
ts.thermo.depth, 29	thermo.depth, 17, 20, 24, 25, 27, 29, 31, 36
ts.uStar, 30	ts.buoyancy.freq, 21
uStar, 32	ts.center.buoyancy, 22
	ts.internal.energy, 24, 25, 27, 29, 31
approx.bathy, 2	ts.lake.number, 11, 16, 24, 25, 27, 29, 31
as.POSIXct, 16	ts.layer.temperature, 26

INDEX

```
ts.meta.depths, 16, 17, 24, 25, 27, 29, 31,
         36, 37, 39
ts.schmidt.stability, 16, 20, 24, 25, 27,
         28, 29, 31
ts.thermo.depth, 16, 21, 24, 25, 27, 29, 29,
         31, 37, 39
ts.uStar, 24, 25, 27, 29, 30, 33
ts.wedderburn.number, 31, 35
uStar, 32
water.density, 33
wedderburn.number, 11, 20, 34
whole.lake.temperature, 7, 9, 35
wtr.heat.map, 36, 36, 37, 39
wtr.heatmap.layers, 36
wtr.layer, 37
wtr.lineseries, 12, 38, 39
wtr.plot.temp, 39
```