```
% Name: Lamin Jammeh
% Class: EE480 Online
% Semster: Fall 2023
% HW 4
% Basic Problems
%% ******* question 2.1 *******
% ******* question 2.1(ai) *******
 clear;
 clc;
x = -20:20; %define the range for the X-axis
y = 100 * x; %y(t) @ -10<x(t)<10
y(x>10) = 1000; % y(t) when x(t)>10
y(x<-10) = -1000; % y(t) when x(t)<-10
plot(x, y, 'LineWidth',2); %plot x(t) vs y(t) at all stages
xlabel('x(t)'); %label x-axis
ylabel('y(t)'); %labels y-axis
title('x(t) vs y(t) for Q2.1a'); %assign a plot title
grid on;
%% ******* question 2.1(aii) *******
%test for linearity using the scaling method since there is only one input
%perform the scale test for Output scenario 1
S cale Test alpha*y(t) = alpha*S[x(t)]
 clear;
 clc;
x = -10:10; % define x(t) from -10:10
alpha = 10; %scaling factor is 10
y = mySystem1(x); %mySystem1 is a function defined as <math>y=100x(t)
y alpha = alpha * mySystem1(x);
 %condition for linearity
 System is Linaer = isequal(y_alpha,alpha * y);
  if System is Linaer
      disp('The System is Linear @ -10 < x(t) < 10');
  else
      disp('System is not Linear @ -10 < x(t) < 10');
  end
 %% ******* question 2.1(b) ******
 clear;
 clc;
 %notee am changing the y(t) from 100x(t) to be 2x(t) for better resultion on input x \checkmark
 t = -2:0.001:4; %range of value for t
```

```
u = heaviside(t); % use unit step function already build in matlab as heaviside
 x = 20 * cos(2*pi*t) .* u; %define Input of the system with the sinusoid wave
 y = 2.*(x);% define the output of the system with the system
 figure;
plot(t,x,'r');
hold on;
plot(t,y,'b','LineWidth',2);
xlabel('t');
 ylabel('Amplitude');
 legend('input=x(t)','output=y(t)')
title('x(t) vs y(t)');
 grid on;
hold off;
 % ******* question 2.1(c) ******
 t = -2:0.001:4; %range of value for t
u1 = heaviside(t-2); % use unit step function already build in matlab as heaviside
x1 = 20 * cos(2*pi*t-2) .* u1; %define Input of the system with the sinusoid wave
 y1 = 2.*(x1); % define the output of the system with the system
 figure;
plot(t,x1,'r');
hold on;
plot(t,y1,'b','LineWidth',2);
xlabel('t');
 vlabel('Amplitude');
 legend('input=x1(t)','output=y1(t)')
 title('x1(t) vs y1(t)');
 grid on;
hold off;
 % ******* compare the y(t) to y1(t) or the delayed response ********
 figure;
plot(t,y,'g','LineWidth',2);
hold on;
plot(t,y1,'r','LineWidth',3);
xlabel('t');
ylabel('Amplitude');
 legend('input=x1(t)','output=y1(t)')
 title('y(t) vs y1(t)');
 grid on;
hold off;
%% ******* question 2.5(b) ******
clear;
 clc
t = -10:0.01:10; % t range should show peak of y(t) of not increase the range
y = 1/2 \cdot (1-\exp(-2 \cdot t)) \cdot heaviside(t); %use matrix multiplication '.*' to include \checkmark
all values of t
```

```
plot(t,y,'LineWidth',2);
xlabel('t');
ylabel('y(t)');
title('y(t) plot for question 2.5(b)')
grid on;
%% ******* question 2.22(a) *******
clear;
clc;
% Vo(t) = R(t)Vi(t)
t = 0:0.01:0.2; % time range
u = heaviside (t);
R = (1 + 0.5*\cos(20*pi*t)).*u;
Vi = 1; %input voltage
Vo = -R * Vi;
figure;
plot(t, Vo, 'LineWidth', 2);
xlabel('t');
ylabel('Vo');
title('Output Vo = R * Vi')
grid on;
% ****** question 2.22(b) *******
%if the switch close at t0=50msec
% Vo(t+(0.05) = R(t+0.05)Vi(t+0.05)
                 % Starting time in seconds (50 ms)
t1 = t0:0.01:0.2; % Time vector from t0 to 0.2 seconds with a step of 1 ms
u1 = heaviside (t0); % Unit step function starting at t0
\mbox{\%} Calculate the values of R(t) for the given time vector:
R1 = (1 + 0.5 * cos(20 * pi* (t1 - t0))) .* u1;
% Calculate Vo(t) using the equation Vo(t) = R(t) * Vi(t):
Vo1 = -R1 .* Vi;
% Plot Vo(t):
figure;
plot(t1, Vo1);
xlabel('Time (s)');
ylabel('Vo(t)(V)');
title('Plot of Vo(t) with t0 = 50 \text{ ms'});
grid on;
% ****** Reason for Time invariant *******
```

```
% the unit step response u(t) makes the system Time Invariant because it
% only allows the system to be active at t>=0 irrespective of the anytime
% shifting
\% Vi(t) =1V which is time independent so the input voltage of the system won't change \checkmark
with time
%R(t) has a cos(20pit) which is equal to cos(10*2pi*t) with make the R(t)
%time invariant sine cos(2pi)=cos(0)=1 and any number multiply by zero is
%zero regarles of time shifting
%% ******* question 2.25 ******
clear;
clc;
% Note the Impulse response concoluted with the Input of the system gives
% the output
Step 1 convolute h(t) with x(t)
%Step 2 Apply the diode effect
% Define Impulse Response h(t) = e^{(-2t)} \cdot u(t)
figure;
t = 0:0.001:20;
u = heaviside(t); % u(t)
h = \exp(-2*t).*u;
subplot(2,2,1)
plot(t,h,'LineWidth',2);
xlabel('Time (s)');
ylabel('h(t)');
title("Impulse Response h(t) = e^{(-2t).u(t)}");
grid on;
% Define input x1(t) = cos(2pi*t)[u(t) - u(t-20)]
u1 = heaviside(t-20); % defines u(t-20)
x1 t = cos(2*pi*t).*(u-u1); %Defines x1(t)
subplot(2,2,2)
plot(t,x1 t,'LineWidth',2);
xlabel('Time (s)');
ylabel('x1(t)');
title("Input x1(t)=\cos(2pi*t)[u(t)-u(t-20)]");
grid on;
% Step 1 convolute x(t) with h(t)
y t = conv(x1 t,h, "same"); % Output without diode effect
subplot(2,2,3)
plot(t,y t, 'LineWidth',2);
xlabel('Time (s)');
ylabel('y(t)');
title('Output without Diode effect');
grid on;
```

```
% Apply Diode effect this will clip all negative values of y(t)
d = max(y t, 0); % Diode effect
y1 t=(y t).*d;
                % Apply diode effect to the output
subplot(2,2,4)
plot(t,y1_t,'LineWidth',2);
xlabel('Time (s)');
ylabel('y1(t)');
title('Output with Diode effect');
grid on;
% ******* using input x2(t) *******
% Define input x2(t) = \sin(pi \cdot t) e^{-20t} [u(t) - u(t-20)]
figure;
x2 t = sin(pi*t).*exp(-20*t).*(u-u1); %Defines x1(t)
subplot(2,2,1)
plot(t,x2 t,'LineWidth',2);
xlabel('Time (s)');
ylabel('x2(t)');
title("Input x2(t) = sin(pi*t)e^{(-20t)[u(t)-u(t-20)]}");
grid on;
% Step 1 convolute x(t) with h(t)
y t2 = conv(x2 t,h, "same"); % Output without diode effect
subplot(2,2,2)
plot(t,y t2,'LineWidth',2);
xlabel('Time (s)');
ylabel('y(t)');
title('Output without Diode effect');
grid on;
% Apply Diode effect this will clip all negative values of y(t)
d = max(y t2,0); % Diode effect
y2 t=(y t2).*d; % Apply diode effect to the output
subplot(2,2,3)
plot(t,y2 t,'LineWidth',2);
xlabel('Time (s)');
ylabel('y2(t)');
title('Output with Diode effect');
grid on;
% ******* using input x3(t) *******
%input x3(t)=r(t)-2r(t-2)+r(t-4)
% Step 1 define input x3(t) into 3 sections r(t), -2r(t-2), and r(t-4)
figure;
x3(t \ge 0) = 1; % defines the r(t) as unit step
```

```
x3(t \ge 2) = -2 * exp(-2 * (t(t \ge 2)-2)); % defines -2r(t-2) @t>=2
x3(t >= 4) = exp(-2*(t(t >= 4)-4)); % defines r(t-4) @t>=4
subplot(3,1,1)
plot(t,x3,'LineWidth',2);
xlabel('Time (s)');
ylabel('x3(t)');
title("Input x3(t)=r(t)-2r(t-2)+r(t-4)");
grid on;
% Step2 defines output y3(t) for input x3(t)
y3 = conv(x3, h, 'full'); % convolute x3(t)*h(t) for all parts of x3(t)
y3 = y3(1:length(t)); % define length of y3 to be the same as range of t
subplot(3,1,2)
plot(t,y3,'LineWidth',2);
xlabel('Time (s)');
ylabel('y(t)');
title('Output without Diode effect');
grid on;
% Step3 Apply Diode effect this will clip all negative values of y(t)
d = max(y3,0); % Diode effect
y3 t=(y3).*d;
               % Apply diode effect to the output
subplot(3,1,3)
plot(t,y3 t,'LineWidth',2);
xlabel('Time (s)');
ylabel('y3(t)');
title('Output with Diode effect');
grid on;
```