

abp



ABP Professional LCD Curling Iron

Important Safety Instructions

Thank you for choosing ABP Professional curling iron, please read all the instructions before using!

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

KEEP AWAY FROM WATER.

DANGER: As with most electrical appliances, electrical parts are electrically live even when the switch is off.

To reduce the risk of death by electric shock:

1. Always “unplug it” immediately after using.
2. DO NOT use while bathing.
3. DO NOT place or store appliance where it can fall or be pulled into a tub or sink.
4. DO NOT use near, place in or drop into water or other liquid.
5. If an appliance falls into water, “unplug it” immediately. DO NOT reach into the water.
6. DO NOT use an appliance with a twisted, bent or otherwise damaged cord.



WARNING: To reduce the risk of burns, fire, electrocution, or injury to persons:

1. An appliance should never be left unattended when plugged in. Turn off the switch and unplug the electrical cord when not in use.
 2. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
 3. Use this appliance only for its intended use as described in this manual.
- DO NOT use attachments not recommended by the manufacturer.

4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service center for repair or replacement.
5. Keep the cord away from heated surfaces. DO NOT pull, twist or wrap the cord around the appliance.
6. Never use while sleeping.
7. Never drop or insert any object into any opening.
8. DO NOT use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
9. This curling iron is hot when in use. DO NOT let eyes and bare skin touch heated surfaces. Use the handle.
10. DO NOT use an extension cord with this appliance.
11. DO NOT place the heated appliance directly on any surface while it is hot or plugged in. Use the stand provided.
12. Keep the safety stand extended forward while in use.
13. DO NOT operate this appliance with a voltage converter

Maintenance Instructions

1. Your appliance is virtually maintenance-free. No lubrication is needed.
2. Keep heated surfaces clean and free of dust, dirt, and hair spray.
3. If cleaning becomes necessary, unplug the appliance from the power source and clean with a damp cloth.
4. Never wrap the cord around the appliance since this will cause the cord to wear prematurely and break. If the cord becomes twisted, untwist prior to use.
5. Handle the cord carefully for longer life and do not put any stress on the cord where it enters the handle.
6. Do not attempt to repair the appliance by yourself.

Storage Instructions

When the appliance not in use, your curling iron should be disconnected and stored in safe, dry location, out of reaching for children. Do not wrap the cord around the curling iron. Allow the cord hang or lie loose and straight at the point of the entry of the curling iron.

Operating Instructions

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

IMPORTANT: During the first few minutes of initial use, you may notice smoke and a slight odor. This is normal and is not a cause for concern.

Start-up

Plug the iron into an electrical outlet and slide the On / Off Switch to the "On" position. Allow the appliance at least 60 seconds heating time.

Caution: Curling irons with Rheostat Control Dials operate at high temperatures when used on high settings. When using for the first time, begin with the LOWEST setting. Please read all instructions carefully before using. For best results, follow these guidelines:

Heat Selection Hair Type

180 °F - 300°F For Very soft and thin hair

320 °F - 340 °F For soft and thin hair

360 °F - 390 °F For thin, fine or bleached hair

410 °F - 430 °F For dyed or darkened colored hair

450 °F - 450 °F For thick, curly and wavy hair

Helpful Styling Hints


- Hair should be clean and dried completely before using any styling tool.
- Comb out a 2-inch section of hair and place hair ends between the Barrel and Clamp. The Clamp should be on top of the hair.
- Using one hand to hold the Insulated Tip and the other to hold the curling iron Handle, roll under for a curl and over for a flip.
- Leave the iron in fine hair for 5 to 8 seconds, and 10 to 15 seconds for thick hair.
- Press Thumb Grip to release hair.
- Allow curls to cool before combing or brushing.
- When styling is complete, slide the “On / Off” Switch to the “Off” position. Unplug the appliance and allow it to cool before storing.

1-Year Limited Warranty

ABP warrants to the original purchaser that this appliance is free from defects in workmanship for 1 years from the date of purchase. This warranty does not cover damages resulting from accident, misuse, abuse, attempts at repair or the use of unauthorized attachments.

If this appliance fails to operate properly under normal use within 1 years from purchase because of defect, please contact us via the platform you purchased from or via our customer service email with the proof of your purchase:
wangxuehong@foxmail.com

Product Overview



Note: Press and hold the "+" and "-" buttons at the same time to switch between °C and °F display modes

Package Includes: Curling iron *1, User Manual *1,

Product Specification

Brand	abp
Input Power	100-240V 50/60Hz (Worldwide Auto Voltage)
Temperature	180 - 450 F Degree
Auto Shutoff	60 Minutes
Hair Type	All hair types



Note

- It will take 30-60 seconds for the appliance to heat once switched on.
- The appliance has intelligent features of the high efficiency and energy saving. After 60 minutes working, it will be switched off automatically. If it is put into work again, press the power button for restarting the appliance.
- While using the appliance, the hair should be under dry status, otherwise,
- You should choose the suitable temperature and use the appliance properly according to your hair condition, otherwise, it may make your hair dry.
- To protect your hair from heat damage, you can use Lanvier heat protectant spray for hair protection.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is Subject to the following two conditions: (1) This device may cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.