
## **ER-SH-NOISE**



### **Contents**

#### **Features**

Sample and Hold Noise Generator


**Assembly Sheet** 

#### **Features**

- Eurorack 6HP, 3U module
- LF398 Sample and Hold (https://www.mouser.com/ProductDetail/926-LF398AN-NOPB)
  - Based on schmitzbits YASH \* (Yet another Sample and Hold) design (https://www.schmitzbits.de/sah.html)
  - Adjustable Internal Clock over-ridden by external jack
  - Signal Level LED
- Noise Generator
  - Based on Moritz Klein's <u>Designing a white, pink & blue noise generator from scratch (https://www.youtube.com/watch?v=0yB h wFkh4) design</u>
  - White, Pink, Blue noise outputs
  - Outputs are all buffered
- White noise routed to Sample and hold switch input
  - If no jack is connected to the Sample and Hold Input jack, the input is from the white noise output
- 10 pin Eurorack power connector


#### Sample and Hold

 Credit Moritz Klein's Designing a white, pink & blue noise generator from scratch (https://www.youtube.com/watch?v= 0yB\_h\_wFkh4) design




#### **Noise Generator**

- Credit Moritz Klein's Designing a white, pink & blue noise generator from scratch (https://www.youtube.com/watch?v= 0yB\_h\_wFkh4) design
- Noise Generator




White/Pink/Blue noise



Low Pass Filter (Pink Noise)

# PSEUDO-3dB/OCT LOW PASS 100K 330p 33n IOK 51K 2 K 100K 22 K 100% 10% 1% lok f IK 100

High Pass Filter (Blue Noise)



## **Assembly Sheet**

ER-SH-NOISE Rev 1 Assembly Sheet

Retrieved from "http://land-boards.com/blwiki/index.php?title=ER-SH-NOISE&oldid=21504"

This page was last edited on 3 November 2022, at 17:55.