


Device to Cloud ESP8266 QMTT in MSVS2017



Sketchbook location



Edit PubSubClient.h



Change "#define MQTT_MAX_PACKET_SIZE" to 256

```
D:\Documents\Arduino\libraries\PubSubClient\src\PubSubClient.h - Notepad++
File Edit Search View Encoding Language Settings Tools Macro Run Plugins Window ?
7 🔑 🗎 🖺 🥦 R R A | 🔏 R R R P P C | ## 🐈 🔍 🤍 R R | 📑 1 1 🗜 🗷 💹 🖍 🖆 👁 🕩 🗩
🗏 outline.txt 🗵 📙 new 2 🗵 📙 PubSubClient.h 🗵
      PubSubClient.h - A simple client for MQTT.
       Nick O'Leary
       http://knolleary.net
    □#ifndef PubSubClient h
      #define PubSubClient_h
     #include <Arduino.h>
     #include "IPAddress.h"
     #include "Client.h"
      #include "Stream.h"
13
     #define MQTT_VERSION_3_1
     #define MQTT_VERSION_3_1_1
17
    // MOTT VERSION : Pick the version
     //#define MQTT_VERSION MQTT_VERSION_3_1
20 p#ifndef MQTT_VERSION
     #define MQTT_VERSION MQTT_VERSION_3_1_1
22
      #endif
     // MQTT_MAX_PACKET_SIZE : Maximum p c'et size
#define MQTT MAX PACKET SIZE 256
     #endif
 28
     // MQTT_KEEPALIVE : keepAlive interval in Seconds
   #ifndef MQTT_KEEPALIVE
```