# ARM Cortex-M3 Instruction Set & Architecture




### Why another Micro

- Greater performance efficiency: allowing more work to be done without increasing the frequency or power requirements
- Low power consumption: enabling longer battery life, especially critical in portable products including wireless networking applications
- Enhanced determinism: guaranteeing that critical tasks and interrupts are serviced as quickly as possible and in a known number of cycles
- Improved code density: ensuring that code fits in a small memory footprint
- Ease of use: providing easier programmability and debugging for the growing number of 8-bit and 16-bit users migrating to 32 bits
- Lower cost solutions: reducing 32-bit-based system costs close to those of legacy 8-bit and 16-bit devices and enabling low-end, 32-bit microcontrollers to be priced at less than US\$1 for the first time
- Wide choice of development tools: from low-cost or free compilers to full-featured development suites from many development tool vendors


#### Processor vs. MCU

#### **Focus today**




#### ARM Cortex-M3 Processor

- Cortex-M3 architecture
- Harvard bus architecture
  - 3-stage pipeline with branch speculation
- Configurable nested vectored interrupt controller (NVIC)
- Wake-up Interrupt Controller (WIC)
  - Enables ultra low-power standby operation
- Extended configurability of debug and trace capabilities
  - More flexibility for meeting specific market requirements
- Optional components for specific market reqs.
  - Memory Protection Unit (MPU)
  - Embedded Trace Macrocell™(ETM™)
- Support for fault robust implementations via configurable observation interface
  - EC61508 standard SIL3 certification
- Physical IP support
  - Power Management Kit<sup>™</sup>(PMK) + low-power standard cell libraries and memories enable0.18µm Ultra-Low Leakage (ULL) process



Comparison	Cortex-M0	Cortex-M3		
DMIPS/MHz	0.9	1.25		
Gate count	12k 43k			
Number interrupts	1-32 + NMI	1-240 + NMI		
Interrupt priorities	4	256		
Breakpoints, Watchpoints	4/2, 2/1	8/4, 2/1		
MPU, integrated trace option	No	Yes		
Hardware Divide	No	Yes		



### ARM Architecture roadmap



ARM7TDMI ARM922T

Thumb instruction set



ARM926EJ-S ARM946E-S ARM966E-S

Improved ARM/Thumb Interworking

DSP instructions

Extensions:

Jazelle (5TEJ)



ARM1136JF-S ARM1176JZF-S ARM11 MPCore

SIMD Instructions

Unaligned data support

Extensions:

Thumb-2 (6T2)

TrustZone (6Z)

Multicore (6K)



Cortex-A8/R4/M3/M1

Thumb-2

Extensions:

v7A (applications) – NEON

v7R (real time) – HW Divide


V7M (microcontroller) – HW Divide and Thumb-2 only

# Which architecture is my processor?

	Processor core	Architecture
•	ARM7TDMI family	v4T
	<ul> <li>ARM720T, ARM740T</li> </ul>	
•	ARM9TDMI family	v4T
	<ul><li>ARM920T,ARM922T,ARM940T</li></ul>	
•	ARM9E family	v5TE, v5TEJ
	<ul> <li>ARM946E-S, ARM966E-S, ARM926EJ-S</li> </ul>	
•	ARM10E family	v5TE, v5TEJ
	<ul> <li>ARM1020E, ARM1022E, ARM1026EJ-S</li> </ul>	
•	ARM11 family	v6
	<ul><li>ARM1136J(F)-S</li></ul>	
	<ul><li>ARM1156T2(F)-S</li></ul>	v6T2
	<ul><li>ARM1176JZ(F)-S</li></ul>	v6Z
•	Cortex family	
	<ul><li>ARM Cortex-A8</li></ul>	v7A
	<ul><li>ARM Cortex-R4</li></ul>	v7R
	<ul><li>ARM Cortex-M3</li></ul>	v7M

#### Thumb-2

- Mixes 16 and 32 bits instructions
  - Enhancements: eg. UDIV, SDIF division, bit-field operators
     UFBX, BFC, BFE, wrt traditional ARMv4T
  - No need to mode switch, can be mixed freely
- Not backwards binary compatible
  - But porting is «easy»



# ARMv7 M (Thumb-2) features

Source	Destination	Cycles
16b x 16b	32b	1
32b x <b>1</b> 6b	32b	1
32b x 32b	32b	1
32b x 32b	64b	3-7*

Dynamic compiler support

VFPv3

NEON™ advanced SIMD

Thumb®-2 (option)

TrustZone™

SIMD

VFPv2


Jazelle®

ARMv5

ARMv6

Thumb-2 (mandated)

ARMv7 A&R



Mix of 16 and 32b instructions

1.2 CPI

26% higher code density ARM32

25% speed improvement over Thumb16

Thumb-2 only

ARMv7 M

#### Cortex-M3 features

#### Low-gate count with advanced features

- —ARMv7-M: A Thumb-2 ISA subset, consisting of all base Thumb-2 instructions, 16-bit and 32-bit, and excluding blocks for media, SIMD, E (DSP), and ARM system access.
- -Banked SP only
- Hardware divide instructions, SDIV and UDIV (Thumb-2 instructions)
- Handler and Thread modes
- -Thumb and Debug states.
- Interruptible-continued LDM/STM, PUSH/POP for low interrupt latency.
- Automatic processor state saving and restoration for low latency Interrupt
   Service Routine (ISR) entry and exit.
- —ARM architecture v6 style BE8/LE support.
- –ARMv6 unaligned accesses.

# M3 - Enhanced Interrupt support

#### Nested Vectored Interrupt Controller (NVIC) integrated with the processor for low latency

- -Configurable number, 1 to 240, of external interrupts
- -Configurable number, 3 to 8, of bits of priority.
- Dynamic reprioritization of interrupts.
- Priority grouping. This allows selection of pre-empting interrupt levels and non pre-empting interrupt levels
- Support for tail-chaining, and late arrival, of interrupts. This enables back-toback interrupt processing without the overhead of state saving and restoration between interrupts
- Processor state automatically saved on interrupt entry, and restored on interrupt exit, with no instruction overhead.

# Memory, Peripheral, Debug IFs

- Optional Memory Protection Unit (MPU)
  - -Eight memory regions.
  - -Sub Region Disable (SRD), enabling efficient use of memory regions.
  - -Background region can be enabled which implements the default memory map attributes.


#### Bus interfaces:

- -AHBLite ICode, DCode and System bus interfaces.
- -APB Private Peripheral Bus (PPB) Interface
- -Bit band support. Atomic bit-band write and read operations.
- -Memory access alignment.
- Write buffer. For buffering of write data.

#### • Low-cost debug solution:

- —Debug access to all memory and registers in the system, including Cortex-M3 register bank when the core is running, halted, or held in reset.
- -Serial Wire (SW-DP) or JTAG (JTAG-DP) debug access, or both.
- -Flash Patch and Breakpoint unit (FPB) for implementing breakpoints and code patches.
- Data Watchpoint and Trigger unit (DWT) for implementing watchpoints, trigger resources, and system profiling.
- Instrumentation Trace Macrocell (ITM) for support of printf style debugging.
  - —Trace Port Interface Unit (TPIU) for bridging to a Trace Port Analyzer.
  - -Optional Embedded Trace Macrocell (ETM) for instruction trace.

### Architecture Diagram




### Pipeline


Harvard architecture

Separate Instruction & Data buses enable parallel fetch & store


Advanced 3-Stage Pipeline Includes Branch Forwarding & Speculation

Additional Write-Back via Bus Matrix





#### Instruction Prefetch & Execution



#### **Processor Modes**

- The ARM has seven basic operating modes:
  - Each mode has access to:
    - Its own stack space and a different subset of registers
  - Some operations can only be carried out in a privileged mode

		Mode	Description	
(A		Supervisor (SVC)	Entered on reset and when a Software Interrupt instruction (SWI) is executed	
mode		FIQ	Entered when a high priority (fast) interrupt is raised	
Exception modes		IRQ	Entered when a low priority (normal) interrupt is raised	Privileged
Exc		Abort	Used to handle memory access violations	modes
	_	Undef	Used to handle undefined instructions	
		System	Privileged mode using the same registers as User mode	
		User	Mode under which most Applications / OS tasks run	Unprivileged mode


# **Operating Modes**

#### User mode:

- Normal program execution mode
- System resources unavailable
- Mode changed by exception only

#### **Exception modes:**

- Entered upon exception
- Full accessto system resources
- Mode changed freely




		Operations (privilege out of reset)	Stacks (Main out of reset)
es of reset)	Handler - An exception is being processed	Privileged execution Full control	Main Stack Used by OS and Exceptions
Mod (Thread out	Thread - No exception is being processed - Normal code is executing	Privileged/Unprivileged	Main/Process

# Exceptions

Exception	Mode	Priority	IV Address
Reset	Supervisor	1	0x0000000
Undefined instruction	Undefined	6	0x00000004
Software interrupt	Supervisor	6	0x00000008
Prefetch Abort	Abort	5	0x000000C
Data Abort	Abort	2	0x0000010
Interrupt	IRQ	4	0x00000018
Fast interrupt	FIQ	3	0x0000001C

Table 1 - Exception types, sorted by Interrupt Vector addresses

### Registers



### **ARM Registers**

- 31 general-purpose 32-bit registers
- 16 visible, R0 R15
- Others speed up the exception process

# ARM Registers (2)


#### Special roles:

- Hardware
  - R14 Link Register (LR): optionally holds return address for branch instructions
  - R15 Program Counter (PC)
- Software
  - R13 Stack Pointer (SP)

# ARM Registers (3)

- Current Program Status Register (CPSR)
- Saved Program Status Register (SPSR)
- On exception, entering mod mode:
  - $(PC + 4) \rightarrow LR$
  - CPSR → SPSR\_mod
  - PC ← IV address
  - R13, R14 replaced by R13\_mod, R14\_mod
  - In case of FIQ mode R7 R12 also replaced

# **Special Registers**



Register	Function
xPSR	Provide arithmetic and logic processing flags (zero flag and carry flag), execution status, and current executing interrupt number
PRIMASK	Disable all interrupts except the nonmaskable interrupt (NMI) and hard fault
FAULTMASK	Disable all interrupts except the NMI
BASEPRI	Disable all interrupts of specific priority level or lower priority level
CONTROL	Define privileged status and stack pointer selection


# Memory map


 Statically defined memory map (faster addr decoding) 4GB of address psace

0xFFFFFFFF 0xE0000000	System level	Private peripherals including build-in interrupt controller (NVIC), MPU control registers, and debug components		
0xDFFFFFFF				
	External device	Mainly used as external peripherals		
0xA0000000				
0x9FFFFFF				
	External RAM	Mainly used as external memory		
0x60000000				
0x5FFFFFFF	Peripherals	Mainly used as peripherals		
0x40000000	Periprierais	Mainly used as periprierals		
0x3FFFFFF	SRAM	Mainly used as static RAM		
0x20000000	SHAW	Mainly asea as state nam		
0x1FFFFFFF	CODE	Mainly used for program code. Also provides exception		
0x00000000	CODE	code. Also provides exception		

### **Bit Banding**

Fast single-bit manipulation: 1MB → 32MB aliased regions in SRAM & Peripheral space






#### **Cortex M3 Instruction Set**



### Major Elements of ISA

(registers, memory, word size, endianess, conditions, instructions, addressing modes)



#### Traditional ARM instructions

- Fixed length of 32 bits
- Commonly take two or three operands
- Process data held in registers
- Shift & ALU operation in single clock cycle
- Access memory with load and store instructions only
  - Load/Store multiple register
- Can be extended to execute conditionally by adding the appropriate suffix
- Affect the CPSR status flags by adding the 'S' suffix to the instruction

#### Thumb-2

- Original 16-bit Thumb instruction set
  - a subset of the full ARM instructions
  - performs similar functions to selective 32-bit ARM instructions but in 16-bit code size
- For ARM instructions that are not available
  - more 16-bit Thumb instructions are needed to execute the same function compared to using ARM instructions
  - but performance may be degraded
- Hence the introduction of the Thumb-2 instruction set
  - enhances the 16-bit Thumb instructions with additional 32-bit instructions
- All ARMv7 chips support the Thumb-2 (& ARM) instruction set
  - but Cortex-M3 supports only the 16-bit/32-bit Thumb-2 instruction set


#### 16bit Thumb-2

Some of the changes used to reduce the length of the instructions from 32 bits to 16 bits:

- reduce the number of bits used to identify the register
  - less number of registers can be used
- reduce the number of bits used for the immediate value
  - smaller number range
- remove options such as 'S'
  - make it default for some instructions
- remove conditional fields (N, Z, V, C)
- no conditional executions (except branch)
- remove the optional shift (and no barrel shifter operation
  - introduce dedicated shift instructions
- remove some of the instructions
  - more restricted coding

# Thumb-2 Implementation

 The 32-bit ARM Thumb-2 instructions are added through the space occupied by the Thumb BL and BLX instructions



32-bit Thumb-2 Instruction format

- The first Halfword (Hw1)
  - determines the instruction length and functionality
- If the processor decodes the instruction as 32-bit long
  - the processor fetches the second halfword (hw2) of the instruction from the instruction address plus two

# Unified Assembly Language

- UAL supports generation of either Thumb-2 or ARM instructions from the same source code
  - same syntax for both the Thumb code and ARM code
  - enable portability of code for different ARM processor families
- Interpretation of code type is based on the directive listed in the assembly file
- Example:
  - For GNU GAS, the directive for UAL is

#### .syntax unified


For ARM assembler, the directive for UAL is

#### **THUMB**

### 32bit Instruction Encoding

**Example: ADD instruction format** 

ARM 32-bit encoding for ADD with immediate field



#### ARM and 16-bit Instruction Encoding

- Equivalent 16-bit Thumb instruction: ADD r1, #2
  - No condition flag
  - No rotate field for the immediate number
  - Use 3-bit encoding for the register
  - Shorter opcode with implicit flag settings (e.g. the set status flag is always set)

#### Application Program Status Register (APSR)

31	30	29	28	27	26 0	_
N	Z	С	v	Q	RESERVED	

#### APSR bit fields are in the following two categories:

- Reserved bits are allocated to system features or are available for future expansion. Further
  information on currently allocated reserved bits is available in The special-purpose program status
  registers (xPSR) on page B1-8. Application level software must ignore values read from reserved bits,
  and preserve their value on a write. The bits are defined as UNK/SBZP.
- Flags that can be set by many instructions:
  - N, bit [31] Negative condition code flag. Set to bit [31] of the result of the instruction. If the result is regarded as a two's complement signed integer, then N == 1 if the result is negative and N = 0 if it is positive or zero.
  - Z, bit [30] Zero condition code flag. Set to 1 if the result of the instruction is zero, and to 0 otherwise. A result of zero often indicates an equal result from a comparison.
  - C, bit [29] Carry condition code flag. Set to 1 if the instruction results in a carry condition, for example an unsigned overflow on an addition.
  - V, bit [28] Overflow condition code flag. Set to 1 if the instruction results in an overflow condition, for example a signed overflow on an addition.
  - Q, bit [27] Set to 1 if an SSAT or USAT instruction changes (saturates) the input value for the signed or unsigned range of the result.

# Updating the APSR

- SUB Rx, Ry
  - Rx = Rx Ry
  - APSR unchanged
- SUBS
  - Rx = Rx Ry
  - APSR N or Z bits might be set
- ADD Rx, Ry
  - Rx = Rx + Ry
  - APSR unchanged
- ADD<u>S</u>
  - Rx = Rx + Ry
  - APSR C or V bits might be set

#### **Conditional Execution**

- Each data processing instruction prefixed by condition code
- Result smooth flow of instructions through pipeline
- 16 condition codes:

EQ	equal	MI	negative	HI unsigned higher		GT	signed greater than
NE	not equal	PL	positive or zero	LS	unsigned lower or same	LE	signed less than or equal
cs	S unsigned higher or same		overflow	GE	signed greater than or equal	AL	always
СС	unsigned lower	VC	no overflow	LT	signed less than	NV	special purpose

#### **Conditional Execution**

- Every ARM (32 bit) instruction is conditionally executed.
- The top four bits are ANDed with the CPSR condition codes, If they do not matched the instruction is executed as NOP
- The AL condition is used to execute the instruction irrespective of the value of the condition code flags.
- By default, data processing instructions do not affect the condition code flags but the flags can be optionally set by using "S". Ex: SUBS r1,r1,#1
- Conditional Execution improves code density and performance by reducing the number of forward branch instructions.

Normal	Conditional
CMP r3,#0	CMP r3,#0
BEQ skip	ADDNE r0,r1,r2
ADD r0,r1,r2	
skip	

#### Conditional Execution and Flags

- ARM instructions can be made to execute conditionally by postfixing them with the appropriate condition code
  - This can increase code density and increase performance by reducing the number of forward branches

```
CMP r0, r1 \leftarrow r0 - r1, compare r0 with r1 and set flags

ADDGT r2, r2, #1 \leftarrow if > r2=r2+1 flags remain unchanged

ADDLE r3, r3, #1 \leftarrow if <= r3=r3+1 flags remain unchanged
```

 By default, data processing instructions do not affect the condition flags but this can be achieved by post fixing the instruction (and any condition code) with an "S"

# ADD r2, r2, r3 r2=r2+r3 SUBS r1, r1, #0x01 decrement r1 and set flags BNE 100p if Z flag clear then branch

#### Conditional execution examples

#### C source code

# if (r0 == 0)r1 = r1 + 1;else r2 = r2 + 1;

#### **ARM** instructions

```
unconditional
```

CMP r0, #0

```
BNE else
ADD r1, r1, #1
B end
```

ADD r2, r2, #1

end

else

#### 5 instructions


- 5 words
- 5 or 6 cycles

```
conditional
```

```
CMP r0, #0
  ADDEQ r1, r1,
#1
  ADDNE r2, r2,
#1
```

- 3 instructions
- 3 words
- 3 cycles

#### ARM Instruction Set (3)



#### **Data Processing Instructions**

- Arithmetic and logical operations
- 3-address format:
  - Two 32-bit operands(op1 is register, op2 is register or immediate)
  - 32-bit result placed in a register
- Barrel shifter for op2 allows full 32-bit shift within instruction cycle

#### Data Processing Instructions (2)

- Arithmetic operations:
  - ADD, ADDC, SUB, SUBC, RSB, RSC
- Bit-wise logical operations:
  - AND, EOR, ORR, BIC
- Register movement operations:
  - MOV, MVN
- Comparison operations:
  - TST, TEQ, CMP, CMN

#### Data Processing Instructions (3)

Conditional codes

+

Data processing instructions

+

Barrel shifter

\_

Powerful tools for efficient coded programs

## Data Processing Instructions (4)


e.g.:

if (z==1) R1=R2+(R3\*4)

compiles to

EQADDS R1,R2,R3, LSL #2


(SINGLE INSTRUCTION!)



#### Multiply Instructions

- Integer multiplication (32-bit result)
- Long integer multiplication (64-bit result)
- Built in Multiply Accumulate Unit (MAC)
- Multiply and accumulate instructions add product to running total

#### Saturated Arithmetic



# Multiply Instructions

#### • Instructions:

MUL	Multiply	32-bit result
MULA	Multiply accumulate	32-bit result
UMULL	Unsigned multiply	64-bit result
UMLAL	Unsigned multiply accumulate	64-bit result
SMULL	Signed multiply	64-bit result
SMLAL	Signed multiply accumulate	64-bit result

#### Data Transfer Instructions

- Load/store instructions
- Used to move signed and unsigned
   Word, Half Word and Byte to and from registers
- Can be used to load PC
   (if target address is beyond branch instruction range)

LDR	Load Word	STR	Store Word
LDRH	Load Half Word	STRH	Store Half Word
LDRSH	Load Signed Half Word	STRSH	Store Signed Half Word
LDRB	Load Byte	STRB	Store Byte
LDRSB	Load Signed Byte	STRSB	Store Signed Byte

#### Addressing Modes


- Offset Addressing
  - Offset is added or subtracted from base register
  - Result used as effective address for memory access
  - [<Rn>, <offset>]
- Pre-indexed Addressing
  - Offset is applied to base register
  - Result used as effective address for memory access
  - Result written back into base register
  - [<Rn>, <offset>]!
- Post-indexed Addressing
  - The address from the base register is used as the EA
  - The offset is applied to the base and then written back
  - [<Rn>], <offset>

## <offset> options

- An immediate constant
  - **#10**
- An index register
  - <Rm>
- A shifted index register
  - <Rm>, LSL #<shift>

#### **Block Transfer Instructions**

- Load/Store Multiple instructions (LDM/STM)
- Whole register bank or a subset copied to memory or restored with single instruction




#### **Swap Instruction**

- Exchanges a word between registers
  - Two cycles but


single atomic action

Support for RT semaphores



#### Modifying the Status Registers

- Only indirectly
- MSR moves contents from CPSR/SPSR to selected GPR
- MRS moves contents from selected GPR to CPSR/SPSR
- Only in privileged modes



#### Software Interrupt

- SWI instruction
  - Forces CPU into supervisor mode
  - Usage: SWI #n

3	31	28	27	24	23	(	)
	Cond		Opco	ode	Ordinal		

- Maximum 2<sup>24</sup> calls
- Suitable for running privileged code and making OS calls

#### **Branching Instructions**

- Branch (B): jumps forwards/backwards up to 32 MB
- Branch link (BL):

```
same + saves (PC+4) in LR
```

- Suitable for function call/return
- Condition codes for conditional branches

#### **IF-THEN Instruction**

- Another alternative to execute conditional code is the new 16-bit IF-THEN (IT) instruction
  - no change in program flow
  - no branching overhead
- Can use with 32-bit Thumb-2 instructions that do not support the 'S' suffix
- Example:

```
CMP R1, R2 ; If R1 = R2

IT EQ ; execute next (1st)

; instruction

ADDEQ R2, R1, R0 ; 1st instruction
```

The conditional codes can be extended up to 4 instructions

#### Barrier instructions

Useful for multi-core & Self-modifying code

Instruction	Description
DMB	Data memory barrier; ensures that all memory accesses are completed before new memory access is committed
DSB	Data synchronization barrier; ensures that all memory accesses are completed before next instruction is executed
ISB	Instruction synchronization barrier; flushes the pipeline and ensures that all previous instructions are completed before executing new instructions

# Backup

