

Signal Generator 1-Channel 1Hz-150KHz

I . Introduction

This signal generator is a device that provides electrical signals at a variety of frequencies, square wave, and output levels. It is used as a signal source or excitation source for testing. Widely used in production practice and technology.

II . Features

1. With outer casing
2. LCD high definition display
3. Support UART
4. Support frequency adjustment
5. Support duty cycle adjustment
6. High precision detection
7. Support power-down memory function
8. 1-Channel PWM output
9. Dual Work Mode
10. Knob supports lock function to avoid misoperation
11. Support enable output

III. Parameter

Size: 3*1.65*1.45in(78*42*37mm)
Work Voltage: DC 3.3V-30V
Frequency Range(Normal mode): 1Hz~150KHz
Frequency Range(Precise mode): 1Hz~15KHz
Frequency Accuracy: 2%
Duty Cycle Accuracy: 1% at Normal mode
Duty Cycle Accuracy: 0.1% at Precise mode
Duty Cycle Range: 0. 00%-100%
Output Current: About 5-30mA
Output Amplitude: Same to input voltage
Work Temperature: -104°F ~185°F (-40°C~85°C)
Work Humidity: 0%~95%RH

IV. Frequency Range Setting

There are two work modes so it has two frequency range.

Normal Mode: Frequency range 1Hz~150KHz. Duty cycle range 0.00%-100%.
Duty cycle accuracy 1%.

Precise Mode: Frequency range 1Hz~15KHz. Duty cycle range 0.00%-100%.
Duty cycle accuracy 0.1%.

Enter the settings interface when short press rotary switch in the normal running status to select frequency range. Rotary potentiometer to set frequency value.

Keep pressing rotary switch for 10 seconds to switch Normal mode and Precise

mode.

Keep pressing for 5 seconds to lock parameters to protect the parameters from being modified.

Pay attention to the position where the decimal point moves when rotate potentiometer.

Display 'XXX'. No decimal point, The minimum frequency is 1Hz. The frequency range is 1Hz ~ 999Hz.

Display 'X.XX'. The decimal point is the penultimate, The minimum frequency is 0.01KHz. The frequency range is 1.00KHz ~ 9.99KHz.

Display 'XX.X'. The decimal point is the third last, The minimum frequency is 0.1KHz. The frequency range is 10.0KHz ~ 99.9KHz.

Display 'X.X.X'. The decimal point is fully lit, The minimum frequency is 1KHz. The frequency range is 1KHz ~ 150KHz.

For Example:

Display '100' means PWM output frequency is 100Hz;

Display '1.91' means PWM output frequency is 1.91KHz;

Display '52.1' means PWM output frequency is 52.1KHz;

Display '1.3.4' means PWM output frequency is 134KHz;

V. Duty Cycle Range Setting

Short press potentiometer to select set duty cycle and rotary potentiometer to set duty cycle value.

VI. Using Step

1. Connect to power supply
2. Press rotary switch for 10second to switch Normal mode and Precise mode
3. Short press rotary switch to set frequency and change value by rotating switch
4. Press rotary switch for 2second to set duty cycle
5. Keep press for 5second to lock set parameters
6. Test
7. Press button 'ON/OFF' to turn on or off PWM output
8. Remove power and connect load to use module.

VII. Appendix

1. WHDTS specializes in Electronics Products, such as circuit components, function modules, wireless module, robotics accessories, DIY kits etc.. WHDTS devotes lifetime to providing excellent products with competitive price, fast delivery and 100% after-sales service for all makers, DIYer, R & D personnel, electronic enthusiasts, students and teachers. We are aimed at making your electronics projects go with a swing.
2. WHDTS has long been engaged in Electronics Related Products **wholesale** and **retail** business. Welcome letter calls to discuss the wholesale and retail business.
3. We have been keeping trying to improve the manual. If any words or steps of the instruction confuses you, please feel free to let us know. We will appreciate for the

generous help of pointing out our expression problem. Thank you in advance.

4. We pledge seriously to you: We could fully satisfy you with our quality products, high-efficiency logistics and perfect after-sale service! We will **do our utmost to assist you** to complete the installation. Your satisfaction is our commitment.

5. If the product does not achieve the effect we described or you have any questions or problems with our product or the transaction unfortunately, **don't rush to give us a negative feedback** out of anger and impulse, please do not hesitate to **contact us** directly for further help.