Deltares
Enabling Delta Life

How to	Prepare ROWS-Flood at the start of an event
Description	Step by step description of how to prepare the SA system for Flood Operations
Comments	The *italic* phrases correspond to the red markings in the screenshots.
	Please be aware that the screenshots may deviate slightly from the application
version	2016-01

Because ROWS-Flood is a Stand Alone system, some of the data of the Live System ROWS is not automatically available. Therefore, we need to prepare the system when we start using it.

Overview of steps

1. Copy the data from ROWS-Flood\ImportPrepare to ROWS-Flood\Import
2. Run the appropriate import workflows in ROWS-Flood

ad 1. The data concerns the rating curves and historical events. Keep the subfolder structure as is. Overwrite files if prompted to.
Note: it could be that ROWS contains updated rating curves and/or historical events. In that case export the new files from ROWS and copy them to the Import folder of ROWS-Flood before you run the import tasks. It would be wise to update the data in the ImportPrepare\ folder as well.

ad 2. Run the tasks
Import Ratings from local Import folder and
Import historical events from local Import folder