

Enabling Delta Life

How to	Quarterly and yearly summary of all counted breaches
Description	All threshold crossings that have not been excluded are summed up
Comments	The <i>italic</i> phrases correspond to the red markings in the screenshots.
	Please be aware that the screenshots may deviate slightly from the application
version	2018-02



Breaches (aka threshold crossings) are all summed for quarterly and yearly reports. The operators can exclude crossings from this count. For example, once a breach has started, subsequent threshold crossings can be excluded (see HowTo_ThresholdCrossings_Exclusion). This how to describes how to generate these quarterly and annual reports.

- 1. In Workflows > Reporting > Export Quarterly report and run the appropriate task.
- 2. View the results in the internal web viewer. The html files are written locally to Export/Reports folder, from where they can copied into the overall report.

Note that if all but one threshold crossing in that period is excluded from the count, this will be reflected in the summary report (example for H at 409030 GULPA, see insert).

