Deltares

Enabling Delta Life

How to	View Water quality data in the Data Viewer
Description	Import and analyse water quality sample data
Comments	This is an excerpt of wiki page:
	https://publicwiki.deltares.nl/pages/viewpage.action?pageId=108954735
version	2016-01




Data Viewer and qualifier tree

in the Data Viewer, location(s), parameter(s), <u>and</u> qualifier(s) can be selected; qualifiers are used a sort of sub-parameters that define specific attributes of a parameter value, e.g. the parameter Mass of Fish (kg) can be further specified into different fish species (lucius esox, abramis brama, ...), gender (male, female), length class etc.; all these sub-parameters can be shown in a <u>qualifier tree</u>, which can be configured by the user. The use of qualifiers helps to keep the parameter list small.

In the qualifier tree one can:

- * toggle between different name conventions for the qualifiers, and
- * use the on-the-fly summation tool to sum selected qualifiers for the active timeSeries (location(s) and parameter(s) selection)



Example of a qualifier tree:

