## **Deltares**

Enabling Delta Life	7
n	

How to	Configuration – Add username to gain permission to the system
Description	Step by step description of how add a username to the UserGroups.xml
Comments	The <i>italic</i> phrases correspond to the red markings in the screenshots.
	Please be aware that the screenshots may deviate slightly from the application
version	2016-01

- 1. Open the file ..\Config\SystemConfigFiles\UserGroups.xml in a text editor like notepad.
- 2. Copy an existing line defining an user and replace the user id with your Windows login name
- 3. Save the file and either
  - a. Refresh ROWS-Flood: File > Reload Configuration (F5),
  - b. Restart ROWS-Flood
- Ad 2. This is what the content of UserGroups.xml looks like

```
<userGroup id="Forecaster">
<!-- MDBA work accounts -->
  <user id="rmw"/>
  <user id="prs"/>
  <user id="awb"/>
  <user id="am4"/>
  <user id="wl1"/>
  <user id="sk1"/>
  <user id="klg"/>
  <user id="jw"/>
  <user id="ng1"/>
  <user id="rs1"/>
  <user id="Il"/>
<!-- MDBA private accounts -->
 <user id="Peter"/>
<!-- Deltares employees -->
<user id="kleerma"/>
```