AI MEDIA GUARD

設備註冊與鏡頭 RTSP 添加操作說明

DVR AI MEDIAGUARD 系統操作說明 - HK

与太滨鄉

DOC FROM : D:\CamGuard610\DeviceConnector\DeviceConnector\NetCamGuardNew95\DOC\API 幫助說明

FROM D:\OpenssIRSA_NEW_MPEG_REC\new-ffmpeg-helper2023\MediaGuard\MediaGuard_DOC

業務 API

後臺連接: http://localhost:5002/

帳戶密碼: admin2 密碼: admin123

程式提交需要密碼 MD5 格式: 0192023a7bbd73250516f069df18b500 (admin123)

大多數的 API 路徑中,如需要返回的語言表示都是要求寫在路徑開頭:

例如: http://localhost:5002/zh-HK/Device/GetMainComBySerialNo/DeviceSerialNo123456789

語言標識有三種: zh-CN, zh-HK, en-US

設備: AI MdeiaGuard.exe 整套程式視為一個設備,需要雲端設備序列號和 device.json 的設備序列號一致。

API 連接列表: http://localhost:5002/api/index.html

獲取 API TOKEN 和登錄帳號一樣

1、註冊設備 (第一步)

定義與概念:設置指的是連接到雲的一個裝置,如海康門禁設備、錄影系統,如 Mediaguard 錄影系統,儘管是一個軟體,但被視為一個獨立的設備,授權控制是基於設備序列號。

設備列表對應的鏈接: http://81.71.74.135:5002/zh-HK/Device/DeviceList



2、CAMERA 鏡頭 (第二步)

在雲系統不屬於獨立的設備,是單獨定義的概念: Camera/鏡頭。





▶點擊這裡以配置鏡頭的具體功能業務。如果是 MediaGuard 系統,則必須配置準確,目前的容錯功能不多。



上述 Schedule 對 AI MediaGuard 是沒有作用的,僅僅 For Media 系統

3、啟動 MediaGuard 系統

需要先在雲端創建設備,然後設備下麵下掛具體鏡頭,並且鏡頭設置需要最少設定:是否保存 Video 是否保存圖片是否 RTMP(停用此功能,默認為 FALSE)。

所以啟動 MediaGuard 系統最啟動要定義雲端設備,和下掛定義的鏡頭。



Config.json 棄用,改使用 device.json (device 指盒子等等設備對象)

4、設備配置與播放列表 Camera List Json (來自 API)


這是獲取鏡頭列表,如果要用於 MediaGuard 系統的 InfoStream 的設置需要三方面配合才能合成一個配置:

```
"meta": {
    "success": true,
    "message": "OK",
    "ernorCode": -1
},
    "data": [
    "rtspIp": "192.168.0.92",
    "rtspDsername": "admin",
    "rtspDsername": "admin",
    "rtspPassword": "hik12345",
    "maincondid": "6000014",
    "cameraIo": stellame": "6800014",
    "cameraIo": mull,
    "siteName": "66",
    "rtsp!: "hsp://admin:hik12345@192.168.0.92:554/h264/ch1/main/av_stream",
    "type": 9,
    "online": "fd用中",
    "reateTime": "3023-01-20 00:00:00",
    "deviceId": 3007,
    "deviceId": 3007,
    "deviceId": 3007,
    "deviceId": 3007,
    "deviceId": 3007,
    "deviceIv": "1007,
    "deviceIv": 1006,
    "onlive": true
}
```

上述的 json 列表是由於沒有配置雲端鏡頭鏈接, 試試通過 bool CameraMpeg::camera list 這個函數,裡面改造成上面的字串而不是通過雲獲取。

FOR MediaGuard 的設備配置檔: device.json (在 conf//device.json) (必須保證是非簽名的 UTF8 格式文件)

設備配置檔說明:



```
"password": "D05751D442A016B5D03AE3BE3B1A37D3", 密碼 MD5
"password_format": "md5_32_upcase",
"reamrks": "serial no is hamc by toll from STAR-LangMXcore password forma"
"language_code": "zh-HK" 語言標識
                                                                   angMXcore password format is md5_32_upcase",
        "remarks": "cloud for api"
        "http_server": { WEB APP 的 URL 資訊 "scheme": "http", "host": "81.71.74.135", "port": 5002,
          "remarks": "web server"
        "remarks": "The node and cloud are the same, if they are separated, you need to set another one here"
        "ffmpegOpenInfo": false,
          "nHDType": "kHWDeviceTypeCUDA", 是否顯卡解碼 参考下麵的類型選填這裡
          "nHDTypeRemark": {
            "remarks": "硬體解碼類型",
"hdtype": [
             "kHWDeviceTypeNone", //沒有硬解碼設備
"kHWDeviceTypeVDPAU",
"kHWDeviceTypeCUDA", //硬解碼設備=NVIDA
"kHWDeviceTypeVAAPI",
"kHWDeviceTypeDXVA2",
              "kHWDeviceTypeQSV"
              "kHWDeviceTypeVIDEOTOOLBOX",
              "kHWDeviceTypeD3D11VA",
"kHWDeviceTypeDRM",
              "kHWDeviceTypeOPENCL"
              "kHWDeviceTypeMEDIACODEC"
           "remarks": "The node is used to configure the recording system and hardware environment ;Storage Limited bytes 502400000 = 502M;
videoRemainMinutes::The rule keeps video files for at least 15 minutes"
         'database": { //節點 database 是描述數據庫 ip、port 等
          "ip": "81.71.74.135",
"port": 3306,
         "base_frontend": "camera_guard_business",
"base_history": "camera_guard_history",
"user": "root",
"password": "root"
        "pool": { "database_pool": 30 },
"carPlateRecogBusiness": { //車牌識別業務,列出相關的車牌識別列表
          "enable": false,
          "permited_cameraID": [
           {
"cameraId": 17,
"name": "大華 SRV2 IP91"
              "rtspIp": "192.168.0.90",
"cameraId": 18,
"name": "海康 SRV2_IP91"
          "user": "admin",
"password": "123456",
"reamrks": "for card plate recognition, post to detct server and return the result and then post back to http server, Post time out
200millseconds - 500millseconds, timeout will be exited!"
        },
"doc_encoding": "the current document endoding is requied utf-8. *****"
```

5、播放 HLS 和 MP4 的請求格式

API 介面名稱	API 描述
/media/hello	媒體服務可用性測試介面
/_media/play	<u>視頻播放介面</u>
/ media/stop	停止播放介面
/ media/addDevice	動態添加接入設備介面
/ media/updateStrategy	動態更新設備錄影策略介面
/ media/delDevice	動態刪除接入設備介面
/hls/設備 id/通道/碼流/index.m3u8	HLS 視頻播放
/play	Mp4/Flv 播放

6. device.json

系統設備配置文件,包括設備序列號、雲服務器、雲存儲服務器等等

7、配置

D:\OpensslRSA_NEW_MPEG_REC\new-ffmpeg-helper2023\MediaGuard\MediaGuard\conf\config 作廢.json