

double
RTL_Double_1
double
RTL_Double_2
double
RTL_Double_6
Stop_At_Native_Fault
double
RTL_Double_3
double
RTL_Double_4
double
RTL_Double_5
double
RTL_Double_7
double
RTL_Double_8
double
RTL_Double_21
double
RTL_Double_9
Plant_Log
Plant_Mux
int16
Input_Exact_Type_1
int16
Input_Exact_Type_2
int32
Input_Exact_Type_3
uint32
Input_Exact_Type_4
int32
Input_Exact_Type_5
int16
Input_Exact_Type_6
convert
Input_Exact_Type_7
boolean
Input_Exact_Type_8
boolean
Input_Exact_Type_9
convert
Input_Exact_Type_10
convert
Input_Exact_Type_11
int32
Input_Exact_Type_12
int32
Input_Exact_Type_13
int32
Input_Exact_Type_14
int32
Input_Exact_Type_15
int32
Input_Exact_Type_16
uint32
Input_Exact_Type_17
uint32
Input_Exact_Type_18
uint32
Input_Exact_Type_19
uint32
Input_Exact_Type_20
uint32
Input_Exact_Type_21
double
RTL_Double_20
double
RTL_Double_22
double
RTL_Double_23
v5_plant
Physical_Plant_And_Source_Observation
fast_error
measured_error
measured_raw
request_index
measured_raw_now
measured_guard
observation_source_faults
observation_permission
observation_stop
observation_adc_raw
observation_adc_q4
raw_ms1
raw_ms2
raw_ms3
raw_ms4
raw_ms5
age_ms1
age_ms2
age_ms3
age_ms4
age_ms5
ModelSim
Simulator
motor_command
target_position
actual_position
position_error
motion_state
fault
trajectory_done
tracking_settled
completed_transactions
accepted_count
draw_index
reference_velocity
measured_velocity
virtual_input_error
lead_inhibited
raw_edges
edge_budget
physical_average_q15_q8
applied_snapshot_q15
angle_observed
prefix1_q8
prefix2_q8
steady_q8
frame_actual
frame_target
guard_observed
outer_fault_code
Actual_PID_Planner_Actuator
double
RTL_Double_10
double
RTL_Double_11
double
RTL_Double_12
double
RTL_Double_13
double
RTL_Double_14
double
RTL_Double_15
double
RTL_Double_16
double
RTL_Double_17
double
RTL_Double_18
double
RTL_Double_19
double
RTL_Double_24
double
RTL_Double_25
double
RTL_Double_26
double
RTL_Double_27
RTL_Log
RTL_Mux