#### Power-limits estimation example



- In this lesson, we look at Octave code to compute HPPC limits
- Code starts by loading data, configuring parameters

```
load('CellModel.mat');
                                     % ESC cell model
load('CellData.mat');
                                     % time/current/voltage/soc/spkfSOC/bounds
% Cell Configuration
                                               % [degC] ambient temperature
       = 25;
Thorz = 10;
                                               % [s] horizon time
       = 0.5;
                                               % [] initial cell SOC
z
Ns
       = 1;
                                               % [] number of series cells
Νp
       = 1;
                                               % [] number of parallel cells
% Operational Limits
                                               % [] soc limits
zmin = 0.1; 	 zmax = 0.9;
vmin = 2.8;
               vmax = 4.3;
                                               % [V] voltage limits
imin = -200;
              imax = 350;
                                               % [A] current limits
                                              % [W] power limits
pmin = -inf;    pmax = inf;
```

Dr. Gregory L. Plett | University of Colorado Colorado Springs

Battery Pack Balancing and Power Estimation | How to find available battery power using a simplified cell model | 1 of 8

5.3.4: Introducing Octave code to compute power limits using simplified cell model

#### Find $\Delta T$ resistances



- Next, find effective dis/charge resistances over horizon  $\Delta T$
- Use 10C pulses to do so

```
% Effective Resistances
   = getParamESC('QParam',T,model);
iChg = 10*Q*[zeros(5,1); -ones(Thorz,1); zeros(5,1)]; % [A] charge pulse iDis = 10*Q*[zeros(5,1); ones(Thorz,1); zeros(5,1)]; % [A] discharge pulse
[vk,~,~,~,~] = simCell(iChg,T,model,1,z,0,0); % 1 = sample period
dvChg = max(vk) - vk(1);
iChg = min(iChg);
RChg = abs(dvChg/iChg);
fprintf('Rchg = %2.4f (mOhm)\n',1000*RChg);
[vk, \tilde{z}, \tilde{z}, \tilde{z}, \tilde{z}] = simCell(iDis, T, model, 1, z, 0, 0); % 1 = sample period
dvDis = min(vk) - vk(1);
iDis = max(iDis);
RDis = abs(dvDis/iDis);
fprintf('Rdis = %2.4f (m0hm)\n',1000*RDis);
```

Dr. Gregory L. Plett University of Colorado Colorado Springs

Battery Pack Balancing and Power Estimation | How to find available battery power using a simplified cell model | 2 of 8

5.3.4: Introducing Octave code to compute power limits using simplified cell model

# **HPPC** truth power limits



■ We now compute "truth" power limits using exact SOC from carefully calibrated lab tests

```
% HPPC Power Estimation: Truth
OCV
     = OCVfromSOCtemp(soc,T,model);
iDisMaxV = (OCV-vmin)/RDis;
iDisMaxZ = (soc - zmin)*3600*Q/Thorz;
iDisMax = max(0,min([iDisMaxV;iDisMaxZ;imax*ones(size(soc))]));
pDisMax = min(vmin*iDisMax,pmax*ones(size(soc)));
iChgMinV = (OCV-vmax)/RChg;
iChgMinZ = (soc - zmax)*3600*Q/Thorz;
iChgMin = max([iChgMinV;iChgMinZ;imin*ones(size(soc))]);
pChgMin = min(0, max(vmax*iChgMin,pmin*ones(size(soc))));
HPPC.pDisMax = pDisMax;
HPPC.pChgMin = pChgMin;
```

Dr. Gregory L. Plett University of Colorado Colorado Springs

### **HPPC SPKF power limits**



 We now compute more realistic power limits using SOC estimate and bounds produced by SPKF

```
% HPPC Power Estimation: SPKF

OCVDis = OCVfromSOCtemp(spkfSOC-bounds,T,model);
OCVChg = OCVfromSOCtemp(spkfSOC+bounds,T,model);
iDisMaxV = (OCVDis-vmin)/RDis;
iDisMaxZ = (spkfSOC-bounds - zmin)*3600*Q/Thorz;
iDisMax = max(0,min([iDisMaxV;iDisMaxZ;imax*ones(size(soc))]));
pDisMax = min(vmin*iDisMax,pmax*ones(size(soc)));
iChgMinV = (OCVChg-vmax)/RChg;
iChgMinZ = (spkfSOC+bounds - zmax)*3600*Q/Thorz;
iChgMinZ = (spkfSOC+bounds - zmax)*3600*Q/Thorz;
iChgMin = max([iChgMinV;iChgMinZ;imin*ones(size(soc))]);
pChgMin = min(0,max(vmax*iChgMin,pmin*ones(size(soc))));
spkfHPPC.pDisMax = pDisMax;
spkfHPPC.pChgMin = pChgMin;
```

Dr. Gregory L. Plett

niversity of Colorado Colorado Springs

Battery Pack Balancing and Power Estimation | How to find available battery power using a simplified cell model


1 of 8

5.3.4: Introducing Octave code to compute power limits using simplified cell model

### **Example experiment**



- We execute the code to view representative results
- A cell is subjected to a sequence of sixteen UDDS cycles, separated by discharge pulses and five-minute rests
- SOC increases by about 5 % during each UDDS cycle, but is brought down about 10 % during each discharge between cycles
- The entire normal operating range for this cell (10 % to 90 % SOC) is excited during the cell test



Dr. Gregory L. Plett

Iniversity of Colorado Colorado Spring

Battery Pack Balancing and Power Estimation | How to find available battery power using a simplified cell model

E of 9

5.3.4: Introducing Octave code to compute power limits using simplified cell model

#### Parameters for test



- Experiment computes power for single cell,  $N_s = 1$  and  $N_p = 1$
- Cell has nominal capacity of 7.5 Ah, and  $\Delta T = 10 \, \mathrm{s}$  for both charge and discharge
- Operational limits for the power calculations are listed
- Pulse resistances are found to be

$$R_{\mathrm{dis},\Delta T} = 3.539 \,\mathrm{m}\Omega$$
  
 $R_{\mathrm{chg},\Delta T} = 3.517 \,\mathrm{m}\Omega$ 


Parameter	Minimum	Maximum
$v_n(t)$	2.8 V	4.3 V
$i_n(t)$	-200 A	350 A
$z_n(t)$	0.1	0.9
$p_n(t)$	$-\infty$	$\infty$

5.3.4: Introducing Octave code to compute power limits using simplified cell model

## Results from running code



- Dis/charge power limits are plotted below
- SPKF method more conservative because uses bounds



Dr. Gregory L. Plett University of Colorado Colora

Sattery Pack Balancing and Power Estimation | How to find available battery power using a simplified cell model

7 of 8

5.3.4: Introducing Octave code to compute power limits using simplified cell model

#### **Summary**



- You have now learned how to write Octave code to compute HPPC power limits
- Code includes limits on future voltage, future SOC, current magnitude and power magnitude
- Example showed that limits are enforced on current, future SOC, and future voltage for a representative case
- SOC estimate plus bound produced by SPKF agree well with truth calculations, and produce slightly conservative estimates (good!)

Dr. Gregory L. Plett

University of Colorado Colorado Springs

Battery Pack Balancing and Power Estimation | How to find available battery power using a simplified cell model

8 of 8