
BMS requirement 4: Performance management



- So far, we have now looked at requirements 1 through 3 of a BMS
- We now consider requirement 4, performance management
 - □ State-of-charge (SOC) estimation, power-limit computation, balance/equalize cells



Dr. Gregory L. Plett University of Colorado Colorado Spring

Introduction to Battery Management Systems | BMS Design Requirements 2–5 | 1 of 7

1.4.3: Why must a BMS estimate SOC and SOH?

What needs to be estimated, and why?



- Battery applications need to know two battery quantities:
- How much energy is available in the battery pack
- ☐ How much power is available in the immediate future
- Knowing energy is most important for applications such as EV:
 - □ Tells me how far I can drive
- Knowing power is most important for applications such as HEV:
 - □ Tells me whether I can accelerate or accept braking charge
- Both are important for applications such as E-REV/PHEV




Dr. Gregory L. Plett | University of Colorado Colorado Springs

Introduction to Battery Management Systems | BMS Design Requirements 2–5 2 of 7

Why must we estimate energy, power?



- Can't measure available energy or available power
- Instead, must estimate these values
 - □ To estimate energy, we must know (at least) all cell states-of-charge z_k and capacities Q_k
 - □ To estimate power, we must know (at least) all cell states-of-charge z_k and resistances R_k




Dr. Gregory L. Plett University of Colorado Colorado Springs

Introduction to Battery Management Systems | BMS Design Requirements 2–5

Why must we estimate SOC, SOH?



- But, cannot directly measure these parameters either!
- Therefore, must estimate SOC, SOH



 Available inputs include all cell voltages, pack current, and temperatures of cells or modules.

Dr. Gregory L. Plett University of Colorado Colorado Spring

Introduction to Battery Management Systems | BMS Design Requirements 2–5 4 of 7

Quality of estimates



- There are both good and poor methods to produce estimates:
- □ Poor methods are generally simpler to understand, code, and validate, but yield less-accurate results
- Impacts of a poor estimator can be:
 - □ Abrupt corrections when voltage or current limits exceeded, leading to customer perception of poor drivability, or
 - □ Overcharge or overdischarge, which damages cells, or
 - □ Compensating for uncertainty by overdesigning pack
- All of these have costs in dollars, weight and/or volume



Dr. Gregory L. Plett University of Colorado Colorado Spring

1.4.3: Why must a BMS estimate SOC and SOH?

Summary



- Applications need to know battery available energy and power
- Can't measure; must estimate based on z_k , Q_k , R_k
- These also must be estimated using measured voltage, current, and temperature
- Major premise of this specialization: investing in good BMS electronics and algorithms can reduce pack size and result in considerable net savings
 - □ Course 2: How to model cells, needed by algorithms
 - □ Course 3: Advanced methods for SOC estimation
 - □ Course 4: SOH estimation
 - □ Course 5: Balancing and power-limits estimation
- Preview of these next

Credits



Credits for photos in this lesson

- Lemonade on slide 2: CC0 public domain, cropped from https://pixabay.com/en/drinks-juice-fruit-juice-summer-1430739/
- Photo of Rudolph Kalman (pioneer of estimation theory and inventor of the "Kalman filter" we will study in Course 3) on slide 5, By Greuel, Gert-Martin [CC BY-SA 2.0 de (http://creativecommons.org/licenses/by-sa/2.0/de/deed.en)], via Wikimedia Commons, https://commons.wikimedia.org/wiki/File:Rudolf_Kalman.jpg (cropped)

Dr. Gregory L. Plett University of Colorado Colorado Springs

Introduction to Battery Management Systems | BMS Design Requirements 2-5 7 of 7