## Overview of vector random (stochastic) processes



- A stochastic or random process is a family of random vectors indexed by a parameter set ("time" in our case)
- For example, we might refer to a random process  $X_k$  for generic k $\Box$  Value of random process at any specific time k=m is a random variable  $X_m$
- Usually assume stationarity
  - □ The statistics (i.e., pdf) of the RV are time-shift invariant
  - $\Box$  Therefore,  $\mathbb{E}[X_k] = \bar{x}$  for all k and  $\mathbb{E}[X_{k_1}X_{k_2}^T] = R_X(k_1 k_2)$

Dr. Gregory L. Plett | University of Colorado Colorado Spri

Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator

## Properties and important points



1. Autocorrelation:  $R_X(k_1, k_2) = \mathbb{E}[X_{k_1} X_{k_2}^T]$ . If stationary,

$$R_X(\tau) = \mathbb{E}[X_k X_{k+\tau}^T]$$

- □ Provides a measure of correlation between elements of the process having time displacement  $\tau$
- $\ \ \square \ \ R_X(0) = \sigma_X^2 \ \text{for zero-mean} \ X$
- $\ \square\ R_X(0)$  is always the maximum value of  $R_X(\tau)$
- 2. Autocovariance:  $C_X(k_1, k_2) = \mathbb{E}[(X_{k_1} \mathbb{E}[X_{k_1}])(X_{k_2} \mathbb{E}[X_{k_2}])^T]$ . If stationary,  $C_X(\tau) = \mathbb{E}[(X_k - \bar{x})(X_{k+\tau} - \bar{x})^T]$

Dr. Gregory L. Plett University of Colorado Color


Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator

3.1.7: Understanding time-varying uncertain quantities

#### White noise



- White noise: Some processes have a unique autocorrelation:
  - 1. Zero mean
  - 2.  $R_X(\tau) = \mathbb{E}[X_k X_{k+\tau}^T] = S_X \delta(\tau)$  where  $\delta(\tau)$  is the Dirac delta.  $\delta(\tau) = 0 \ \forall \ \tau \neq 0$
  - □ Therefore, the process is uncorrelated in time
  - Clearly an abstraction, but proves to be a very useful one




Correlated noise

#### Shaping filters: Idea



- Will assume noise inputs to dynamic systems are white
  - □ Limiting assumption, but one that can be easily fixed
    - Can use second linear system to "shape" the noise as desired.



 $\Box$  Can drive our linear system with noise that has desired characteristics by introducing shaping filter H(z) that itself is driven by white noise

Dr. Gregory L. Plett

Iniversity of Colorado Colorado Springs

Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator

4 of 7

3.1.7: Understanding time-varying uncertain quantities

#### **Shaping filters: Model**



- Combined system GH(z) looks exactly the same as before, but G(z) is not driven by pure white noise any more
  - Analysis augments original system model
     Shaping filter with white input and desired output statistics has

$$x_{k+1} = Ax_k + B_w w_{1,k}$$
  $x_{s,k+1} = A_s x_{s,k} + B_s w_{2,k}$   
 $y_k = Cx_k$   $w_{1,k} = C_s x_{s,k}$ 

□ Combine into larger-order augmented system driven by white noise:

$$\begin{bmatrix} x_{k+1} \\ x_{s,k+1} \end{bmatrix} = \begin{bmatrix} A & B_w C_s \\ 0 & A_s \end{bmatrix} \begin{bmatrix} x_k \\ x_{s,k} \end{bmatrix} + \begin{bmatrix} 0 \\ B_s \end{bmatrix} w_{2,k}$$
$$y_k = \begin{bmatrix} C & 0 \end{bmatrix} \begin{bmatrix} x_k \\ x_{s,k} \end{bmatrix}$$

Dr. Gregory L. Plett

Iniversity of Colorado Colorado Springs

Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator

5 of

3.1.7: Understanding time-varying uncertain quantities

# **Gaussian processes**



- We will work with Gaussian noises to a large extent
  - □ Uniquely defined by the first- and second central moments of the statistics → Gaussian assumption not essential
  - □ Our filters will always track only the first two moments.

NOTATION: Until now, we have always used capital letters for random variables

- $\blacksquare$  State of system driven by random process is an RV, so we could call it  $X_k$
- More common to retain standard notation  $x_k$  and understand from context that we are discussing an RV

#### Summary



- Random process is a family of RVs indexed by time
- Will assume our random processes are stationary
- Autocorrelation and autocovariance measure self-predictability of a signal at different time offsets
- White noise is zero mean signal, completely uncorrelated with self ("completely random")
  - $\hfill\Box$  An abstraction, but a very useful one
- If noises in a system of interest are not white, can filter white noise to create same general characteristics
- From now on, unless stated otherwise, all noise signals will be white and Gaussian

Dr. Gregory L. Plett | University of Colorado Colorado Springs

Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator | 7 of 7