
Poor, voltage-based method to estimate SOC



- We begin to consider the question, "how should we estimate battery cell state of charge?"
- One method would be to measure cell terminal voltage under load, v(t), and look up on "SOC versus OCV" curve
 - □ SOCest = SOCfromOCVtemp(v,T,model);
 - $\ \square$ Ignores effects of $i(t) \times R_0$ losses, diffusion voltages, and hysteresis on v(t)
 - □ Wide flat areas of OCV curve dilute accuracy of estimate very noisy



Dr. Gregory L. Plett

University of Colorado Colorado Springs

Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator

1 of 7

3.1.4: What are some approaches to estimating battery cell SOC?

Poor, voltage-based method to estimate SOC



- A modification of this method assumes a cell model $v(t) = \text{OCV}(z(t)) i(t)R_0$ and then looks up $v(t) + i(t)R_0$ on "SOC versus OCV" curve
 - □ SOCest = SOCfromOCVtemp(v+i*R0,T,model);
 - Better, but still ignores effects diffusion voltages, hysteresis and so is still noisy
- Filtering helps but adds delay, which must be accounted for
- Hysteresis is another complicating factor
- Even though its estimates are noisy, we'll find an application for this modified method in the next course

application for this modified

Dr. Gregory L. Plet

University of Colorado Colorado Spring

Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator

2 of

3.1.4: What are some approaches to estimating battery cell SOC?

Poor, current-based method to estimate SOC



■ Coulomb counting keeps track of charge in, out of cells via

$$\hat{z}(t) = \hat{z}(0) - \frac{1}{\widehat{Q}} \int_0^t \eta(\tau) i_{\text{meas}}(\tau) d\tau$$


$$i_{\text{meas}}(t) = i_{\text{true}}(t) + i_{\text{noise}}(t) + i_{\text{bias}}(t) + i_{\text{nonlin}}(t) + i_{\text{sd}}(t) + i_{\text{leakage}}(t)$$

- Okay for short periods of operation when initial conditions are known or can be frequently "reset"
- □ Subject to drift due to current sensor's fluctuations, current-sensor bias, incorrect capacity estimate, other losses
- Uncertainty/error bounds grow (without limit) over time until estimate is "reset"

Model-based state estimation



- An alternative to a voltage-only method or a current-only method is somehow to combine the approaches
- Model-based estimators implement algorithms that use sensed measurements to infer internal hidden state of dynamic system



- Mathematical model of system is assumed known (e.g., ESC cell model)
- Same input propagated through true system, model, measured and predicted outputs compared; error used to update model's state estimate
 - □ Output error due to: state, measurement, model errors;
 - Update must be done carefully to account for all of these.

Linear Kalman filter



- Under specific conditions, Kalman filter (KF, special case of sequential probabilistic inference) gives optimal state estimate
- We study linear KF and some of its variants throughout remainder of course
- We start by assuming a general, possibly nonlinear, state-space model

$$x_k = f(x_{k-1}, u_{k-1}, w_{k-1})$$

 $y_k = h(x_k, u_k, v_k),$

where u_k is known (measured) input signal, w_k is a process-noise random input, and v_k is a sensor-noise random input (ESC cell model fits this framework!)

■ Functions $f(\cdot)$ and $h(\cdot)$ may be time-varying, but we generally omit time dependency from notation to avoid clutter

Dr. Gregory L. Plett University of Colorado Colorado Spri


Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator

3.1.4: What are some approaches to estimating battery cell SOC?

Sequential probabilistic inference



- KF is special case of sequential probabilistic inference (SPI):
 - $\ \square$ Estimate present state x_k of dynamic system using all measurements $\mathbb{Y}_k = \{y_0, y_1, \dots, y_k\}$



- The observations allow us to "peek" at what is happening in true system Based on observations and model, we estimate state
- Process- and sensor-noise randomness always cause imperfect estimates
- So, to understand SPI solution, must study vector random processes

Summary



- Direct lookup of terminal voltage in OCV versus SOC table gives very poor estimate of cell SOC
- Modifying lookup to account for ohmic resistance helps, but not enough
- Coulomb counting also has many problems we would like to avoid
- Model-based state estimators combine voltage and current measurements, using a cell model to do so, to yield better state estimates
- Sequential probabilistic inference is the general framework that describes model-based state estimators of interest
- We will study SPI this week, as preparation for developing KF solution

Dr. Gregory L. Plett | University of Colorado Colorado Springs

Battery State-of-Charge (SOC) Estimation | The importance of a good SOC estimator | 7 of 7