

PRESENTATION

Delta WASP 2040 CLAY is a professional instrument for the deposition of dense fluid material as clay mixture, silicones and experimental materials.

It is equipped with a screw system capable of regulating the output flow of the material, allowing a rapid flow interruption and a good retraction control. At the same time it has the function of a deaerator. Any material that is to be used requires a specific research. There are some important factors related to the density, granulometry and the flowability of the material that must be analyzed in order to have an easy extrusion and resistance to collapse.

The Manufacturer declines all liability for injury to persons and damage to components due to an incorrect use of the product.

WASP certifies the use of the LDM extruder with ceramic material, so the use of other kind of mixtures or materials has to be considered as not covered by the technical support and warranty.

WARNINGS

- Carefully read the instruction before the use.
- Be sure that the two tank caps are tight before the pressurization of the tank until the thread is not visible anymore
- Ensure periodically the tank and top thread and check any consume or damage
- Always keep clean the threads, a wrong closure could be dangerous
- Periodically grease the threads
- Don't pressurize the tank if there is some old or dry material inside the 12mm nylon hose
- Check the video tutorial at the address: <https://www.youtube.com/watch?v=1DjVC5MxJr4>
- Keep away from children
- Do not exceed the maximum pressure of 8 bar
- After every use unload the material from the extruder and from the 12mm nylon hose
- Do not point the tank to things or people when it's pressurized and without cap
- Be sure that the 8mm teflon and the 12mm nylon hose are inserted correctly
- Be sure that the extruder cooling fan is functioning
- Be sure that the extruder is empty, clean and without obstruction before the use
- Do not put fingers inside the extruder
- Do not ingest the extruded material
- Be sure that the hose do not present narrowings or bottlenecks
- Check periodically the consumption of the hose in the connection points
- Do not replace parts not supplied by the manufacturer
- The kit can be used only by trained staff

DOWNLOAD THE USER MANUAL ON: www.3dwasp.com