Formato de Instrução

- Instruções Lógicas e Aritméticas
 - op = opcode
 - rx, ry, rz: registradores
 - c: uso do bit de carry



13/03/17

Instruções aritméticas

```
ADD RX, RY, RZ RX<-RY+RZ 100000 | RX | RY | RZ | 0
```

ADDC RX, RY, RZ RX<-RY+RZ+C 100000 | RX | RY | RZ | 1

SUBC RX, RY, RZ RX<-RY-RZ+C 100001 | RX | RY | RZ | 1

MULT RX, RY, RZ RX<-RY*RZ 100010 | RX | RY | RZ | 0

DIVC RX, RY, RZ RX<-RY/RZ+C 100011 | RX | RY | RZ | 1

INC RX RX++ 100100 | RX | 0 | xxx | xxx |

DEC RX RX-- 100100 | RX | 1 | xxx | xxx |

MOD RX, RY, RZ RX<-RY MOD RZ 100101 | RX | RY | RZ | x

13/03/17