## **OPTIONS**

Extension brackets and spacer blocks are used to mount a shade further away from the wall or window to clear thick window moldings, sills or handles.

#### SPACER BLOCKS

Each spacer block projects 1/2". Use a maximum of 3 blocks per installation bracket. The solid side of the blocks should face the wall. Secure with two long screws.




EXTENSION

BRACKET

For Cellular and Angle Top Shades: Make sure the tops of the brackets are in alignment, parallel to the top of the window opening. For Cellular Octagon, Hexagon and Trapezoid Shades: Make sure the tops of the brackets are perfectly horizontal and aligned at the same height.

#### **EXTENSION BRACKETS**

Each extension bracket projects up to 2-1/2". Secure extension bracket to the wall with two long screws. Use the nut and bolts to attach the mounting brackets to the extension bracket as shown.



Make sure the tops of the brackets are in alignment, parallel to the top of the window opening.



Make sure the tops of the brackets are perfectly horizontal and aligned at the same height.

#### HOLD-DOWN BRACKETS

HOLD DOWN BRACKET Hold-down brackets are used to keep the bottom of the shade from swaying when shade is mounted on a door or shade is exposed to the wind.

Lower shade and place the pins on the hold-down brackets into the bottom rail end caps. Mark where to drill the holes. Be sure bracket pins



are aligned and level. Remove bracket from shade. Screw the brackets (one on each side) into the bottom of the window jamb or sill. Next, snap pin ends of bracket into holes in each end of bottom rail.

## BOTTOM RAIL SHADE ADJUSTMENT:

- Lift bottomrail on the side to be adjusted. This will take the weight off the cord.
- Use a screwdriver or dime.
- Tum screw clockwise to lift that side of the shade
- Tum screw counter clockwise to lower that side of the shade
- Half a revolution is 1/4" adjustment (maximum adjustment is 1/2")

## shade I matic

Warranty Policy

C8-SOM-023 Rev 1/16

All Shade-O-Matic products are covered with the Limited Lifetime Warranty. Products shall be free from defects in material and workmanship for so long as the original retail purchaser owns the products, provided that: (1) such products were properly installed in accordance with accompanying instructions in residential dwellings in the window or door for which they were purchased; (2) the products are manually operated custom products which have not been modified or altered.

This warranty does not cover damage to the product resulting from misuse, abuse, alterations, dry cleaning, cleaning with ultrasonic method, discolouration or colour change due to sunlight or passage of time, humidity, exposure to salty air or corrosive materials, warpage due to high humidity or excessive heat. This warranty does not apply to natural features of the products or conditions caused by normal wear and tear upon the product, including normal fading from sunlight.

Dye lots may vary with in commercial tolerances, therefore, colours of fabrics and woods may vary from the samples. Dve lots may not match samples of previous purchases. This applies to all product lines.

In the event of a defect under this warranty, Shade-O-Matic shall at its option repair or replace the product. Our warranty obligation excludes labour costs for measuring and installation out side of one year. Repairs will be made with like or similar parts. It is the responsibility of the Dealer to get the product from the endconsumer back to Shade-O-Matic for any warranty work.

Note: In the event there are multiple blinds or shades in the same room, only the defective blinds or shades will be repaired or replaced. Shade-O-Matic can not guarantee a dye lot match to existing blinds. Different warranty periods and terms apply for commercial applications.

This warranty is exclusive and in lieu of all other obligations, liabilities or warranties written or oral. In no event shall Shade-O-Matic be liable for incidental or consequential damages or for any other direct or indirect damage, loss, cost expense or fee.

Mamanta Osidalinaa

Warranty Guidelines	
Period of Coverage	
Limited Lifetime	
5 Years	
3 Years	
3 Years	
5 Years	
5 Years	
3 Years	
1 Year	
1 Year	
1 Year	
5 Years	


visit www.Shade-O-Matic.com

# **CELLULAR SHADES**

## ANGLE CUTS

CELLULAR SHADES: ANGLED TOP, OCTAGON, HEXAGON, TRAPEZOID

- Installation Instructions
- Parts Identification
- Care Instructions
- LIFETIME LIMITED WARRANTY



## WARNING

To avoid possible strangulation, keep cords out of the reach of children. Use these devices:

- 1. Clamp or clothes pin
- 2. Cleat
- 3. Tie the cord to itself
- 4. Tie-down device

## **CARE INSTRUCTIONS**


**CELLULAR SHADES**: Dust with a feather duster or vacuum frequently with a soft brush attachment. Fabric can be cleaned by gently blotting with a soft damp cloth or sponge.

**CELLULAR SHADES ONLY:** Shade may be immersed in lukewarm water with a mild detergent, for a more thorough cleaning.

**BLACKOUT FABRICS**: Do not immerse in water and avoid creasing during cleaning.

Please read instructions completely before starting! Remember to treat your new shade with care when installing.

## GET ACQUAINTED WITH YOUR NEW CELLULAR SHADE



- Color Coordinated
   Aluminum Headrail
- 2. Reliable Cordlock
- 3. Crisp 3/8" or 3/4" Pleats
- Color Coordinated Multiple Cords
- 5. Plate Adjust
- Single Color
   Coordinated Cord
- Tassel
- 8. Color Coordinated Aluminum Bottomrail
- Color Coordinated End Cap
- 10. Hold Down Bracket
- 11. Installation Brack.ct
- 12. 1/2" Spacer Block
- 13. 3" Extension Bracket
- 14. No Visible Cords or Cord Holes

## How to Install

#### 1. Tools

- Metal measuring tape
   not cloth
- Power drill and bits
- Long flat blade screwdriver
- Phillips head screwdriver
- Scissors

#### 2. INSTALLATION BRACKETS

The brackets provided are used for all types of installations - outside, ceiling and inside. Note: Two screws are supplied for each bracket. These are screws with slotted hex heads, suitable for wood or sheet metal mounting surfaces. FOR PLASTER, DRYWALL, CONCRETE, STONE, BRICK OR TILE installations, we recommend using plugs or anchors.

SPACE EVENLY

**BRACKET SPACING:** Position the first two brackets 2-1/4" from the end of the shade.

If more than two brackets are needed

(see Chart at right), space them evenly between the two end brackets.



INSTALLATION


Note for Cellular and Angle Top Shades: If the rails are the same length, align the bottom brackets directly under the top brackets. If the rail lengths are different, measure the bracket spacing separately for each rail.

**Note for Cellular Octagon, Hexagon and Trapezoid Shades:** Spring-anchored shades require brackets at the bottom of the window opening, as well as at the top. Align the bottom brackets directly under the top brackets.

## INSIDE MOUNT

### STEP 1 - BRACKETS

With mounting brackets level and flush with the window frame, screw through the top of the bracket. All brackets' front edges should be aligned.



For Cellular 3/8" pleat shades, a 1-1/2" window depth is required for a flush mount. For Cellular 3/4" pleat shades, a 2-1/4" window depth is required for a flush mount.

#### STEP 2 - INSTALLING SHADE

Unwind cord and let it hang. Insert the top front of the headrail into the front lip of the brackets. Push on the rail until it snaps into place. Make sure that no material is caught between the headrail and the installation brackets.






## **OUTSIDE MOUNT**

#### STEP 1 - BRACKETS

With the shade open, hold it up to the wall or ceiling in the position you want it to hang.


Make sure the



shade is centered and level. Mark wall 2-1/4" past end of the headrail. Remove shade and place mounting brackets level with pencil marks. Secure with two screws for each bracket For Cellular 3/8" pleat shades, a minimum 5/8" flat surface is needed. For Cellular 3/4" pleat shades, a minimum 1" is needed.

#### STEP 2 - INSTALLING SHADE

Unwind cord and let it hang. Insert the top front of the headrail into the front lip of the brackets. Push on the rail until it snaps into place. Make sure that no material is caught between the headrail and installation brackets.





## **OPERATION**

Keep the cord close to the fabric when operating the shade, no more than 15° from vertical (see diagram at right).

**To raise the shade:** pull the cord toward the center of the shade (approximately 30° from vertical) until lock is released. Continue pulling cord at this angle until shade reaches desired position. To lock, move the cord back to the edge of the shade.

**To lower the shade:** pull the cord toward the center of the shade (approximately 30° from vertical) until lock is released. Let cord slip slowly through fingers until shade reaches desired position. To lock, move the cord back to the edge of the shade. Note: Cellular and Angle Top Shades will raise to the lowest side of the headrail. Cellular Octagon and Hexagon Shades will raise to the widest portion of the shade.

