
UART IP Core Specification

Author: Jacob Gorban gorban@opencores.org

Rev. 0.7 October 14, 2010



Revision History

Rev.	Date	Author	Description	
0.1		Jacob Gorban	First Draft	
0.2	27/5/01	Jacob Gorban	Added reset values and other changes.	
0.3	23/6/01	Jacob Gorban	Divisor latch is 16-bit wide update	
0.4	17/08/01	Jacob Gorban	Modified port names	
0.5	03/12/01	Jacob Gorban	LSR bits 5,6 clear conditions fixed.	
			In IIR, THRE was fixed.	
			Debug registers were added to Registers.	
			Debug interface was added to Operation.	
			WISHBONE interface ports width modified and	
			wb_sel_i signal is added to the list.	
0.6	11/08/02	Jacob Gorban	Added optional BAUD_O output	
0.7	19/10/09	Mark Peryer	Added APB Interface	

Contents

Introduction	 1
IO ports	 2
Clocks	 3
Registers	 4
Operation	 12
Architecture	 14

Introduction

The UART (Universal Asynchronous Receiver/Transmitter) core provides serial communication capabilities, which allow communication with modem or other external devices, like another computer using a serial cable and RS232 protocol. This core is designed to be maximally compatible with the industry standard National Semiconductors' 16550A device.

Features:

- 32-bit APB interface
- FIFO only operation
- Register level and functionality compatibility with NS16550A (but not 16450).

IO ports

2.1 APB interface signals

Port	Width	Direction	Description
PCLK	1	Input	APB Bus clock
PRESETn	1	Input	Asynchronous Reset
PADDR	32	Input	Address Bus
PSEL	1	Input	APB Peripheral Select signal
PWDATA	32	Input	Data input bus
PRDATA	32	Output	Data output bus
PWRITE	1	Input	Write enable
PENABLE	1	Input	Enables transfer cycle
PREADY	1	Output	Peripheral ready to complete transfer

2.2 Other internal signals

Port	Width	Direction	Description
INT_O	1	Output	Interrupt output
BAUD_O	1	Output	Optional baud rate output signal.
			The signal here is the 16 x actual baud rate.
			It is enabled if UART_HAS_BAUDRATE_OUTPUT
			is defined

2.3 External (off-chip) connections

Port	Width	Direction	Description
STX_PAD_O	1	Output	The serial output signal
SRX_PAD_I	1	Input	The serial input signal
RTS_PAD_O	1	Output	Request To Send
DTR_PAD_O	1	Output	Data Terminal Ready
CTS_PAD_I	1	Input	Clear To Send
DSR_PAD_I	1	Input	Data Set Ready
RI_PAD_I	1	Input	Ring Indicator
DCD_PAD_I	1	Input	Data Carrier Detect

Clocks

Clocks table:

Name	Source]	Description		
		Max	Min	Resolution	
clk	APB bus	1258Mhz for	3.6864 for		APB clock
		1200 bps	115200 bps		

Registers

4.1 Registers list

Name	Address	Width	Access	Description
Receiver Buffer	0x0	8	R	Receiver FIFO output
Transmitter Holding	0x0	8	W	Transmit FIFO input
Register (THR)				
Interrupt Enable	0x4	8	RW	Enable/Mask interrupts
				generated by the UART
Interrupt Identification	0x8	8	R	Get interrupt information
FIFO Control	0x8	8	W	Control FIFO options
Line Control Register	0xC	8	RW	Control connection
Modem Control	0x10	8	W	Controls modem
<u>Line Status</u>	0x14	8	R	Status information
Modem Status	0x18	8	R	Modem Status

In addition, there are 2 Clock Divisor registers that together form one 16-bit. The registers can be accessed when the 7th (DLAB) bit of the Line Control Register is set to '1'. At this time the above registers at addresses 0-1 can't be accessed.

Name	Address	Width	Access	Description
Divisor Latch Byte 1 (LSB)	0x0	8	RW	The LSB of the divisor
				latch
Divisor Latch Byte 2	0x4	8	RW	The MSB of the divisor
				latch

4.2 Interrupt Enable Register (IER)

This register allows enabling and disabling interrupt generation by the UART.

Bit #	Access	Description
0	RW	Received Data available interrupt
		'0' – disabled
		'1' – enabled
1	RW	Transmitter Holding Register empty interrupt
		'0' – disabled
		'1' – enabled
2	RW	Receiver Line Status Interrupt
		'0' – disabled
		'1' – enabled
3	RW	Modem Status Interrupt
		'0' – disabled
		'1' – enabled
7-4	RW	Reserved. Should be logic '0'.

Reset Value: 00h

4.3 Interrupt Identification Register (IIR)

The IIR enables the programmer to retrieve what is the current highest priority pending interrupt.

Bit 0 indicates that an interrupt is pending when it's logic '0'. When it's '1' – no interrupt is pending.

The following table displays the list of possible interrupts along with the bits they enable, priority, and their source and reset control.

Bit 3	Bit 2	Bit 1	Priority	Interrupt Type	Interrupt Source	Interrupt Reset Control
0	1	1	1 st	Receiver Line Status	Parity, Overrun or Framing errors or Break Interrupt	Reading the Line Status Register
0	1	0	2 nd	Receiver Data available	FIFO trigger level reached	FIFO drops below trigger level
1	1	0	2 nd	Timeout Indication	There's at least 1 character in the FIFO but no character has been input to the FIFO or read from it for the last 4 Char times.	Reading from the FIFO (Receiver Buffer Register)
0	0	1	3 rd	Transmitter Holding Register empty	Transmitter Holding Register Empty	Writing to the Transmitter Holding Register or reading IIR.
0	0	0	4 th	Modem Status	CTS, DSR, RI or DCD.	Reading the Modem status register.

Bits 4 and 5: Logic '0'.

Bits 6 and 7: Logic '1' for compatibility reason.

Reset Value: C1h

4.4 FIFO Control Register (FCR)

The FCR allows selection of the FIFO trigger level (the number of bytes in FIFO required to enable the Received Data Available interrupt). In addition, the FIFOs can be cleared using this register.

Bit #	Access	Description
0	W	Ignored (Used to enable FIFOs in NS16550D). Since this UART
		only supports FIFO mode, this bit is ignored.
1	W	Writing a '1' to bit 1 clears the Receiver FIFO and resets its logic.
		But it doesn't clear the shift register, i.e. receiving of the current
		character continues.
2	W	Writing a '1' to bit 2 clears the Transmitter FIFO and resets its
		logic. The shift register is not cleared, i.e. transmitting of the
		current character continues.
5-3	W	Ignored
7-6	W	Define the Receiver FIFO Interrupt trigger level
		'00' – 1 byte
		'01' – 4 bytes
		'10' – 8 bytes
		'11' – 14 bytes

Reset Value: 11000000b

4.5 Line Control Register (LCR)

The line control register allows the specification of the format of the asynchronous data communication used. A bit in the register also allows access to the Divisor Latches, which define the baud rate. Reading from the register is allowed to check the current settings of the communication.

Bit #	Access	Description
1-0	RW	Select number of bits in each character
		'00' – 5 bits
		'01' – 6 bits
		'10' – 7 bits
		'11' – 8 bits
2	RW	Specify the number of generated stop bits
		'0' – 1 stop bit
		'1' - 1.5 stop bits when 5-bit character length selected and
		2 bits otherwise
		Note that the receiver always cheeks the first step bit only
3	RW	Note that the receiver always checks the first stop bit only. Parity Enable
3	IX VV	'0' – No parity
		'1' – Parity bit is generated on each outgoing character and
		is checked on each incoming one.
4	RW	Even Parity select
'		'0' – Odd number of '1' is transmitted and checked in each
		word (data and parity combined). In other words, if the data has an
		even number of '1' in it, then the parity bit is '1'.
		'1' – Even number of '1' is transmitted in each word.
5	RW	Stick Parity bit.
		'0' – Stick Parity disabled
		'1' - If bits 3 and 4 are logic '1', the parity bit is transmitted
		and checked as logic '0'. If bit 3 is '1' and bit 4 is '0' then the
		parity bit is transmitted and checked as '1'.
6	RW	Break Control bit
		'1' – the serial out is forced into logic '0' (break state).
		'0' – break is disabled
7	RW	Divisor Latch Access bit.
		'1' – The divisor latches can be accessed
		'0' – The normal registers are accessed

Reset Value: 00000011b

4.6 Modem Control Register (MCR)

The modem control register allows transferring control signals to a modem connected to the UART.

Bit #	Access	Description
0	W	Data Terminal Ready (DTR) signal control
		'0' – DTR is '1'
		'1' – DTR is '0'
1	W	Request To Send (RTS) signal control
		'0' – RTS is '1'
		'1' – RTS is '0'
2	W	Out1. In loopback mode, connected Ring Indicator (RI) signal input
3	W	Out2. In loopback mode, connected to Data Carrier Detect (DCD)
		input.
4	W	Loopback mode
		'0' – normal operation
		'1' – loopback mode. When in loopback mode, the Serial
		Output Signal (STX_PAD_O) is set to logic '1'. The signal of the
		transmitter shift register is internally connected to the input of the
		receiver shift register.
		The following connections are made:
		DTR → DSR
		RTS → CTS
		Out1 → RI
		Out2 → DCD
7-5	W	Ignored

Reset Value: 0

4.7 Line Status Register (LSR)

Bit #	Access	Description
0	R	Data Ready (DR) indicator.
		'0' – No characters in the FIFO
		'1' – At least one character has been received and is in the
		FIFO.
1	R	Overrun Error (OE) indicator
		'1' – If the FIFO is full and another character has been
		received in the receiver shift register. If another character is starting
		to arrive, it will overwrite the data in the shift register but the FIFO
		will remain intact. The bit is cleared upon reading from the register.
		Generates Receiver Line Status interrupt.
		'0' – No overrun state
2	R	Parity Error (PE) indicator
		'1' – The character that is currently at the top of the FIFO
		has been received with parity error. The bit is cleared upon reading
		from the register. Generates Receiver Line Status interrupt.
2	D	'0' – No parity error in the current character
3	R	Framing Error (FE) indicator
		'1' – The received character at the top of the FIFO did not
		have a valid stop bit. Of course, generally, it might be that all the
		following data is corrupt. The bit is cleared upon reading from the
		register. Generates Receiver Line Status interrupt.
4	R	'0' – No framing error in the current character Break Interrupt (BI) indicator
4	K	'1' –A break condition has been reached in the current
		character. The break occurs when the line is held in logic 0 for a
		time of one character (start bit + data + parity + stop bit). In that
		case, one zero character enters the FIFO and the UART waits for a
		valid start bit to receive next character. The bit is cleared upon
		reading from the register. Generates Receiver Line Status interrupt.
		'0' – No break condition in the current character
5	R	Transmit FIFO is empty.
		'1' – The transmitter FIFO is empty. Generates Transmitter
		Holding Register Empty interrupt. The bit is cleared when data is
		being been written to the transmitter FIFO.
		'0' – Otherwise
6	R	Transmitter Empty indicator.
		'1' – Both the transmitter FIFO and transmitter shift register
		are empty. The bit is cleared when data is being been written to the
		transmitter FIFO.
7	D	'0' – Otherwise
7	R	'1' – At least one parity error, framing error or break
		indications have been received and are inside the FIFO. The bit is

Bit #	Access	Description
		cleared upon reading from the register. '0' – Otherwise.

4.8 Modem Status Register (MSR)

The register displays the current state of the modem control lines. Also, four bits also provide an indication in the state of one of the modem status lines. These bits are set to '1' when a change in corresponding line has been detected and they are reset when the register is being read.

Bit #	Access	Description
0	R	Delta Clear To Send (DCTS) indicator
		'1' – The CTS line has changed its state.
1	R	Delta Data Set Ready (DDSR) indicator
		'1' – The DSR line has changed its state.
2	R	Trailing Edge of Ring Indicator (TERI) detector. The RI line has
		changed its state from low to high state.
3	R	Delta Data Carrier Detect (DDCD) indicator
		'1' – The DCD line has changed its state.
4	R	Complement of the CTS input or equals to RTS in loopback mode.
5	R	Complement of the DSR input or equals to DTR in loopback mode.
6	R	Complement of the RI input or equals to Out1 in loopback mode.
7	R	Complement of the DCD input or equals to Out2 in loopback mode.

4.9 Divisor Latches

The divisor latches can be accessed by setting the 7th bit of LCR to '1'. You should restore this bit to '0' after setting the divisor latches in order to restore access to the other registers that occupy the same addresses. The 2 bytes form one 16-bit register, which is internally accessed as a single number. You should therefore set all 2 bytes of the register to ensure normal operation. The register is set to the default value of **0 on reset**, which disables all serial I/O operations in order to ensure explicit setup of the register in the software. The value set should be equal to (system clock speed) / (16 x desired baud rate). The internal counter starts to work when the LSB of DL is written, so when setting the divisor, write the MSB first and the LSB last.

Operation

This UART core is very similar in operation to the standard 16550 UART chip with the main exception being that only the FIFO mode is supported. The scratch register is removed, as it serves no purpose.

This core can operate in 8-bit data bus mode or in 32-bit bus mode, which is now the default mode.

The 32-bit mode is fully WISHBONE compatible and it uses the WISHBONE [SEL_I] signal to properly receive and return 8-bit data on 32-bit data bus. The 8-bit version might have problems in various WISHBONE implementations because a 32-bit master reading from 8-bit bus can expect data on different bytes of the 4-byte word, depending on the register address.

Also, in 32-bit data bus mode, the [ADR_I] is 5 and not 3 bits wide.

In addition, in the 32-bit data bus mode a debug interface is present in the system. This interface has 2 32-bit registers that can be read to provide non-intrusive look into the core's registers and other internal values of importance.

The selection between 32- and 8-bits data bus modes is performed by defining DATA_BUS_WIDTH_8 in uart_defines.v, uart_top.v or on the compiler/synthesizer tool command line.

5.1 Initialization

Upon reset the core performs the following tasks:

- The receiver and transmitter FIFOs are cleared.
- The receiver and transmitter shift registers are cleared
- The Divisor Latch register is set to 0.
- The Line Control Register is set to communication of 8 bits of data, no parity, 1 stop bit.
- All interrupts are disabled in the Interrupt Enable Register.

For proper operation, perform the following:

• Set the Line Control Register to the desired line control parameters. Set bit 7 to '1' to allow access to the Divisor Latches.


- Set the Divisor Latches, MSB first, LSB next.
- Set bit 7 of LCR to '0' to disable access to Divisor Latches. At this time the transmission engine starts working and data can be sent and received.
- Set the FIFO trigger level. Generally, higher trigger level values produce less interrupt to the system, so setting it to 14 bytes is recommended if the system responds fast enough.
- Enable desired interrupts by setting appropriate bits in the Interrupt Enable register.

Remember that (Input Clock Speed)/(Divisor Latch value) = 16 x the communication baud rate. Since the protocol is asynchronous and the sampling of the bits is performed in the perceived middle of the bit time, it is highly immune to small differences in the clocks of the sending and receiving sides, yet no such assumption should be made when calculating the Divisor Latch values.


Architecture

The core implements a 32 bit APB SoC bus interface for communication with the system. The registers are 8 bit, but return 0's for the unused top 24 bits. The core requires one interrupt. It requires 2 pads in the chip (serial in and serial out) and, optionally, another six modem control signals, which can otherwise be implemented using general purpose I/Os on the chip.

The APB bus cycles follow these timing diagrams:



APB Read Cycle Timing – With one wait state



APB Write cycle timing – with one wait state

The block diagram of the core is on the following page.




Figure 1 - Block Diagram of the UART core