## 3GPP TS 38.420 V15.2.0 (2018-12)

Technical Specification

3rd Generation Partnership Project; Technical Specification Group Radio Access Network; NG-RAN; Xn general aspects and principles (Release 15)





#### 3GPP

#### Postal address

3GPP support office address

650 Route des Lucioles - Sophia Antipolis Valbonne - FRANCE Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Internet

http://www.3gpp.org

#### **Copyright Notification**

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© 2018, 3GPP Organizational Partners (ARIB, ATIS, CCSA, ETSI, TSDSI, TTA, TTC). All rights reserved.

UMTS<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its members 3GPP<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners LTE<sup>TM</sup> is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners GSM® and the GSM logo are registered and owned by the GSM Association

## Contents

Forew	ord	5
1	Scope	6
2	References	
3	Definitions and abbreviations	6
3.1	Definitions	
3.2	Abbreviations	
4	General aspects	
4.1	Introduction	
4.2	Xn interface general principles	
4.3	Xn interface specification objectives	
4.4	Xn interface capabilities	/
5	Functions of the Xn interface	7
5.1	General	
5.2	Functions of Xn-C.	
5.2.1	Xn-C interface management and error handling functions	8
5.2.1.1	General	8
5.2.1.2	1 · · · · · · · · · · · · · · · · · · ·	
5.2.1.3		8
5.2.1.4		
5.2.1.5		
5.2.1.6		
5.2.2	UE mobility management functions	
5.2.2.1	r r	
5.2.2.2		
5.2.2.3		
5.2.2.4	0 0	
5.2.2.5	$\epsilon$	
5.2.3	Dual connectivity function	
5.2.4 5.2.5	Energy saving function	
5.2.6	Secondary RAT Data Volume Report function	
5.3	Functions of Xn-U	
5.3.1	Data transfer function	
5.3.2	Flow control function.	
5.3.3	Assistance information function	
5.3.4	Fast retransmission function	
	Xn interface procedures	
6.1	General	
6.2 6.2.1	Control plane protocol procedures	
6.2.1	Mobility management procedures	
6.2.3	Global procedures	
6.2.4	Interface Management procedures	
6.2.5	Energy saving procedures	
6.2.x	Resource coordination procedures	
6.3	User plane protocol procedures	
	Xn interface protocol structure	
7.1	Xn Control Plane	
7.2	Xn User Plane	.11
8	Other Xn interface specifications	.13
8.1	NG-RAN Xn interface: Xn layer 1 (TS 38.421)	
8.2	NG-RAN Xn interface: Xn signalling transport (TS 38.422)	

Annex	A (informative):	Change history	15
8.7	Summary of NG-RA	N Xn interface Technical Specifications	13
8.6	NG-RAN Xn interfa	ce: PDU Session User Plane Protocol (TS 38.415)	13
8.5	NG-RAN Xn interfa	ce: NR user plane protocol (TS 38.425)	13
8.4	NG-RAN Xn interfa	ce: Xn data transport (TS 38.424)	13
8.3	NG-RAN Xn interfa	ce: Xn application protocol (XnAP) (TS 38.423)	13

## Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

#### where:

- x the first digit:
  - 1 presented to TSG for information;
  - 2 presented to TSG for approval;
  - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

## 1 Scope

The present document is an introduction to the TSG RAN TS 38.42x series of Technical Specifications that define the Xn interface. It is an interface for the interconnection of two NG-RAN nodes within the NG-RAN architecture (TS 38.401 [2]).

## 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

```
[1]
                3GPP TR 21.905: "Vocabulary for 3GPP Specifications".
[2]
                3GPP TS 38.401: "NG-RAN; Architecture description".
[3]
                3GPP TS 38.421: "NG-RAN; Xn layer 1".
[4]
                3GPP TS 38.422: "NG-RAN; Xn signalling transport".
                3GPP TS 38.423: "NG-RAN; Xn Application Protocol (XnAP)".
[5]
[6]
                3GPP TS 38.424: "NG-RAN; Xn data transport".
[7]
                3GPP TS 38.425: "NG-RAN; NR user plane protocol".
                3GPP TS 38.300: "NR; Overall Description; Stage 2".
[8]
[9]
                3GPP TS 37.340: "NR; Multi-connectivity; Overall description; Stage-2".
[10]
                3GPP TS 38.415: "PDU Session User Plane protocol".
                3GPP TS 29.281: "General Packet Radio System (GPRS) Tunnelling Protocol User Plane
[11]
                (GTPv1-U)".
```

## 3 Definitions and abbreviations

#### 3.1 Definitions

For the purposes of the present document, the terms and definitions given in 3GPP TR 21.905 [1] and the following apply. A term defined in the present document takes precedence over the definition of the same term, if any, in 3GPP TR 21.905 [1].

corresponding node: as defined in TS 38.425 [7].

NG-RAN node: as defined in TS 38.300 [8]. secondary node: as defined in TS 37.340 [9].

#### 3.2 Abbreviations

For the purposes of the present document, the abbreviations given in 3GPP TR 21.905 [1] and the following apply. An abbreviation defined in the present document takes precedence over the definition of the same abbreviation, if any, in 3GPP TR 21.905 [1].

SCTP Stream Control Transmission Protocol

Xn-C Xn Control plane Xn-U Xn User plane

## 4 General aspects

#### 4.1 Introduction

The interface allowing to interconnect NG-RAN nodes with each other is referred to as the Xn interface.

## 4.2 Xn interface general principles

The general principles for the specification of the Xn interface are as follows:

- the Xn interface is open;
- the Xn interface supports the exchange of signalling information between two NG-RAN nodes, and the forwarding of PDUs to the respective tunnel endpoints;
- from a logical standpoint, the Xn is a point-to-point interface between two NG-RAN nodes. A point-to-point logical interface should be feasible even in the absence of a physical direct connection between the two NG-RAN nodes.

## 4.3 Xn interface specification objectives

The Xn interface specifications facilitate the following:

- inter-connection of NG-RAN nodes supplied by different manufacturers;
- support of continuation between NG-RAN nodes of the NG-RAN services offered via the NG interface;
- separation of Xn interface Radio Network functionality and Transport Network functionality to facilitate introduction of future technology.

## 4.4 Xn interface capabilities

The Xn interface supports:

- procedures to support intra-NG-RAN mobility;
- procedures to support dual connectivity between NG-RAN nodes.

## 5 Functions of the Xn interface

### 5.1 General

The following clauses describe the functions supported in Xn interface.

#### 5.2 Functions of Xn-C

#### 5.2.1 Xn-C interface management and error handling functions

#### 5.2.1.1 General

These functions allow for managing of signalling associations between NG-RAN nodes, surveying the Xn interface and recovering from errors.

#### 5.2.1.2 Xn Setup function

This function allows for the initial setup of an Xn interface between two NG-RAN nodes, including exchange of application level data.

#### 5.2.1.3 Error Indication function

This function allows the reporting of general error situations on application level.

#### 5.2.1.4 Xn reset function

This function allows an NG-RAN node to inform a second NG-RAN node that it has recovered from an abnormal failure and that either all or some of the contexts (except the application level data) related to the first node and stored in the second shall be deleted, and the associated resources released.

#### 5.2.1.5 Xn configuration data update function

This function allows two NG-RAN nodes to update application level data at any time.

#### 5.2.1.6 Xn removal function

This function allows two NG-RAN nodes to remove the respective Xn interface.

## 5.2.2 UE mobility management functions

#### 5.2.2.1 Handover preparation function

This function allows the exchange of information between source and target NG-RAN nodes in order to initiate the handover of a certain UE to the target.

#### 5.2.2.2 Handover cancellation function

This function allows informing an already prepared target NG-RAN node that a prepared handover will not take place. It allows releasing the resources allocated during a preparation.

#### 5.2.2.3 Retrieve UE Context function

The Retrieve UE context function is used for a NG-RAN node to retrieve UE context from another one.

#### 5.2.2.4 RAN Paging function

The RAN paging function allows a NG-RAN node to initiate the paging for a UE in the inactive state.

#### 5.2.2.5 Data Forwarding control function

The data forwarding control function allows establishing and releasing transport bearers between source and target NG-RAN nodes for data forwarding.

#### 5.2.3 Dual connectivity function

The dual connectivity function enables usage of additional resources in a secondary node in the NG-RAN.

#### 5.2.4 Energy saving function

This function enables decreasing energy consumption by indication of cell activation/deactivation over the Xn interface.

#### 5.2.5 Resource coordination function

This function enables coordination of cell resource usage between two NG-RAN nodes.

#### 5.2.6 Secondary RAT Data Volume Report function

This function enables the NG-RAN node to report Secondary RAT usage data information in case of MR-DC with 5GC, either with a dedicated procedure or by including Secondary RAT usage data information in other messages

#### 5.3 Functions of Xn-U

#### 5.3.1 Data transfer function

The data transfer function allows the transfer of data between NG-RAN nodes to support dual connectivity or mobility operation.

#### 5.3.2 Flow control function

The flow control function enables a NG-RAN node receiving user plane data from a second NG-RAN node to provide feedback information associated with the data flow.

#### 5.3.3 Assistance information function

The assistance information function enables a NG-RAN node receiving user plane data from a second NG-RAN node to provide assistance information to the second node (e.g. related to radio conditions).

#### 5.3.4 Fast retransmission function

The fast retransmission function provides coordination between PDCP-hosting node and corresponding node in case of outage in one of the nodes, to enables the node in good RF conditions to handle data previously forwarded to the node in outage.

## 6 Xn interface procedures

#### 6.1 General

The Xn interface supports procedures over the control plane (Xn-C) and user plane (Xn-U).

## 6.2 Control plane protocol procedures

## 6.2.1 Mobility management procedures

The mobility management procedures are used to manage the UE mobility in Connected or RRC\_Inactive modes:

- Handover Preparation
- Handover Cancel
- SN Status Transfer
- Retrieve UE Context
- RAN Paging
- Xn-U Address Indication
- UE Context Release

#### 6.2.2 Dual Connectivity procedures

The dual connectivity procedures are used to add, modify and releases resources for the operation of Dual Connectivity:

- S-NG-RAN-node Addition Preparation
- S-NG-RAN-node Reconfiguration Completion
- M-NG-RAN-node initiated S-NG-RAN-node Modification Preparation
- S-NG-RAN-node initiated S-NG-RAN-node Modification
- M-NG-RAN-node initiated S-NG-RAN-node Release
- S-NG-RAN-node initiated S-NG-RAN-node Release
- S-NG-RAN-node Counter Check
- RRC Transfer
- Notification Control Indication
- Activity Notification
- Secondary RAT Data Usage Report

#### 6.2.3 Global procedures

The global procedures are used to exchange configuration level data between two NG-RAN nodes, or to remove Xn connectivity between two NG-RAN nodes in a controlled manner:

- Xn Setup
- NG-RAN-node Configuration Update
- Xn Removal

## 6.2.4 Interface Management procedures

The interface management procedures are used to align resources between two NG-RAN nodes in the event of failures, and to report detected protocol errors:

- Reset
- Error Indication

## 6.2.5 Energy saving procedures

Cell Activation procedure: enables an NG-RAN node to request the activation of a previously deactivated cell
hosted in another NG-RAN node.

#### 6.2.x Resource coordination procedures

- E-UTRA - NR Cell Resource Coordination procedure: enables an ng-eNB and a gNB to interact for resource coordination purposes.

## 6.3 User plane protocol procedures

The user plane protocol procedures are used to exchange user plane information between Xn-U protocol peers:

- Transfer of Downlink User Data procedure: enables the node hosting the NR PDCP entity to provide user plane information to the corresponding node.
- Downlink Data Delivery Status procedure: enables the corresponding node to provide feedback to the node hosting the NR PDCP entity.
- Transfer of Assistance Information: enables the corresponding node to provide assistance information to the node hosting the NR PDCP entity.
- Transfer of PDU Session Information procedure: enables an NG-RAN node to provide user plane information associated with the forwarding of data towards a peer NG-RAN node, when using PDU session tunnels.

## 7 Xn interface protocol structure

#### 7.1 Xn Control Plane

The control plane protocol stack of the Xn interface is shown on Figure 7.1-1. The transport network layer is built on IP transport. For the reliable transport of signalling messages, SCTP is added on top of IP. The application layer signalling protocol is referred to as XnAP (Xn Application Protocol).




Figure 7.1-1: Xn Interface Control Plane

#### 7.2 Xn User Plane

The Xn user plane (Xn-U) interface is defined between two NG-RAN nodes. The Xn-U interface provides non-guaranteed delivery of user plane PDUs between two NG-RAN nodes.

The protocol stack for Xn-U is shown in Figure 7.2-1.

Note 4:

optionally used in Dual Connectivity




Figure 7.2-1: Xn-U protocol structure

The user plane packets conveyed by GTP-U may be PDCP PDUs (e.g. in case of dual connectivity), PDCP SDUs (e.g. in case of DRB level data forwarding), or SDAP SDUs (e.g. in PDU Session level data forwarding).

User plane protocol messages (as defined in TS 38.425 [7] and TS 38.415 [10]) are carried by container fields in the GTP-U extension header as specified in TS 29.281 [11]. A single GTP-U packet may carry a user plane packet and/or a user plane protocol message. The mapping between container fields and Xn user plane protocol procedures and functions is described in Table 7.2-1.

Table 7.2-1: Mapping between container fields and Xn user plane procedures / functions

Xn-U Function	Container Type	Xn UP Protocol Procedure					
	NR RAN Container, as per TS 29.281 [11] (Note 1)	Transfer of Downlink User Data, TS 38.425 [7]					
Data transfer	PDU Session Container, as per TS 29.281 [11] (Note 2)	Transfer of DL PDU Session Information, TS 38.415 [10] Transfer of UL PDU Session Information, TS 38.415 [10]					
	No container (Note 3)	NA					
Flow control	NR RAN Container as per TS 29.281 [11] (Note 4)	Downlink Data Delivery Status, TS 38.425 [7] Transfer of Downlink User Data, TS 38.425 [7]					
Fast retransmission	NR RAN Container as per TS 29.281 [11] (Note 4)	Downlink Data Delivery Status, TS 38.425 [7] Transfer of Downlink User Data, TS 38.425 [7]					
Assistance information	NR RAN Container as per TS 29.281 [11] (Note 4)	Transfer of Assistance Information, TS 38.425 [7]					
Note 1: optionally used in Dual Connectivity DL data transfer.  Note 2: in case of PDU Session level forwarding only.  Note 3: all other cases of data transfer when no other Xn-U functionality is required							

## 8 Other Xn interface specifications

## 8.1 NG-RAN Xn interface: Xn layer 1 (TS 38.421)

TS 38.421 [3] specifies the physical layer technologies that may be used to support the Xn interface.

## 8.2 NG-RAN Xn interface: Xn signalling transport (TS 38.422)

TS 38.422 [4] specifies how the XnAP signalling messages are transported over Xn.

## 8.3 NG-RAN Xn interface: Xn application protocol (XnAP) (TS 38.423)

TS 38.423 [5] specifies the radio network layer signalling procedures of the control plane between NG-RAN nodes.

## 8.4 NG-RAN Xn interface: Xn data transport (TS 38.424)

TS 38.424 [6] specifies the standards for user data transport protocols over the NG-RAN Xn interface.

## 8.5 NG-RAN Xn interface: NR user plane protocol (TS 38.425)

TS 38.425 [7] specifies the user plane protocol procedures for dual connectivity over the NG-RAN Xn interface.

## 8.6 NG-RAN Xn interface: PDU Session User Plane Protocol (TS 38.415)

TS 38.415 [10] specifies the user plane protocol procedures for data forwarding using PDU Session tunnels over the NG-RAN Xn interface.

## 8.7 Summary of NG-RAN Xn interface Technical Specifications

The relationship between the technical specifications that define the NG-RAN Xn interface is shown in Figure 8.7-1.




Figure 8.7-1: Xn Interface Technical Specifications

# Annex A (informative): Change history

Change history									
Date	Meeting	TDoc	CR	Rev	Cat	Subject/Comment	New version		
2017-04	R3#95b	R3-171313				TS skeleton	0.0.1		
2017-05	R3#96	R3-171807				Change of structure of clause 5	0.0.2		
2017-05	R3#96	R3-171967				Further skeleton change following agreements at R3#96 Initial text for clauses 4, 7 and 8 (R3-171966) Functions from R3-171927 Add change history	0.1.0		
2017-07	R3 NR AH	R3-172636				TP from R3-172596	0.2.0		
2017-09	R3#97	R3-173453				TPs from R3-173320 and R3-173321	0.3.0		
2017-10	R3#97bis	R3-174241				TP from R3-173636	0.4.0		
2017-12	R3#98	R3-175057				TPs from R3-174451 and R3-174764	0.5.0		
2018-02	R3 NR AH 1801	R3-180653				TP from R3-180543	0.6.0		
2018-03	R3#99	R3-181590				TP from R3-181388	0.7.0		
2018-04	R3#99bis	R3-182526				TP from R3-181866	0.8.0		
2018-06	R3#100	R3-183595				TPs from R3-183098, R3-182719 and R3-183375	0.9.0		
2018-06	RP#80	RP-180687				Presentation to RAN for one step approval	1.0.0		
2018-06	RAN#80	-	-	-	-	Specification approved at TSG-RAN and placed under change control	15.0.0		
2018-09	RAN#81	RP-181922	0001	2	F	NR Corrections (38.420 Baseline CR covering RAN3-101 agreements)	15.1.0		
2018-12	RAN#82	RP-182446	0004	1	F	Rapporteur's CR for TS 38.420	15.2.0		
2018-12	RAN#82	RP-182447	0006	-	В	Introduction of Data Volume Reporting for MR-DC	15.2.0		
2018-12	RAN#82	RP-182447	0007	-	F	Rename the Data Forwarding Address Indication procedure	15.2.0		