

# International Currency Technologies Banknote Communication Protocol (ICT-BC)

**Communication Specification** 

Version 1.0

Sep, 2016

# **International Currency Technologies Corp.**

ICT Building, No. 28, Lane. 15, Sec. 6, Minquan E. Rd., Neihu Dist., Taipei City 114, Taiwan, R.O.C <a href="https://www.ictgroup.com.tw">www.ictgroup.com.tw</a>



( Pastedown Endpaper )



# ICT Banknote Communication Protocol

# **Table of Contents**

Rev	vision H	istory	5
1.	Chapt	er 1 - General Information	6
2.	Chapt	er 2 - Communication Format	7
	2.1.	Frame Format	7
	2.2.	Message Structure	7
	2.3.	Example Of Message Sequence	8
	2.4.	ACK Message	9
	2.5.	ICT-BC Peripheral Addresses	9
3.	Chapt	er 3 - Timing Specification	10
	3.1.	Timing Diagram	10
4.	Chapt	er 4 - Command	11
	4.1.	Command List	11
	4.2.	Command Explanation	13
	4.2.1.	Command (0) - Reply Command	13
	4.2.2.	Command (1) – ACK Message	13
	4.2.3.	Command (2) – NAK Message	13
	4.2.4.	Command (10) – Reset	14
	4.2.5.	Command (11) - Request Manufacturer Code	14
	4.2.6.	Command (12) – Request Serial Number	14
	4.2.7.	Command (13) – Request Product Code	14
	4.2.8.	Command (14) – Request Country Code	15
	4.2.9.	Command (15) – Request Firmware Information	15
	4.2.10	. Command (16) – Request Modification Date	16
	4.2.11	. Command (17) – Set Escrow Parameter	16
	4.2.12	. Command (18) – Get Escrow Parameter	17
	4.2.13	. Command (19) – Get Decimal Places	17
	4.2.14	. Command (20) – Get Bill Type Credit	17
	4.2.15	. Command (21) – Set Bill Type Enable Parameter	18
	4.2.16	Command (22) – Get Bill Type Enable Parameter	18
	4.2.17	. Command (23) – Set Recycling Bill Type	18
	4.2.18	. Command (24) – Get Recycling Bill Type	19
	4.2.19	. Command (25) – Poll Status	19
	4.2.20	. Command (26) – Decision of Escrow Action	20
	4.2.21	Command (27) – Get the number of recycling bill	20
	4.2.22	. Command (28) – Dispense the number of bills	20
IC'	TBR v	ersion 1.0 Sep, 2016	Page 3 of 35

**International Currency Technologies Corp.** 

ICT Banknote Communication Protocol	
4.2.23. Command (29) – Dispense Monitor Status	21
<b>4.2.24.</b> Command (30) – Transfer the number of bills	22
<b>4.2.25.</b> Command (31) – Transfer All of bills	22
4.2.26. Command (32) – Transfer Monitor Status	23
4.2.27. Command (33) – Set Recycling Module Capacity	23
4.2.28. Command (34) – Get Recycling Module Capacity	24
4.2.29. Command (35) – Set the number of recycling bill	24
Appendix 1 – ICT-BC Record Codes	25
Appendix 2 – Example Sequence Codes	26
I. Initial procedure	26
II. Escrow ON procedure	27
III. Escrow OFF procedure	27
IV. Enable bill procedure	27
V. Disable bill procedure	28
VI. Set recycling bill type procedure	28
VII. Set recycling capacity procedure	28
VIII. Accept Bill( Escrow ON ) procedure	29
IX. Reject Bill( Escrow ON ) procedure	30
X. Recycling Bill( Escrow ON) procedure	31
XI. Dispense bill( Successful ) procedure	32
XII. Dispense bill(Failed) procedure	33
XIII. Transfer bill( Successful ) procedure	34

Title		ICT Banknote Communication Protocol		
Published		ICT, Department of Software Development		
Version	Date	Author	Comments	
1.0	01-09-16	Phineas Hu	- Draft specification	



# 1. Chapter 1 - General Information

This specification describes the operation of ICT-BC Interface Protocol. It is regarding to the data for the interface between Controller and ICT product.

# 1.1. What is ICT-BC

**ICT-BC** is the International Currency Technologies Corp. serial communication protocol for self-checkout. The interface is a Master-Slave model.



# 2. Chapter 2 - Communication Format

## 2.1. Frame Format

Transmission Method	Full Duplex Transmission			
Transmission Speed	9600 Baud Rate			
Synchronizing Method	Asynchronous Mode			
Connection Control Method	Master/Slave Method			
	Start bit	1		
Data Format	Data bit	8		
Data Format	Parity bit	Even		
	Stop bit	1		

# 2.2. Message Structure

DA	LNG	SA	RC	CMD	DATA	FCC
<u>DA</u>	1 by	yte		Destination A	ddress	
<u>LNG</u>	1 by	yte		Data Length ( what kind of c	The length of data bytes command)	lepends on
<u>SA</u>	1 by	yte		Source Addre	ss	
<u>RC</u>	1 by	yte		Reserve Code	( <u>00</u> H)	
<b>CMD</b>	1 by	yte		Command		
<b>DATA</b>	0 to	249 by	tes	Required by c	ommand	
<b>FCC</b>	1 by	yte		Exclusive or C	Checksum	
				FCC = DA ^ 1	LNG ^ SA ^ RC ^ CMD ^	DATA

**ICTBR version 1.0** 

Sep, 2016

**Page 7 of 35** 



# 2.3. Example Of Message Sequence

Host send command of request manufacturer code to control board ---

<u>**DA**</u> : <u>03</u>H (Bill Recycler Address)

**LNG** : <u>00</u>H ( No data byte )

<u>SA</u> : <u>01</u>H (Controller Address)

**RC** : <u>00</u>H ( Reserve Code )

<u>CMD</u> : <u>0B</u>H ( Request Manufacturer Code)

FCC : <u>09</u>H (Checksum)

Host receives response of command from control board ---

<u>**DA**</u> : <u>01</u>H (Controller Address)

<u>**LNG**</u> : <u>03</u>H ( No data byte )

<u>SA</u> : <u>03</u>H (Bill Recycler Address)

**RC** : <u>00</u>H ( Reserve Code )

<u>CMD</u> : <u>00</u>H (Response Message)

**DATA** : 49H 43H 54H (Response data of "ICT")

FCC : <u>5FH</u> (Checksum)



# 2.4. ACK Message

DA	LNG	SA	CMD	RC	FCC
----	-----	----	-----	----	-----

<u>**DA**</u> : <u>01</u>H (Controller Address)

 $\underline{LNG}$  :  $\underline{00}$ H (No data byte)

<u>SA</u> : <u>03</u>H (Bill Recycler Address)

**RC** : <u>00</u>H ( Reserve Code )

<u>CMD</u> : <u>01</u>H ( ACK Message)

**FCC** : <u>02</u>H ( Checksum )


## 2.5. ICT-BC Peripheral Addresses

Peripheral Category	Default Address
Controller	1 ( <u>01</u> H )
Bill Validator	2 ( <u>02</u> H )
Bill Recycler	3 ( <u>03</u> H )
Reserved for future peripherals	4 ~ 200 ( <u>04</u> H ~ <u>C8</u> H )
Reserved for other purposes	201 ~ 255 ( <u>C9</u> H ~ <u>FF</u> H )

# 3. Chapter 3 - Timing Specification

The following are recommendations for the timing requirements of ICT-BC.

#### 3.1. Timing Diagram



#### **Definition:**

T<sub>P</sub> - Polling Time Interval

T<sub>R</sub> - Response Time (maximum)

T<sub>I</sub> - Inter-byte Time (maximum)

#### The limit of timing:

 $T_{P(min)} = 200 \text{ ms}$ 

 $T_R = 50 \text{ ms}$ 

 $T_I = 3 \text{ ms}$ 

#### **Note**:

• If peripheral receives no support command or mistake checksum .The peripheral doesn't send the response to controller and wait for next command.

**ICTBR version 1.0** 

Sep, 2016

Page 10 of 35



# 4. Chapter 4 - Command

# 4.1. Command List

Command Name	Command Code ( hex )
Reply Command	0 ( <u>00</u> H )
ACK Message	1 ( <u>01</u> H)
NAK Message	2 ( <u>02</u> H )
Reset	10 ( <u>0A</u> H )
Request Manufacturer Code	11 ( <u>0B</u> H)
Request Serial Number	12 ( <u>0C</u> H )
Request Product Code	13 ( <u>OD</u> H )
Request Country Code	14 ( <u>0E</u> H )
Request Firmware Information	15 ( <u>0F</u> H )
Request Modification Date	16 ( <u>10</u> H )
Set Escrow Parameter	17 ( <u>11</u> H)
Get Escrow Parameter	18 ( <u>12</u> H )
Get Decimal places	19 ( <u>13</u> H )
Get Bill Type Credit	20 ( <u>14</u> H )
Set Bill Type Enable Parameter	21 ( <u>15</u> H )
Get Bill Type Enable Parameter	22 ( <u>16</u> H )
*Set Recycling Bill Type	23 ( <u>17</u> H)
*Get Recycling Bill Type	24 ( <u>18</u> H )
Poll Status	25 ( <u>19</u> H )
Decision of Escrow Action	26 ( <u>1A</u> H )
*Get the number of recycling bill	27 ( <u>1B</u> H)
*Dispense the number of bills	28 ( <u>1C</u> H )

**ICTBR version 1.0** 

Sep, 2016

Page 11 of 35



*Dispense Monitor Status	29 ( <u>1D</u> H )
*Transfer the number of bills	30 ( <u>1E</u> H )
*Transfer All of bills	31 ( <u>1F</u> H )
*Transfer Monitor Status	32 ( <u>20</u> H )
*Set Recycling Module Capacity	33 ( <u>21</u> H )
*Get Recycling Module Capacity	34 ( <u>22</u> H )
*Set the number of recycling bill	35 ( <u>23</u> H )

# **Note**:

• \* It means the command only for bill recycler.



## 4.2. Command Explanation

• It Introduces the ICT-BC command that how to use.

#### 4.2.1. Command (0) – Reply Command

Command Code	Response Data
<u>00</u> H	Depend on Command

• The response data length depends on the command.

#### 4.2.2. Command (1) – ACK Message

Command Code	Response Data
<u>00</u> H	No data bytes

• The slave device sends ACK message to Controller after receiving the controller's command. The master device confirms the slave device that received command already.

#### **4.2.3.** <u>Command (2) – NAK Message</u>

Command Code	Response Data
<u>02</u> H	No data bytes

• The slave device sends NAK message to Controller after receiving the controller's command. It means the slave device doesn't perform the operation.

#### 4.2.4. <u>Command (10) – Reset</u>

Command Code	Controller data	Response Data
<u>0A</u> H	No data bytes	ACK Message

- Command for reset the device.
- Controller should wait one second delay to next command after reset.

# 4.2.5. Command (11) – Request Manufacturer Code

Command Code	Controller data	Response Data
<u>0B</u> H	No data bytes	3 bytes : Z1 – Z3

Z1 - Z20 : Manufacturer Code – 3 bytes (ASCII)

• It indicates the equipment supplier's identification code.

# 4.2.6. Command (12) – Request Serial Number

Command Code	Controller data	Response Data
<u>0C</u> H	No data bytes	12 bytes : Z1 – Z12

Z1 - Z12 : Serial Number – 12 bytes

• It indicates the product serial number.

# 4.2.7. Command (13) – Request Product Code

Command Code	Controller data	Response Data
<u>0D</u> H	No data bytes	12 bytes : Z1 – Z12

Z1 - Z12: Product Code – 12 bytes (ASCII)

• It indicates the product code. Unsent bytes are assumed to be unused.

ICTBR version 1.0

Sep, 2016

Page 14 of 35

**International Currency Technologies Corp.** 



# 4.2.8. Command (14) – Request Country Code

Command Code	Controller data	Response Data
<u>0E</u> H	No data bytes	3 bytes : Z1 – Z3

Z1 - Z3 : Country Code – 3 bytes (ASCII)

• It depends on ISO 4217 alphabetic currency codes.(e.g. "TWD")

# 4.2.9. Command (15) – Request Firmware Information

Command Code	Controller data	Response Data
<u>0F</u> H	No data bytes	24 bytes : Z1 – Z24

Z1 - Z20 : Firmware Code – 20 bytes (ASCII)

• It indicates the program firmware code. Unsent bytes are assumed to be unused.

Z21 - Z22 : Firmware Version– 2 bytes (BCD)

• It indicates the firmware checksum. (e.g. 01.01)

Z23 - Z24 : Firmware CheckSum- 2 bytes (Hex)

- It indicates the firmware checksum. (e.g. 5A5A)
- Z1 · Z21 · Z23 equal to MSB.



## 4.2.10. Command (16) – Request Modification Date

Command Code	Controller data	Response Data
<u>10</u> H	No data bytes	3 bytes : Z1 – Z3

Z1: Day - 1 byte

• Range: 1 ~ 31

Z2: Month - 1 byte

• Range: 1 ~ 12

Z3: Year - 1 byte

• Range: 00 ~ 99

# 4.2.11. Command (17) – Set Escrow Parameter

Command Code	Controller data	Response Data
<u>11</u> H	1 bytes : Y1	ACK Message

Y1 : Escrow Capability – 1 bytes

- The escrow capability of the bill Validator. ( **Default setting** is Escrow On )
- <u>FFH</u> Escrow On Other Escrow Off



## 4.2.12. Command (18) – Get Escrow Parameter

Command Code	Controller data	Response Data
<u>12</u> H	No data bytes	1 bytes : Z1

Z1 : Escrow Capability – 1 byte

- The escrow capability of the bill Validator.
- Refer to Command(17) for detail information.

## **4.2.13.** Command (19) – Get Decimal Places

Command Code	Controller data	Response Data
<u>13</u> H	No data bytes	1 bytes : Z1

Z1 : Decimal Place – 1 byte

- It means the number of decimal places.
- e.g. 0 to 3

## 4.2.14. Command (20) – Get Bill Type Credit

Command Code	Controller data	Response Data
<u>14</u> H	1 bytes : Y1	3 bytes : Z1 – Z3

Y1 : Request Bill Type – 1 bytes

- Get each bill type value.
- e.g. 1 to 16

Z1 - Z3 : Bill Type Credit – 3 bytes

- It means the value of bill type.( Z1-- MSB Z--LSB )
- e.g. Decimal places is <u>2</u>. Bill type credit is <u>500</u>. The currency is \$<u>5.00</u>

**ICTBR version 1.0** 

Sep, 2016

Page 17 of 35



# 4.2.15. Command (21) – Set Bill Type Enable Parameter

Command Code	Controller data	Response Data
<u>15</u> H	2 bytes : Y1 - Y2	ACK Message

#### Y1 - Y2 : Bill Type Enable Parameter – 2 bytes

Byte Y1 bits						I	Byte Y	72 bit	<u>s</u>					
b16	b15	b14	b13	b12	b11	b10	b9 b8	b7	b6	b5	b4	b3	b2	b1

- Indicates the bill enables for bill types 1 to 16.
- A bit is set to indicate acceptance of bill type.
- **Default setting** is All bill types that are disabled.

#### 4.2.16. Command (22) – Get Bill Type Enable Parameter

Command Code	Controller data	Response Data
<u>16</u> H	No data bytes	2 bytes : Z1 – Z2

#### Z1 - Z2 : Bill Type Enable Paramete – 2 bytes

- It means what type of bill are accepted.
- Refer to Command(21) for detail information.

#### 4.2.17. Command (23) – Set Recycling Bill Type

Command Code	Controller data	Response Data
<u>17</u> H	1 bytes : Y1	ACK Message

#### Y1 : Recycling Bill Type − 1 bytes

- Indicate what bill type can be routed to the recycling module.
- $01H \sim 10H$  Recycled Bill Type Other No Recycled Bill Type
- **Default setting** is no recycled bill.

ICTBR version 1.0

Sep, 2016

Page 18 of 35



# 4.2.18. Command (24) – Get Recycling Bill Type

Command Code	Controller data	Response Data
<u>18</u> H	No data bytes	1 bytes : Z1

Z1 : Recycling Bill Type – 1 bytes

- Indicate what bill type can be routed to the recycling module.
- Refer to Command(23) for detail information.

#### **4.2.19.** Command (25) – Poll Status

Command Code	Controller data	Response Data
<u>19</u> H	No data bytes	13 bytes : Z1 – Z13

Z1 : Status Register – 1 bytes

- Indicate the new records and this must be compared at each poll to the last known value
- Range: 1 to 255. 0 means power up or reset

#### Z2 - Z13 : Status Buffer – 12 bytes

			Status Buffer			
<b>Z</b> 2	Z3 Z4	Z5 Z6	Z7 Z8	Z9 Z10	Z11 Z12	Z13

- Two byte represents a new record. 12 bytes can store the last 6 records. The records are lost if More than buffer limit range.

$$Z2 \cdot Z3$$
 – The last record  $Z12 \cdot 13$  – The oldest record

Status Register	The last record stored in buffer.
0	<u>No Record</u>
1	<u>Record1</u>
2	Record2 · Record1
5	<u>Record5</u> \ <u>Record4</u> \ <u>Record3</u> \ Record2 \ Record1
8	Record8 \ Record7 \ Record6 \ Record5 \ Record4 \ Record3 \ older data are lost

Refer to "Appendix 1" for credit and error detail

ICTBR version 1.0

Sep, 2016

Page 19 of 35



#### 4.2.20. Command (26) – Decision of Escrow Action

Command Code	Controller data	Response Data
<u>1A</u> H	1 bytes : Y1	ACK Message

Y1 : Escrow Action Parameter – 1 bytes

- The controller decides to stack or reject the bill that in the escrow position.
- The slave device will send the NAK message to the controller when no bill in escrow position.

Parameter Code (Hex)	Status Detail information
<u>11</u> H	Stack the Bill
<u>22</u> H	Reject the Bill from escrow position
Other code	

#### 4.2.21. Command (27) – Get the number of recycling bill

Command Code	Controller data	Response Data
<u>1B</u> H	No data bytes	1 bytes : Z1

Z1: The number of recycling bill – 1 bytes

- Indicate how many bills that are stored in the recycling module.
- The stored capacity that depend on the bill recycler module.
- e.g. NE77-BR 30 stored bill in the recycling module.

#### 4.2.22. Command (28) – Dispense the number of bills

Command Code	Controller data	Response Data
<u>1C</u> H	1 bytes : Y1	ACK Message

Y1: Number of bills to be paid out – 1 bytes

• Controller decides how many bills can be paid out.

**ICTBR version 1.0** 

Sep, 2016

Page 20 of 35



# **ICT Banknote Communication Protocol**

- The parameter can't be assigned to 0 or more than number of stored bill. The response is NAK Message.
- The dispense operation can't be excuted at other operation is excuted. Like
   <u>Accepting bill</u> \( \text{transfer bill} \) or <u>Disable mode</u>. The response is NAK
   Message.
- Controller need to send the <u>Dispense Monitor Status</u> command to monitor the dispense operation that is finish or fail.
  - If the Bill module occurs error status. It means the dispense operation is stopped. The rest of bills can't be paid out from recycling module.

# 4.2.23. Command (29) – Dispense Monitor Status

Command Code	Controller data	Response Data
<u>1D</u> H	No data bytes	7 bytes : Z1 – Z7

Z1 : Dispense Monitor Register – 1 bytes

• The function like Command (25) Status Register.

• Range: 1 to 255. 0 means power up or reset

Z2 - Z7 : Dispense Monitor Status – 6 bytes

• To check the dispense operation that is accomplished or not.

Status Code (Hex)	Status Detail information	
<u>00</u> H	No dispense operation	
<u>11</u> H	The dispense operation is busy	
<u>22</u> H	The dispense operation is finished	
<u>33</u> H	The dispense operation is failed	

- One byte represents a new record. 6 bytes can store the last 6 records. The records are lost if More than buffer limit range.
- Z2 The last record Z7 The oldest record

ICTBR version 1.0

Sep, 2016

Page 21 of 35



#### **4.2.24.** Command (30) – Transfer the number of bills

Command Code	Controller data	Response Data
<u>1E</u> H	1 bytes : Y1	ACK Message

Y1: Number of bills to be transferred – 1 bytes

- Controller decides how many bills can be transferred.
- The parameter can't be assigned to 0 or more than number of stored bill. The response is NAK Message.
- The transfer operation can't be excuted at other operation is excuted. Like
   <u>Accepting bill</u> <u>dispense bill</u> or <u>Disable mode</u>. The response is NAK
   Message.
- Controller need to send the <u>Transfer Monitor Status</u> command to monitor the transfer operation that is finish or fail.
  - If the Bill module occurs error status. It means the transfer operation is stopped. The rest of bills can't be transferred to cashbox from recycling module.

#### 4.2.25. Command (31) – Transfer All of bills

Command Code	Controller data	Response Data
<u>1F</u> H	No data bytes	ACK Message

- All of bills are transferred to cashbox from the recycling module.
- The transfer operation can't be excuted at other operation is excuted. Like
   <u>Accepting bill</u> · <u>dispense bill</u> or <u>Disable mode</u>. The response is NAK
   Message.
- Controller need to send the <u>Transfer Monitor Status</u> command to monitor the transfer operation that is finish or fail.
  - If the Bill module occurs error status. It means the transfer operation is stopped. The rest of bills can't be transferred to cashbox from recycling module.

**ICTBR version 1.0** 

Sep, 2016

Page 22 of 35



#### 4.2.26. Command (32) – Transfer Monitor Status

Command Code	Controller data	Response Data
<u>20</u> H	No data bytes	7 bytes : Z1 – Z7

Z1: Transfer Monitor Register – 1 bytes

• The function like Command (25) Status Register.

• Range: 1 to 255. 0 means power up or reset

Z2 - Z7 : Transfer Monitor Status – 6 bytes

• To check the transfer operation that is accomplished or not.

Status Code (Hex)	Status Detail information			
<u>00</u> H	No transfer operation			
<u>11</u> H	The transfer operation is busy			
<u>22</u> H	The transfer operation is finished			
<u>33</u> H	The transfer operation is failed			

• One byte represents a new record. 6 bytes can store the last 6 records. The records are lost if More than buffer limit range.

• Z2 – The last record Z7 – The oldest record

# 4.2.27. Command (33) – Set Recycling Module Capacity

Command Code	Controller data	Response Data
<u>21</u> H	1 bytes : Y1	ACK Message

Y1: Recycling Module Capacity – 1 bytes

- Indicate how many bills can be routed to the recycling module.
- The maximum capacity depends on Bill recycler.
- If the setting parameter is more than the structure capacity. The response is NAK Message.
- The recycling module capacity change is valid until the next power on.

ICTBR version 1.0

Sep, 2016

Page 23 of 35



# 4.2.28. Command (34) – Get Recycling Module Capacity

Command Code	Controller data	Response Data
<u>22</u> H	No data bytes	1 bytes : Z1

#### Z1 : Recycling Module Capacity – 1 bytes

- Indicate how many bills can be routed to the recycling module.
- Refer to Command(33) for detail information.

#### 4.2.29. Command (35) – Set the number of recycling bill

Command Code	Controller data	Response Data
<u>23</u> H	1 bytes : Y1	ACK Message

#### Y1: The number of recycling bill – 1 bytes

- Indicate how many bills that are stored in the recycling module.
- Refer to Command(27) for detail information.
- The number of recycling bill is not correct after the unknown mistake is occurred. The administrator can use this command to correct the number of recycling bill.
- To verify the number of recycling bill in recycling module before correcting the value.



# Appendix 1 – ICT-BC Record Codes

Record(Two bytes)		Record detail information			
Byte1	Byte2	Record detail information			
0	1 to 16	Bill type 1 to 16 hold on escrow			
1	1 to 16	Bill type 1 to 16 stacked in cashbox			
2	1 to 16	Bill type 1 to 16 stored in recycling module			
3	0	A banknote is transferred to escrow position from recycling module.*			
4	0	A banknote is return to customer from escrow position.*			
5	0	A banknote is transferred to cashbox from escrow position.*			
255	0	The issue is solved			
255	1	Motor problem			
255	2	Sensor problem			
255	3	Bill Jam			
255	4	Bill Remove			
255	5	Bill Reject			
255	6	Stacker remove			
255	7	Stacker faulty			
255	8	Recycled module sensor problem.*			
255	9	Recycled module motor problem.*			
255	10	Recycled module jam problem.*			
255	11	Recycled module is disconnected.*			
XXX	XXX	Reserved			

# Note:

• \* It means the command only for bill recycler.



# Appendix 2 – Example Sequence Codes

I. Initial procedure

Controller		Bill Recycler	<b>Explanation</b>
Reset( <u>0A</u> H)	$\rightarrow$		Reset command for Device
	<b>←</b>	Ack Message	
Manufacturer	<b>†</b>		e.g. "ICT"
Code( <u>0B</u> H)	<b>←</b>	Identification code	
Serial Number( <u>0C</u> H)	<b>→</b>		e.g. "123456789012"
	<b>←</b>	Identification code	
Product Code( <u>0D</u> H)	$\rightarrow$		e.g. "NE77B2B-TWD4"
	<b>←</b>	Product code	
Country Code( <u>0E</u> H)	<b>→</b>		e.g. "TWD"
	<b>←</b>	Country code	
Firmware Info( <u>0F</u> H)	$\rightarrow$		e.g.
	<b>←</b>	Firmware Info	NKRX013BV01000TW403
			1.01(5A5A)
Modification Date( <u>10</u> H)	<b>→</b>		e.g. "28/02/16"
	<b>←</b>	Modification date	It means 2016/02/28
Decimal Places(13H)	<b>→</b>		e.g. "1"
	<b>←</b>	Decimal Places	The value displays "xxx.0"
Bill Type Credit( <u>14</u> H)	<b>~</b>		e.g. Type1 is "100"
	<b>←</b>	Bill Type Credit	Controller need to get the type by ordering 16 times.

**ICTBR version 1.0** 

Sep, 2016

Page 26 of 35

**International Currency Technologies Corp.** 



# II. Escrow ON procedure

<u>Controller</u>		Bill Recycler	<b>Explanation</b>
Set Escrow( <u>11</u> H)	$\rightarrow$		The data is <u>FF</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Escrow( <u>12</u> H)	<b>→</b>		The response is <u>FF</u> H
	<b>←</b>	Escrow parameter	FFH – Escrow ON

# III. Escrow OFF procedure

<u>Controller</u>		Bill Recycler	<b>Explanation</b>
Set Escrow( <u>11</u> H)	<b>→</b>		The data is <u>00</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Escrow( <u>12</u> H)	<b>^</b>		The response is <u>00</u> H
	<b>←</b>	Escrow parameter	<u>00</u> H – Escrow OFF

# IV. Enable bill procedure

<u>Controller</u>		Bill Recycler	<b>Explanation</b>
Set Bill Enable( <u>15</u> H)	<b>~</b>		e.g. The data is <u>00FF</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	<b></b>		e.g. The response is <u>00FF</u> H
	<b>←</b>	Enable parameter	<u>00FF</u> H – Device enable

**ICTBR version 1.0** 

Sep, 2016

Page 27 of 35



# V. Disable bill procedure

<u>Controller</u>		Bill Recycler	<b>Explanation</b>
Set Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The data is <u>0000</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The response is <u>0000</u> H
	<b>←</b>	Enable parameter	<u>0000</u> H – Device disable

# VI. Set recycling bill type procedure

Controller		Bill Recycler	<b>Explanation</b>
Set recycling type( <u>17</u> H)	<b>→</b>		e.g. The data is <u>01</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get recycling type ( <u>18</u> H)	<b>→</b>		e.g. The response is <u>01</u> H
	<b>←</b>	Recycling type	<u>01</u> H – Recycling type is type1

# VII. Set recycling capacity procedure

Controller		Bill Recycler	<b>Explanation</b>
Set recycling capacity(21H)	<b>†</b>	Ack Message	e.g. The data is <u>32</u> H  Ack means setting successful
Get recycling capacity (22H)	<b>→</b>	Recycling capacity	e.g. The response is <u>32</u> H <u>32</u> H – The capacity is 50



# ICT Banknote Communication Protocol

#### $\ \, \textbf{Accept Bill} ( \ \, \textbf{Escrow ON} \ ) \ \textbf{procedure} \\$ VIII.

Controller		Bill Recycler	<b>Explanation</b>
Set Escrow( <u>11</u> H)	<b>→</b>		The data is <u>FF</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Escrow(12H)	$\rightarrow$		The response is <u>FF</u> H
	<b>←</b>	Escrow parameter	FFH – Escrow ON
Set Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The data is <u>000F</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The response is <u>000F</u> H
	<b>←</b>	Enable parameter	<u>000F</u> H – Device enable
Poll Status( <u>19</u> H)	$\rightarrow$		No event occur.
	<b>←</b>	No record	
Poll Status( <u>19</u> H)	$\rightarrow$		e.g. Bill type 1 hold on escrow
	<b>←</b>	Add record1	position.
Decision of Escrow	$\rightarrow$		e.g. The data is <u>11</u> H
Action( <u>1A</u> H)	<b>←</b>	Ack Message	Stack the bill
Poll Status( <u>19</u> H)	$\rightarrow$		Bill type 1 hold on escrow
	<b>←</b>	Only record1	position.
Poll Status( <u>19</u> H)	$\rightarrow$		e.g. Bill type 1 is stacked in
	<b>←</b>	Add record2	cashbox.



# IX. Reject Bill (Escrow ON ) procedure

<u>Controller</u>		Bill Recycler	<b>Explanation</b>
Set Escrow(11H)	$\rightarrow$		The data is <u>FF</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Escrow( <u>12</u> H)	<b>→</b>		The response is <u>FF</u> H
	<b>←</b>	Escrow parameter	FFH – Escrow ON
Set Bill Enable( <u>15</u> H)	<b>→</b>		e.g. The data is <u>000F</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	<b>→</b>		e.g. The response is <u>000F</u> H
	<b>←</b>	Enable parameter	000FH – Device enable
Poll Status( <u>19</u> H)	<b>→</b>		No event occur.
	<b>←</b>	No record	
Poll Status( <u>19</u> H)	<b>→</b>		e.g. Bill type 1 hold on escrow
	<b>←</b>	Add record1	position.
Decision of Escrow	<b>→</b>		e.g. The data is <u>22</u> H
Action( <u>1A</u> H)	<b>←</b>	Ack Message	Reject the bill from escrow
Poll Status( <u>19</u> H)	<b>→</b>		Bill type 1 hold on escrow
	<b>←</b>	Only record1	position.
Poll Status( <u>19</u> H)	<b>→</b>		e.g. Bill reject
	<b>←</b>	Add record2	
Poll Status( <u>19</u> H)	<b>→</b>		e.g. The issue is solved.
	<b>←</b>	Add record3	

ICTBR version 1.0

Sep, 2016 Page 30 of 35



# X. Recycling Bill (Escrow ON) procedure

Controller		Bill Recycler	<b>Explanation</b>
Set recycling type( <u>17</u> H)	<b>→</b>		e.g. The data is <u>01</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get recycling type ( <u>18</u> H)	<b>→</b>		e.g. The response is <u>01</u> H
	<b>←</b>	Recycling type	01H – Recycling type is type1
Set Bill Enable( <u>15</u> H)	<b>→</b>		e.g. The data is <u>000F</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The response is <u>000F</u> H
	<b>←</b>	Enable parameter	<u>000F</u> H – Device enable
Poll Status( <u>19</u> H)	$\rightarrow$		No event occur.
	<b>←</b>	No record	
Poll Status( <u>19</u> H)	<b>→</b>		e.g. Bill type 1 hold on escrow
	<b>←</b>	Add record1	position.
Decision of Escrow	<b>→</b>		e.g. The data is <u>11</u> H
Action( <u>1A</u> H)	<b>←</b>	Ack Message	Stack the bill
Poll Status( <u>19</u> H)	$\rightarrow$		Bill type 1 hold on escrow
	<b>←</b>	Only record1	position.
Poll Status( <u>19</u> H)	$\rightarrow$		e.g. Bill type 1 is Stored in
	<b>←</b>	Add record2	recycling module
Get the number of	$\rightarrow$		e.g. The response is <u>01</u> H
recycling bill( <u>11</u> H)	<b>←</b>	Number of bill	01H – number of recycling bill

ICTBR version 1.0

Sep, 2016

Page 31 of 35



# **XI.** Dispense bill( Successful ) procedure

<u>Controller</u>		Bill Recycler	<b>Explanation</b>
Get the number of	<b>→</b>		e.g. The response is <u>03</u> H
recycling bill( <u>11</u> H)	<b>←</b>	Number of bill	03H – number of recycling bill
Set Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The data is <u>000F</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The response is <u>000F</u> H
	<b>←</b>	Enable parameter	<u>000F</u> H – Device enable
Dispense bill( <u>1C</u> H)	$\rightarrow$		e.g. The data is <u>01</u> H
	<b>←</b>	Ack Message	<u>01</u> H – Dispense one bill
Poll Status( <u>19</u> H)	$\rightarrow$		No event occur.
	<b>←</b>	No record	
Dispense Monitor	$\rightarrow$		e.g. The response is <u>11</u> H
Status( <u>1D</u> H)	<b>←</b>	Add record1	11H – Dispensing busy
Poll Status( <u>19</u> H)	$\rightarrow$		A banknote is transferred to
	<b>←</b>	Add record1	escrow position form recycler
Dispense Monitor	$\rightarrow$		e.g. The response is <u>11</u> H
Status( <u>1D</u> H)	<b>←</b>	only record1	11H – Dispensing busy
Poll Status( <u>19</u> H)	$\rightarrow$		A banknote is return to
	<b>←</b>	Add record2	customer from escrow position
Dispense Monitor Status( <u>1D</u> H)	$\rightarrow$		e.g. The response is <u>22</u> H
	<b>←</b>	Add record2	<u>22</u> H – Dispensed Finish
Get the number of	$\rightarrow$		e.g. The response is <u>02</u> H
recycling bill( <u>11</u> H)	←	Number of bill	02H – number of recycling bill

ICTBR version 1.0

Sep, 2016

Page 32 of 35



# ICT Banknote Communication Protocol

#### Dispense bill(Failed) procedure XII.

Controller		Bill Recycler	<b>Explanation</b>
Get the number of	<b>→</b>		e.g. The response is <u>03</u> H
recycling bill( <u>11</u> H)	<b>←</b>	Number of bill	03H – number of recycling bill
Set Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The data is <u>000F</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	<b>→</b>		e.g. The response is <u>000F</u> H
	<b>←</b>	Enable parameter	<u>000F</u> H – Device enable
Dispense bill( <u>1C</u> H)	$\rightarrow$		e.g. The data is <u>01</u> H
	<b>←</b>	Ack Message	<u>01</u> H – Dispense one bill
Poll Status( <u>19</u> H)	$\rightarrow$		No event occur.
	<b>←</b>	No record	
Dispense Monitor	<b>→</b>		e.g. The response is <u>11</u> H
Status( <u>1D</u> H)	<b>←</b>	Add record1	11H – Dispensing busy
Poll Status( <u>19</u> H)	<b>→</b>		Recycled module jam problem
	<b>←</b>	Add record1	
Dispense Monitor	<b>→</b>		e.g. The response is <u>33</u> H
Status( <u>1D</u> H)	<b>←</b>	Add record2	33H – Dispensed Failed
Poll Status( <u>19</u> H)	$\rightarrow$		Recycled module jam problem
	<b>←</b>	only record1	
The administrator solved the bill recycler problem.			
Poll Status( <u>19</u> H)	<b>→</b>		e.g. The issue is solved.
	<b>←</b>	Add record2	

**ICTBR version 1.0** 

Sep, 2016

Page 33 of 35

**International Currency Technologies Corp.** 



# ICT Banknote Communication Protocol

#### XIII. $Transfer\ bill(\ Successful\ )\ procedure$

Controller		Bill Recycler	<b>Explanation</b>
Get the number of	<b>→</b>		e.g. The response is <u>03</u> H
recycling bill( <u>11</u> H)	<b>←</b>	Number of bill	03H – number of recycling bill
Set Bill Enable( <u>15</u> H)	$\rightarrow$		e.g. The data is <u>000F</u> H
	<b>←</b>	Ack Message	Ack means setting successful
Get Bill Enable( <u>15</u> H)	<b>→</b>		e.g. The response is <u>000F</u> H
	<b>←</b>	Enable parameter	<u>000F</u> H – Device enable
Transfer bill( <u>1E</u> H)	<b>→</b>		e.g. The data is <u>01</u> H
	<b>←</b>	Ack Message	01H –Transfer one bill
Poll Status( <u>19</u> H)	<b>→</b>		No event occur.
	<b>←</b>	No record	
Transfer Monitor	<b>→</b>		e.g. The response is <u>11</u> H
Status( <u>20</u> H)	<b>←</b>	Add record1	11H –Transfer busy
Poll Status( <u>19</u> H)	<b>→</b>		A banknote is transferred to
	<b>←</b>	Add record1	escrow position form recycler
Transfer Monitor	<b>→</b>		e.g. The response is <u>11</u> H
Status( <u>20</u> H)	<b>←</b>	only record1	11H –Transfer busy
Poll Status( <u>19</u> H)	<b>→</b>		A banknote is transferred to
	<b>←</b>	Add record2	cashbox from escrow position
Transfer Monitor	<b>→</b>		e.g. The response is <u>22</u> H
Status( <u>20</u> H)	<b>←</b>	Add record2	<u>22</u> H –Transfer Finish
Get the number of	<b>→</b>		e.g. The response is <u>02</u> H
recycling bill( <u>11</u> H)	<b>←</b>	Number of bill	02H – number of recycling bill

**ICTBR version 1.0** 

Sep, 2016

Page 34 of 35



# **END**