# The Digital Music Synthesizer

#### Hanhee Lee

November 20, 2024

#### **Abstract**

The digital music synthesizer (DMS) is a system that makes musical sounds by using digital signal processing (DSP) techniques to (wikipedia). The DMS does this by modulating

### 1 Introduction

# 2 Mathematical Background

There are several mathematical concepts related to ECE355 that are relevant of the DMS. These include:

### 2.1 Fourier Analysis

From lecture

1. Synthesis Equation (Inverse Fourier Transform):

$$x(t) = \int_{-\infty}^{\infty} X(f)e^{j2\pi ft} df \tag{1}$$

2. Analysis Equation (Fourier Transform):

$$X(f) = \int_{-\infty}^{\infty} x(t)e^{-j2\pi ft} dt$$
 (2)

### 2.2 LTI Systems

From lecture

1. Convolution Integral in Time Domain:

$$y(t) = (x * h)(t) = \int_{-\infty}^{\infty} x(\tau)h(t - \tau) d\tau$$
(3)

2. Convolution Integral in Frequency Domain:

$$Y(f) = X(f) \cdot H(f) \tag{4}$$

## 3 Digital Synthesis Pipeline

### 3.1 Frequency Oscillators


The fundamental building blocks of digital music synthesis are the basic waveforms. These waveforms are used to create more complex sounds by combining them in various ways. The most common waveforms used in digital music synthesis are the sine wave, square wave, sawtooth wave, and triangle wave, which are created from frequency oscillators by adjusting the amplitude, frequency, and phase of the waveforms. For  $x \in \mathbb{R}^{\mathbb{R}}$ 

1. **Sine:** 

$$x(t) = A\sin(2\pi f t + \phi) \tag{5}$$


2. Square Wave:

$$x(t) = \frac{1}{T} + \sum_{k>1} \frac{2}{T} \operatorname{sinc}\left(\frac{k}{T}\right) \cos\left(2\pi \frac{k}{T}t\right)$$
(6)



3. Sawtooth Wave:

$$x(t)\sum_{k\geq 1} \frac{(-1)^{k-1}T}{\pi k} \sin\left(2\pi \frac{k}{T}t\right) \tag{7}$$



4. Triangle Wave:

$$x(t) = \sum_{k=1,3,5,\dots}^{\infty} \frac{8A}{\pi^2 k^2} (-1)^{(k-1)/2} \cos\left(2\pi \frac{k}{T}t\right)$$
 (8)

- A: Amplitude of the waveform.
- f[Hz]: Frequency of the waveform.
- t: Time.
- $\phi[rad]$ : Phase offset.
- n: Harmonic number.
- T: Period of the waveform.

5. Additive Synthesis: Synthesizing sound by adding together N sinusoidal components by time-varying amplitude and frequency envelopes to get  $y \in \mathbb{R}^{\mathbb{R}}$ , (from Spectral audio signal processing III)

$$y(t) = \sum_{i=1}^{N} A_i(t) \sin(\theta_i(t))$$
(9)

- $A_i(t) \in \mathbb{R}$ : Amplitude of ith partial over time t
- $\theta_i(t) = \int_0^t \omega_i(t)dt + \theta_i(0) \in \mathbb{R}$ 
  - $\omega_i(t) = \frac{d\theta_i(t)}{dt} \in \mathbb{R}$ : Radian frequency of ith partial vs. time.
  - $-\phi_i(0) \in \mathbb{R}$ : Phase offset of *i*th partial at time 0.

#### 3.2 Waveform Generation

- 1. Subtractive Synthesis:
- 2. Amplitude Modulation (AM) Synthesis: From the theory and techniques of electronic music (Miller Puckette)

$$y(t) = A_c \left( 1 + \frac{A_m}{A_c} \cos \omega_m t \right) \cos \omega_c t \tag{10}$$

3. Frequency Modulation (FM) Synthesis:

$$x(t) = A_c \sin\left[\omega_c t + \phi_c + A_m \sin(\omega_m t + \phi_m)\right] \tag{11}$$

- $(A_c, \omega_c, \phi_c)$ : Specify the carrier sinusoid.
- $(A_m, \omega_m, \phi_m)$ : Specify the modulator sinusoid.

### 3.3 Envelope Shaping

- 1. **Filtering:** Filtering is a method to affect only a certain range of frequencies in a signal. Some common filters are:
  - Low Pass Filter: This filter allows low frequencies to pass through.  $H(j2\pi f) = \begin{cases} 1 & \text{if } |f| \leq f_c \\ 0 & \text{if } |f| > f_c \end{cases}$
  - **High Pass Filter:** This filter allows high frequencies to pass through.  $H(j2\pi f) = \begin{cases} 1 & \text{if } |f| \geq f_c \\ 0 & \text{if } |f| > f_c \end{cases}$
  - Band Pass Filter: This filter allows a certain band of frequencies to pass through.  $H(j2\pi f) = \begin{cases} 1 & \text{if } f_c \frac{B}{2} \leq |f| \leq f_c + \frac{B}{2} \\ 0 & \text{otherwise} \end{cases}$

### 3.4 ADSR Envelope

### 3.5 Digital-to-Analog Conversion

### 3.5.1 Nyquist-Shannon Sampling Theorem

The theorem states that a continuous signal can be reconstructed from its samples if the sampling frequency is greater than twice the maximum frequency of the signal:

$$f_s > 2f_{\text{max}} \tag{12}$$

- $f_s$ : Sampling frequency.
- $f_{\text{max}}$ : Maximum frequency of the original signal.

As a result, there are enough samples to accurately capture the details fo the signal without aliasing (i.e. distortion in the reconstructed signal).

- The theorem is used for Digital-to-Analog Conversion (DAC) and Analog-to-Digital Conversion (ADC).
  - Specifically, for DAC, the theorem ensures that the processed digital signal after going through the DMS pipeline can be accurately converted back to an analog signal for playback through speakers or headphones.

### 3.6 Example

#### 4 Conclusion

# Acknowledgement

#### References

- [1] A. Akhmadiya, A. Mirmanov, N. Nabiyev, S. Bostanova, T. Serikov, and K. Ibrayev, "Assessing battery life and accuracy of modern GPS trackers for herd horse breeding," in *Proc. 2023 IEEE Int. Conf. on Smart Info. Sys. and Techn.* (SIST), Astana, Kazakhstan, May 4–6, 2023, pp. 109–113.
- [2] E. D. Kaplan and C. J. Hegarty, (Eds). *Understanding GPS: Principles and Applications*, Second Edition. Boston, MA: Artech House Publishing, 2017.
- [3] W. Lewandowski, J. Azoubib, and W. J. Klepczynski, "GPS: primary tool for time transfer," *Proc. IEEE*, vol. 87, no. 1, pp. 163–172, Jan. 1999.
- [4] M. Tamazin, *High Resolution Signal Processing Techniques for Enhancing GPS Receiver Performance*, Ph.D. dissertation, Dept. of Electrical and Computer Engineering, Queen's University, Kingston, Ontario, Canada, March 2015.