

¹⁰When laminated to plywoodboard thin-A XIRTL/MF is deemed to be class 0 in accordance with the building regulations.

Thermal Lining Insulation

Figure 1 consists of three parts: (a) a 3D perspective view of a window frame assembly showing the frame, insulation, and structural elements; (b) a 2D cross-section view of the window frame and insulation; and (c) a photograph of the window frame installed in a wall.

Mechanical Fixing XT/TL-MF

Fix a pre-treated timber batten horizontally at ceiling level and another 20mm above the finished floor level.

and another 20mm above the finished floor level.

Fix vertical banners at max 600mm centres

Ensure battens are wide enough to offer 20mm support to all four edges of the plasterboard.

all four edges of the plasterboard.

Trim all openings and service penetrations with timber battens.

betters.

Insulation should be cut back to accommodate an adjoining panel at external corners.

Lift the XT/TL-MF Thermal Liner into position using wedges on the floor.

Stems should be fixed to the timber batten at 150mm centres, at least 12mm in from the board edge. The bungs should penetrate at least 25mm into the batten.

practice, BS 8212:1998 should be considered, careful sealing out and planning is essential, fill any gaps with foam filler.

Accredited details should be followed to ensure that calculated performance is achieved.

WALLS (XT/TL-MF) - Dry Lined

XIPRAITH

Contact Matheson Technical Support for specific U-value calculations

The resistance value of any thickness of Xlatherm PIR can be ascertained by simply dividing the thickness of the material (in metres) by its α figure declared lambda value 0.022 W/mK, eg 50mm = $0.050/0.022 = R2.27$

TITLE	PROPOSED DRAWINGS	ADDRESS	95 MALVERN ROAD LONDON, NW6
CLIENT	Mr. C. NORMAN	SCALE	1:50 @ A3
		DATE	MARCH 2019

Tel: 07970 647 449 Fax: 020 8963 9991 Email: urlondon@aol.com