

TASKS

Question: 1

Remove the side panel of a desktop PC case and take a clear photo showing the internal layout before any components are removed?

Answer: First, switch off the desktop PC and disconnect the power cable. Carefully remove the side panel of the PC case. Do not remove or disconnect any components. Take a clear photo showing the complete internal layout, including the motherboard, RAM, storage drives, power supply, cooling fans, graphics card, and cable connections. This photo will serve as a reference for the original arrangement before any components are removed.

Question: 2

Carefully remove the RAM module(s) from the motherboard, document the removal steps, and record the RAM type, speed, and form factor as printed on the module?

- Answer: 1. Shut down the computer and disconnect the power cable.
2. Open the computer case and locate the RAM module(s) on the motherboard.
3. Press the locking clips on both sides of the RAM slot outward.
4. Carefully hold the RAM module by its edges and remove it from the slot.
5. Check the label printed on the RAM module and record its specifications.

Question: 3

Disconnect and remove the storage drive (HDD or SSD) from the system, then list all connector types (SATA, power, etc.) used and describe how the drive was mounted inside the case. **Hint:** Pay attention to both cable connectors and any brackets or screws securing the drive.

Answer: The storage drive (HDD/SSD) was removed by first disconnecting the SATA data cable and the SATA power cable from the drive. After disconnecting the cables, the screws holding the drive in the drive bay/bracket were removed, and the drive was carefully taken out of the case. The drive was securely mounted inside the case using a drive bracket/cage and screws.

Question: 4

Identify and remove one expansion card (such as a graphics card or Wi-Fi card), then document the connector type (e.g., PCIe), screw type used, and any locking mechanisms you encountered?

Answer: 1. Expansion Card: Wi-Fi card.
2. Connector Type: PCIe (PCI Express) slot.
3. Screw Type: Standard case/expansion-slot screw.
4. Removal: The screw was removed first, and then the card was carefully pulled out of the PCIe slot.
5. Locking Mechanism: A PCIe slot locking clip was released before removing the card.

Installation: The card was secured to the computer case with a screw.

Question: 5

Explain three safety precautions you followed during the disassembly process to prevent static electricity damage or injury and describe how you ensure proper grounding.

Hint: Mention tools or accessories like anti-static wrist straps, and steps like unplugging the power supply.

Answer: 1. Before starting the disassembly, I switched off the computer and unplugged the power cable to prevent electric shock and damage to the internal components.
2. Use an anti-static wrist strap: I used an anti-static wrist strap to prevent static electricity from transferring from my body to the computer components, which could damage sensitive parts.

3. Ensure proper grounding: I connected the wrist strap to a grounded metal part of the computer case. This safely discharged any static electricity from my body while handling the components.