


MAIN 2/3



RESISTOR	PARTS NAME	CAPACITOR	PARTS NAME
0402	0402	0402	0402
0603	0603	0603	0603
0805	0805	0805	0805
1206	1206	1206	1206
1812	1812	1812	1812
2512	2512	2512	2512
3225	3225	3225	3225
4024	4024	4024	4024
5024	5024	5024	5024
6024	6024	6024	6024
7024	7024	7024	7024
8024	8024	8024	8024
9024	9024	9024	9024
10024	10024	10024	10024
15024	15024	15024	15024
20024	20024	20024	20024
25024	25024	25024	25024
30024	30024	30024	30024
35024	35024	35024	35024
40024	40024	40024	40024
45024	45024	45024	45024
50024	50024	50024	50024
55024	55024	55024	55024
60024	60024	60024	60024
65024	65024	65024	65024
70024	70024	70024	70024
75024	75024	75024	75024
80024	80024	80024	80024
85024	85024	85024	85024
90024	90024	90024	90024
95024	95024	95024	95024
100024	100024	100024	100024

NOTICE

1. All components are marked with a triangle and must be replaced with parts having specifications equal to those originally installed.

2. Schematic diagram is subject to change without notice.

Details of colored lines

- Red / full line: Power supply (+)
- Red / dashed line: Power supply (-)
- Orange: Signal detect
- Yellow: Clock
- Green: Protection detect
- Brown: Reset signal
- Blue: Panel key input