
# UPRA - MATeF-2

Integration Manual




#### **MODULES**




#### **EPS-GPS Interface Card**

- UPRA 2.0 Standard
- 94x80 mm



#### On-Board Computer (OBC)


- OBC.mega328
- UPRA Standard
- 70x75 mm




#### **Communication Module (COM)**

- COM.RF69HCW
- UPRA Standard
- 70x75 mm


#### **SPACERS**




Height: 10mm Male-Female Material: Metal



Height: 12mm Male-Female Material: Metal



Height: 15mm Male-Female Material: Nylon



Nº4

Height: 15mm Female-Female Material: Nylon

#### **WASHERS**

Nº5




Height: 1mm


Diameter: M3/8mm


Material: Metal

## **Exploded 1**



### **Exploded 2**









1. Place 12mm Spacers(Nº2) to the fixing holes of the COM module

Personnel

Date

Signature









1. Add M3 washers(No5) to the threaded spacers


Personnel

Date


Signature









	1. Add 15mm Male-Female Spacers	Personnel	
		Date	
		Signature	





1x





1. Connect the OBC module on top of the COM module

Personnel

Date

Signature









1. Add M3 washers(No5) to the threaded spacers


Personnel Date


Signature






1. Add 15mm FM-FM Spacers(No4)	Personnel	
	Date	
	Signature	





1x




**EPS-GPS Module** 


1. Connect the EPS-GPS module on top of the OBC module


Personnel

Date

Signature







- 1. Add 10mm Spacer(No1) to the thread over the EPS-Proto module
- 2. Add 12mm Spacers(No2) to the rest

Personnel	
Date	
Signature	

