## **SPARE PARTS LIST**

PAGE 1
MODEL: BBC300I

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	265995-6	TAPPING SCREW 4X18	8	PC.
002	188841-5	GRIP SET	1	PC.
003	922228-9	H.S.H.BOLT M5X18 WITH WR	1	PC.
004	265995-6	TAPPING SCREW 4X18	1	PC.
005	687261-5	STRAIN RELIEF	1	PC.
006	451983-1	LOCK OFF BUTTON	1	PC.
007		COMPRESSION SPRING 4	2	PC.
800		SWITCH SLE6A2-33	1	PC.
009		SWITCH LEVER	1	PC.
010		INDICATOR	1	
011		STEEL BALL 5.0	1	PC.
012		COMPRESSION SPRING 2	1	PC.
013 014		SWITCH TGR3-3 RECEPTACLE SLEEVE	1	PC. PC.
014	188841-5		1	
016		LINK PLATE	1	PC.
017		LEAD COVER	1	PC.
018	431303 7	ELAD COVER	-	1 C.
019				
020				
021				
022				
023				
024	195215-3	LOOP HANDLE SET	1	PC.
025	451598-4	LOOP HANDLE 24	1	PC.
026	451599-2	HANDLE CLAMP 24	1	PC.
027	911253-5	PAN HEAD SCREW M5X30	4	PC.
028	168478-4	HANGER	1	PC.
029	922228-9	H.S.H.BOLT M5X18 WITH WR	1	PC.
030				
031	140284-9	SHAFT PIPE COMPLETE	1	PC.
032				
033				
034	225042.2	CHAFT		DC
035	325812-3		1	
036		H.S.H.BOLT M5X14 WITH WR	2	PC.
037	125/91-3	GEAR CASE ASSY	1	PC.
038				
039 040	210040 4	BALL BEARING 609ZZ	1	PC.
040		RETAINING RING S-9	1	PC.
041		RETAINING RING 5-9 RETAINING RING R-24	1	
043		HEX. SOCKET HEAD BOLT M5X25	1	PC.
044		+HEX.BOLT M8X10 WITH R	1	
045	200000 2		-	
046	188902-1	CUTTER SHAFT SET	1	PC.
047	100302 1		-	
048				
049	210115-7	BALL BEARING 6001LLU	1	PC.
050		RETAINING RING R-28	1	
051		RECEIVE WASHER	1	
052	222302 0		-	
053				
054				
055	451566-7	PROTECTOR	1	PC.
056		PROTECTOR COVER	1	
057		O PING 11	- 2	DC.

2 PC.

2 PC.

1 PC.

PC.

057

058

059

060

213105-9 O RING 11

346073-2 PROTECTOR CLAMP

911233-1 PAN HEAD SCREW M5X20

922353-6 HEX.SOCKET HEAD BOLT M6X30

## **SPARE PARTS LIST**

PAGE 2

## **MODEL: BBC300L**

ITEM	PART NO.	DESCRIPTION	QTY	N	OTE	
061	451981-5	GEAR BOX COVER	1	.	PC.	
062	424307-4	PIPE RUBBER	1		PC.	
063	922231-0	HEX. SOCKET HEAD BOLT M5X20	1	.	PC.	
064	318560-1	PIPE BRACKET	1		PC.	
065	911233-1	PAN HEAD SCREW M5X20	4	.	PC.	
066	263002-9	RUBBER PIN 4	1		PC.	
067	213045-1	O-RING 6	1		PC.	
068	325811-5	SPINDLE HUB	1		PC.	
069	211148-5	BALL BEARING 6001ZZ	1	.	PC.	
070	253744-3	FLAT WASHER 12	1	.	PC.	
071	227720-3	HELICAL GEAR 33	1	.	PC.	
072	253744-3	FLAT WASHER 12	1	.	PC.	
073	211150-8	BALL BEARING 6901ZZ	1	.	PC.	
074	318559-6	GEAR BOX	1		PC.	
075	265995-6	TAPPING SCREW 4X18	4	.	PC.	
076		TAPPING SCREW 5X25	4	.	PC.	
077	451572-2	STAND	1		PC.	
078	911233-1	PAN HEAD SCREW M5X20	2	.	PC.	
079	699047-5	POWER SUPPLY CORD UNIT	1	.	PC.	
080	265995-6	TAPPING SCREW 4X18	5	.	PC.	
081	867948-7	BBC300L NAME PLATE	1		PC.	
082	251314-2	+ SCREW M4X12	4	.	PC.	
083	346194-0	BATTERY GUARD	1		PC.	
084	188836-8	HOUSING SET	1		PC.	
085		TAPPING SCREW 4X18	3		PC.	
086	188838-4	MOTOR HOUSING SET	1		PC.	
087	213961-7	O RING 22	1		PC.	
088	619254-4	ROTOR	1		PC.	
089	629880-1	STATOR	1		PC.	
090	188838-4	MOTOR HOUSING SET	1	.	PC.	
091	265995-6	TAPPING SCREW 4X18	1	.	PC.	
092		STRAIN RELIEF	1		PC.	
093	346039-2	SUPPORT PLATE	1	.	PC.	
094		HOUSING SET	1		PC.	
095		TERMINAL	1		PC.	
096		CONTROLLER	1		PC.	
097		CONTROLLER COMPLETE	1		PC.	
098	140285-7	INDICATION PLATE COMPLETE	1	.	PC.	
099			_			
100	265995-6	TAPPING SCREW 4X18	1	.	PC.	
101	346280-7		1		PC.	
102		PROTECTOR EXTENSION COMPLETE	1		PC.	
103		INDICATION LABEL	1		PC.	
	35 - 5 . 1 5		-		٠.	

