

# CryptoServer

Error Reference



#### **Imprint**

copyright 2017 Utimaco IS GmbH

Germanusstrasse 4 D-52080 Aachen

Germany

phone +49 (0)241 / 1696-200 fax +49 (0)241 / 1696-199 web http://hsm.utimaco.com email support-cs@utimaco.com

document version 4.10.0.7 date 4.10.0.7

author Utimaco HSM R&D

document no. 2003-0001

all rights reserved No part of this documentation may be reproduced in any form (printing, photocopy

or according to any other process) without the written approval of Utimaco IS  $\mbox{\sf GmbH}$ 

or be processed, reproduced or distributed using electronic systems.

Utimaco IS GmbH reserves the right to modify or amend the documentation at any time without prior notice. Utimaco IS GmbH assumes no liability for typographical

errors and damages incurred due to them.

All trademarks and registered trademarks are the property of their respective owners.

## **Contents**

1	Introduction	on	5
2	Structure o	of the error codes	5
3	Error Desci	ription Table	7
	B000xxxx	CryptoServer module SMOS	7
	B001xxxx	CryptoServer module FIPS140	31
	B006xxxx	Bootloader	33
	B00Axxxx	CryptoServer module HCE	50
	B00Dxxxx	CryptoServer module EXAR	52
	B00Exxxx	CryptoServer module HCE	54
	B050xxxx	CryptoServer module PK	55
	B061xxxx	CryptoServer module CTS	59
	B064xxxx	CryptoServer module PKCS11	61
	B068xxxx	CryptoServer module CXI	63
	B081xxxx	CryptoServer module VDES	69
	B082xxxx	CryptoServer module PP, PIN pad driver	70
	B083xxxx	CryptoServer module CMDS, Command scheduler	72
	B084xxxx	CryptoServer module VRSA	78
	B085xxxx	CryptoServer Module SC	81
	B086xxxx	CryptoServer module UTIL	84
	B087xxxx	CryptoServer module ADM	86
	B088xxxx	CryptoServer Database Module	92
	B089xxxx	CryptoServer module HASH	94
	B08Bxxxx	CryptoServer module AES	95
	B08Dxxxx	CryptoServer module DSA	96
	B08Exxxx	CryptoServer module LNA	98
	B08Fxxxx	CryptoServer module ECA	99
	B090xxxx	CryptoServer module TECA	101
	B091xxxx	CryptoServer module ASN1	102
	B096xxxx	CryptoServer module MBK	104

B099xxxx	CryptoServer module PIN	108
B09Axxxx	CryptoServer module NTP	109
B09Cxxxx	CryptoServer module ECDSA	110
B900xxxx	CryptoServer API	112
B901xxxx	CryptoServer API LINUX	119
B902xxxx	CryptoServer API Windows	123
B904xxxx	yacl library	128
B905xxxx	Serial Driver	146
B906xxxx	CryptoServer admin library	148
B908xxxx	LCD Display module	172
B90Axxxx	CSLAN	173
B90Bxxxx	csadm Tool	176
B90Cxxxx	CSXAPI	177
B90Dxxxx	ulog library	179
B90Exxxx	Simple Database library	180
B90Fxxxx	P11 admin library	182
B912xxxx	Host Service Daemon	183
B915xxxx	dsp_admin3 - DSP Daemon on CSLAN	186
B916xxxx	Host API CTS - Crypto Timestamp	190
B917xxxx	CryptoServer Protocol Daemon	193
B918xxxx	CryptoServer Protocol Daemon	196
B91Cxxxx	CryptoServer PKCS11 API	198
B91Dxxxx	PIN pad API	199
B91Exxxx	copa Config Parser	202
B920xxxx	CryptoServer Core API Cxi	204
B980xxxx	java CryptoServer API	206
B981xxxx	Java CryptoServer API CXI	209
B982xxxx	Database API Java	211
B983xxxx	PinPad API Java	212
B984xxxx	JCA/JCE provider	213
B985xxxx	CryptoServerAPI.NET	214
RQR6xxxx	CryntoServer API CXI NET	215

### 1 Introduction

This document contains a complete list of all standard error codes that can be generated by any soft-ware developed for Utimaco hardware security module CryptoServer. Error codes that are generated by customer specific software developed for the CryptoServer are not described in this document. They are described in the individual documentation of that customer-specific software.

### 2 Structure of the error codes

All error codes are built according to a special scheme. Based on the value of an error code it can uniquely be identified which part of the software has generated the error. Each error code is a 4 byte integer displayed as a 8-digit hexadecimal number. The first digit is always a 'B'. The second digit divides the error code into three classes:

- Second digit is in the range '0' to '3':
  - This means the error is generated from any firmware module inside the CryptoServer. In this case the second to the forth digit define the ID of the firmware module (Function Code, FC). The last four digits contain the individual error code within this firmware module. For example, the error code B087000F is generated from the firmware module 0x087 (the administration module ADM), which issued the error code 000F. Currently, only error codes starting with B0 are defined by Utimaco. All error codes starting with B1 are reserved for firmware modules developed by customers or OEM partners. The error code prefixes B2 and B3 are not used yet and are reserved for future use.
- · Second digit is '9':
  - This means the error is generated by any standard software outside the CryptoServer, for example the device driver for the CryptoServer, the TCP software of the CryptoServer LAN or an API running on a host system. In this case the third and forth digit identify the software module. The last four digits contain the individual error code within this software. For example, the error code B9010007 is generated from the software identified by its id 0x01 (the UNIX version of the TCP section of the CryptoServer API, CSAPI), which issued the error code 0007.
- Second digit is 'A':
   This means the error is generated by any customer specific software outside the CryptoServer,

for example a customer specific API running on a host system. In this case the third to the fifth digit identify the software module. The last three digits contain the individual error code within this software.

These error codes are not described in this document.

# 3 Error Description Table

## **B000**xxxx — CryptoServer module SMOS

Code	Description
B00001xx	CryptoServer module SMOS
	SENS section
B0000100	CryptoServer module SMOS
	SENS section
	Sensory write error
B0000101	CryptoServer module SMOS
	SENS section
	Sensory read error
B0000102	CryptoServer module SMOS
	SENS section
	Bad info type
B0000103	CryptoServer module SMOS
	SENS section
	Error during memory allocation
B0000104	CryptoServer module SMOS
	SENS section
	Sensory I/O error
B0000105	CryptoServer module SMOS
	SENS section
	Corrupted Master Key
B0000106	CryptoServer module SMOS
	SENS section
	Sensory error answer
B0000107	CryptoServer module SMOS
	SENS section
	CryptoServer not in alarm state

Code	Description
B0000108	CryptoServer module SMOS
	SENS section
	Sensory read timeout
B0000109	CryptoServer module SMOS
	SENS section
	Alarm still present, can't reset
B000010A	CryptoServer module SMOS
	SENS section
	Controller: read timeout
B000010B	CryptoServer module SMOS
	SENS section
	Controller: bad command
B000010C	CryptoServer module SMOS
	SENS section
	Controller: bad address
B000010D	CryptoServer module SMOS
	SENS section
	Controller: bad data
B000010E	CryptoServer module SMOS
	SENS section
	Controller: bad CRC
B000010F	CryptoServer module SMOS
	SENS section
	Bad CRC in answer
B0000110	CryptoServer module SMOS
	SENS section
	Invalid parameter
B0000111	CryptoServer module SMOS
	SENS section
	Buffer size too small

Code	Description
B0000112	CryptoServer module SMOS
	SENS section
	Invalid length of answer data
B0000113	CryptoServer module SMOS
	SENS section
	Invalid job state
B0000114	CryptoServer module SMOS
	SENS section
	Sensory controller is locked
B000013x	CryptoServer module SMOS
	Sensory Controller section
B0000130	CryptoServer module SMOS
	Sensory Controller section
	unknown error code
B0000131	CryptoServer module SMOS
	Sensory Controller section
	timeout
B0000132	CryptoServer module SMOS
	Sensory Controller section
	bad command
B0000133	CryptoServer module SMOS
	Sensory Controller section
	bad address
B0000134	CryptoServer module SMOS
	Sensory Controller section
	bad data
B0000135	CryptoServer module SMOS
	Sensory Controller section
	bad CRC

Code	Description
B0000136	CryptoServer module SMOS
	Sensory Controller section
	I2C error
B0000137	CryptoServer module SMOS
	Sensory Controller section
	currently busy
B00002xx	CryptoServer module SMOS
	device section
B0000201	CryptoServer module SMOS
	device section
	notifies if an error occurs during operation
B0000202	CryptoServer module SMOS
	device section
	device is used by an other session
B0000203	CryptoServer module SMOS
	device section
	illegal device name length or characterset
B0000204	CryptoServer module SMOS
	device section
	illegal mode of operation
B0000205	CryptoServer module SMOS
	device section
	passed parameter illegal
B0000206	CryptoServer module SMOS
	device section
	session handle not allowed
B0000207	CryptoServer module SMOS
	device section
	corrupted data

Code	Description
B0000209	CryptoServer module SMOS
	device section
	can't allocate memory space
B000020A	CryptoServer module SMOS
	device section
	no private module function
B000020B	CryptoServer module SMOS
	device section
	no serial device available
B00003xx	CryptoServer module SMOS
	serial device section
B0000301	CryptoServer module SMOS
	serial device section
	bad handle
B0000302	CryptoServer module SMOS
	serial device section
-	device already open
B000030D	CryptoServer module SMOS
	serial device section
-	read error on serial line
B000030E	CryptoServer module SMOS
	serial device section
-	parameter to be modified is invalid
B0000310	CryptoServer module SMOS
	serial device section
	invalid parameter value to set control of SL
B0000311	CryptoServer module SMOS
	serial device section
	timeout while reading char from serial line

Code	Description
B0000312	CryptoServer module SMOS
	serial device section
	parity error
B0000313	CryptoServer module SMOS
	serial device section
	receiver over-run
B0000314	CryptoServer module SMOS
	serial device section
	receiver frame error
B0000315	CryptoServer module SMOS
	serial device section
	no data ready to read
B0000381	CryptoServer module SMOS
	serial device section
	too many lines open
B0000382	CryptoServer module SMOS
	serial device section
	error setting line parameters
B0000383	CryptoServer module SMOS
	serial device section
	can't open device
B0000384	CryptoServer module SMOS
	serial device section
_	handle not open
B0000385	CryptoServer module SMOS
	serial device section
	invalid handle
B0000386	CryptoServer module SMOS
	serial device section
	invalid parameter value

Code	Description
B0000387	CryptoServer module SMOS
	serial device section
	invalid parameter type
B0000388	CryptoServer module SMOS
	serial device section
	error on read
B0000389	CryptoServer module SMOS
	serial device section
	timeout on read
B000038A	CryptoServer module SMOS
	serial device section
	error on write
B000038B	CryptoServer module SMOS
	serial device section
	timeout on write
B000038C	CryptoServer module SMOS
	serial device section
	error on ioctl
B0000390	CryptoServer module SMOS
	serial device section
	no valid device name
B0000391	CryptoServer module SMOS
	serial device section
	no valid Buffer selected
B0000392	CryptoServer module SMOS
	serial device section
	line state parameter incorrect
B0000393	CryptoServer module SMOS
	serial device section
	line select parameter incorrect

Code	Description
B0000394	CryptoServer module SMOS
	serial device section
	error in comunication driver
B0000395	CryptoServer module SMOS
	serial device section
	Parity Error
B00004xx	CryptoServer module SMOS
	i2c device section
B0000401	CryptoServer module SMOS
	i2c device section
	one parameter is wrong
B0000402	CryptoServer module SMOS
	i2c device section
	got no acknowledge after sending a byte
B0000403	CryptoServer module SMOS
	i2c device section
	bad device identifier
B0000404	CryptoServer module SMOS
	i2c device section
	device does not exist
B00005xx	CryptoServer module SMOS
	file section
B0000501	CryptoServer module SMOS
	file section
	file system not initialized
B0000502	CryptoServer module SMOS
	file section
	the file is already opened
B0000503	CryptoServer module SMOS
	file section
	file name is not allowed

Code	Description
B0000504	CryptoServer module SMOS
	file section
	invalid open mode
B0000505	CryptoServer module SMOS
	file section
	the directory does not exist
B0000506	CryptoServer module SMOS
	file section
	the file does not exist
B0000507	CryptoServer module SMOS
	file section
	the file doesn't / already exists
B0000508	CryptoServer module SMOS
	file section
	invalid parameter
B000050A	CryptoServer module SMOS
	file section
-	the file isn't open for access mode
B000050B	CryptoServer module SMOS
	file section
	position offset not allowed
B000050C	CryptoServer module SMOS
	file section
	no more memory space available
B000050D	CryptoServer module SMOS
	file section
	no bad block table
B000050E	CryptoServer module SMOS
	file section
	invalid magic tag

Code	Description
B0000510	CryptoServer module SMOS
	file section
	flash file device is still busy
B0000511	CryptoServer module SMOS
	file section
	flash file device replies an error
B0000513	CryptoServer module SMOS
	file section
	illegal page address
B0000514	CryptoServer module SMOS
	file section
	page parity error
B0000515	CryptoServer module SMOS
	file section
	file system is read only
B0000516	CryptoServer module SMOS
	file section
	bad file handle
B0000517	CryptoServer module SMOS
	file section
	file system full
B0000518	CryptoServer module SMOS
	file section
	file table full
B0000519	CryptoServer module SMOS
	file section
	file corrupted
B000051A	CryptoServer module SMOS
	file section
	different file systems

Code	Description
B000051B	CryptoServer module SMOS
	file section
	bad file system type, can't mount
B000051C	CryptoServer module SMOS
	file section
	too many bad blocks, giving up
B000051D	CryptoServer module SMOS
	file section
	detected bad block in flash file
B000051E	CryptoServer module SMOS
	file section
	bad flash page geometry
B000051F	CryptoServer module SMOS
	file section
	too many open file handles
B00006xx	CryptoServer module SMOS
	task section
B0000601	CryptoServer module SMOS
	task section
	stack overflow
B0000602	CryptoServer module SMOS
	task section
	stack corrupted
B0000603	CryptoServer module SMOS
	task section
	buffer size to small
B0000604	CryptoServer module SMOS
	task section
	memory allocation failed
B00007xx	CryptoServer module SMOS
	AUDIT section

B0000700 CryptoServer module SMOS  AUDIT section  Audit file does not exist  B0000701 CryptoServer module SMOS  AUDIT section	
Audit file does not exist  B0000701 CryptoServer module SMOS	
B0000701 CryptoServer module SMOS	
AUDIT section	
Audit files full	
B0000702 CryptoServer module SMOS	
AUDIT section	
File system full	
B0000703 CryptoServer module SMOS	
AUDIT section	
Buffer too small	
B0000704 CryptoServer module SMOS	
AUDIT section	
Memory allocation failed	
B0000705 CryptoServer module SMOS	
AUDIT section	
Invalid configuration item	
B0000706 CryptoServer module SMOS	
AUDIT section	
Configuration value out of range	
B0000707 CryptoServer module SMOS	
AUDIT section	
Invalid parameter value	
B0000708 CryptoServer module SMOS	
AUDIT section	
Invalid audit handle	
B00008xx CryptoServer module SMOS	_
MDL section	

Code	Description
B0000801	CryptoServer module SMOS
	MDL section
	Error during memory allocation
B0000802	CryptoServer module SMOS
	MDL section
	Invalid input parameter
B0000803	CryptoServer module SMOS
	MDL section
	module already exists
B0000804	CryptoServer module SMOS
	MDL section
	module table full
B0000805	CryptoServer module SMOS
	MDL section
	illegall parameter passed
B0000806	CryptoServer module SMOS
	MDL section
	event not reached
B0000807	CryptoServer module SMOS
	MDL section
	module not found
B0000808	CryptoServer module SMOS
	MDL section
	can't write module to SDRAM directory
B0000809	CryptoServer module SMOS
	MDL section
	bad signed licence file
B000080A	CryptoServer module SMOS
	MDL section
	can't read bl_ini file

Code	Description
B000080B	CryptoServer module SMOS
	MDL section
	SLF parameter not found
B000080C	CryptoServer module SMOS
	MDL section
	invalid MTC file
B000080D	CryptoServer module SMOS
	MDL section
	invalid MMC file
B000080E	CryptoServer module SMOS
	MDL section
	No MTC signature present
B000080F	CryptoServer module SMOS
	MDL section
	Config parameter not found
B0000810	CryptoServer module SMOS
	MDL section
	Module does not match hardware type
B0000811	CryptoServer module SMOS
	MDL section
	invalid MSC file
B0000812	CryptoServer module SMOS
	MDL section
	MSC verification failed
B0000813	CryptoServer module SMOS
	MDL section
	Function not supported
B0000814	CryptoServer module SMOS
	MDL section
	Function not available

Code	Description
B00009xx	CryptoServer module SMOS
	memory section
B0000901	CryptoServer module SMOS
	memory section
	illegal memory type
B0000902	CryptoServer module SMOS
	memory section
	corrupted memory structure
B0000903	CryptoServer module SMOS
	memory section
	buffer size too small
B0000904	CryptoServer module SMOS
	memory section
	bad memory address
B0000Axx	CryptoServer module SMOS
	string section
B0000A01	CryptoServer module SMOS
	string section
	memory allocation failed
B0000Bxx	CryptoServer module SMOS
	Config section
B0000B01	CryptoServer module SMOS
	Config section
	memory allocation failed
B0000B02	CryptoServer module SMOS
	Config section
	invalid parameter
B0000B03	CryptoServer module SMOS
	Config section
	invalid handle

Code	Description
B0000B04	CryptoServer module SMOS
	Config section
	bad config file
B0000B05	CryptoServer module SMOS
	Config section
	section not found
B0000B06	CryptoServer module SMOS
	Config section
	item not found
B00010xx	CryptoServer module SMOS
	PCI section
B0001000	CryptoServer module SMOS
	PCI section
	DMA timeout
B0001001	CryptoServer module SMOS
	PCI section
-	request canceled
B0001002	CryptoServer module SMOS
	PCI section
	MBR read timeout
B0001003	CryptoServer module SMOS
	PCI section
	MBR write timeout
B0001004	CryptoServer module SMOS
	PCI section
	bad MBR command
B0001005	CryptoServer module SMOS
	PCI section
	rx crc error

Code	Description
B0001006	CryptoServer module SMOS
	PCI section
	function not implemented
B0001007	CryptoServer module SMOS
	PCI section
	shutdown request received
B0001008	CryptoServer module SMOS
	PCI section
	memory allocation failed
B0001009	CryptoServer module SMOS
	PCI section
	bad sequence counter
B000100A	CryptoServer module SMOS
	PCI section
	read timeout
B000100B	CryptoServer module SMOS
	PCI section
	write timeout
B000100C	CryptoServer module SMOS
	PCI section
	block length error
B000100D	CryptoServer module SMOS
	PCI section
	socket error
B000100E	CryptoServer module SMOS
	PCI section
	bad state for receive
B00011xx	CryptoServer module SMOS
	RTC section

Code	Description
B0001100	CryptoServer module SMOS
	RTC section
	RTC failed
B0001101	CryptoServer module SMOS
	RTC section
	RTC not initialized
B0001102	CryptoServer module SMOS
	RTC section
	Bad parameter
B00013xx	CryptoServer module SMOS
	CRYPT section
B0001301	CryptoServer module SMOS
	CRYPT section
	Error during memory allocation
B0001302	CryptoServer module SMOS
	CRYPT section
	Invalid input parameter
B0001303	CryptoServer module SMOS
	CRYPT section
	Error reading master key
B0001304	CryptoServer module SMOS
	CRYPT section
	no internal access to CS2 master key
B0001305	CryptoServer module SMOS
	CRYPT section
	CS2 master key corrupted
B0001306	CryptoServer module SMOS
	CRYPT section
	Error updating master key

Code	Description
B0001307	CryptoServer module SMOS
	CRYPT section
	Function not supported
B0001308	CryptoServer module SMOS
	CRYPT section
	Random number generator failed
B0001309	CryptoServer module SMOS
	CRYPT section
	SHA-512 Known Answer Test failed
B0001310	CryptoServer module SMOS
	CRYPT section
	Random number generator timeout
B0001311	CryptoServer module SMOS
	CRYPT section
	Known answer test failed
B0001312	CryptoServer module SMOS
	CRYPT section
	Random Number Generator is not initialized
B0001313	CryptoServer module SMOS
	CRYPT section
	Given security strength not supported
B0001314	CryptoServer module SMOS
	CRYPT section
	Max number of requested randombits per call exceeded
B0001315	CryptoServer module SMOS
	CRYPT section
	Prediction resistance not supported for current handle
B0001316	CryptoServer module SMOS
	CRYPT section
	Random Number Generator needs to be reseeded

Code	Description
B0002xxx	CryptoServer module SMOS
	COFF section
B0002001	CryptoServer module SMOS
	COFF section
	relocation error (low 16 bits)
B0002002	CryptoServer module SMOS
	COFF section
	relocation error (high 16 bits)
B0002003	CryptoServer module SMOS
	COFF section
	relocation error (PC relative)
B0002004	CryptoServer module SMOS
	COFF section
	relocation error (long)
B0002005	CryptoServer module SMOS
	COFF section
-	can't allocate memory
B0002006	CryptoServer module SMOS
	COFF section
	bad number of section headers
B0002007	CryptoServer module SMOS
	COFF section
	multiple BSS segments
B0002008	CryptoServer module SMOS
	COFF section
	multiple CINIT segments
B0002009	CryptoServer module SMOS
	COFF section
	missing data in segment

Code	Description
B000200A	CryptoServer module SMOS
	COFF section
	bad entry function
B000200B	CryptoServer module SMOS
	COFF section
	missing symbol table
B000200C	CryptoServer module SMOS
	COFF section
	bad relocation data
B000200D	CryptoServer module SMOS
	COFF section
	bad section number in relocation data
B000200E	CryptoServer module SMOS
	COFF section
	bad displacement in relocation data
B000200F	CryptoServer module SMOS
	COFF section
	bad symbol index in relocation data
B0002010	CryptoServer module SMOS
	COFF section
	bad relocation type
B0002011	CryptoServer module SMOS
	COFF section
	bad coff file header
B0002012	CryptoServer module SMOS
	COFF section
	missing information in coff file
B0002013	CryptoServer module SMOS
	COFF section
	BSS segment is not empty

Code	Description
B0002014	CryptoServer module SMOS
	COFF section
	CINIT segment is not empty
B0002015	CryptoServer module SMOS
	COFF section
	module does not match CPU type
B0002016	CryptoServer module SMOS
	COFF section
	bad relocation target address
B0002017	CryptoServer module SMOS
	COFF section
	symbol stack overflow
B0002018	CryptoServer module SMOS
	COFF section
	relocation error (USTFLD)
B0002019	CryptoServer module SMOS
	COFF section
	relocation error (XSTFLD)
B0003xxx	CryptoServer module SMOS
	USB section
B0003001	CryptoServer module SMOS
	USB section
	memory allocation failed
B0003002	CryptoServer module SMOS
	USB section
	invalid parameter
B0003003	CryptoServer module SMOS
	USB section
	USB not supported

Code	Description
B0003004	CryptoServer module SMOS
	USB section
	initialization of host controller failed
B0003005	CryptoServer module SMOS
	USB section
	device is not connected
B0003006	CryptoServer module SMOS
	USB section
	invalid device state
B0003007	CryptoServer module SMOS
	USB section
	timeout occured
B0003008	CryptoServer module SMOS
	USB section
	NAK received
B0003009	CryptoServer module SMOS
	USB section
	protocol error
B000300A	CryptoServer module SMOS
	USB section
	ID table is full
B000300B	CryptoServer module SMOS
	USB section
	item not found
B000300C	CryptoServer module SMOS
	USB section
	invalid data length
B00031xx	CryptoServer module SMOS
	transaction error
B00032xx	CryptoServer module SMOS
	libusb

Code	Description
B00050xx	CryptoServer module SMOS
	panic message
B0005001	CryptoServer module SMOS
	panic message
	Can't start bootloader (CRC)
B0005002	CryptoServer module SMOS
	panic message
	Can't start bootloader (SDRAM error)
B000500B	CryptoServer module SMOS
	panic message
	PCI interface closed
B000500C	CryptoServer module SMOS
	panic message
	memory corruption detected
B00053xx	CryptoServer module SMOS
	shutdown message
B0005306	CryptoServer module SMOS
	shutdown message
	High temperature
B000530A	CryptoServer module SMOS
	shutdown message
	Alarm reseted
B000530E	CryptoServer module SMOS
	shutdown message
	CryptoServer cleared
B0005344	CryptoServer module SMOS
	shutdown message
	CryptoServer halted

## **B001**xxxx — CryptoServer module FIPS140

Code	Description
B0010001	CryptoServer module FIPS140
	invalid module version
B0010002	CryptoServer module FIPS140
	illegal firmware module in FIPS mode
B0010003	CryptoServer module FIPS140
	missing approved module
B0010004	CryptoServer module FIPS140
	approved module initialization failed
B0010010	CryptoServer module FIPS140
	known answer test of DES failed
B0010011	CryptoServer module FIPS140
	known answer test of RSA failed
B0010012	CryptoServer module FIPS140
	known answer test of AES failed
B0010013	CryptoServer module FIPS140
	pair-wise consistency test of ECDSA failed
B0010014	CryptoServer module FIPS140
	known answer test of HASH failed
B0010020	CryptoServer module FIPS140
	known answer test for AES encrypt/decrypt failed
B0010021	CryptoServer module FIPS140
	known answer test for AES CBC-MAC failed
B0010022	CryptoServer module FIPS140
	known answer test for AES CMAC failed
B0010023	CryptoServer module FIPS140
	known answer test for AES GCM failed
B0010024	CryptoServer module FIPS140
	known answer test for AES OFB failed

Code	Description
B0010025	CryptoServer module FIPS140
	known answer test for AES GMAC failed
B0010030	CryptoServer module FIPS140
	known answer test for RSA sign/verify failed
B0010031	CryptoServer module FIPS140
	pair-wise consistency test for RSA encrypt/decrypt failed
B0010040	CryptoServer module FIPS140
	known answer test for HMAC failed
B0010050	CryptoServer module FIPS140
	pair-wise consistency test for DSA sign/verify failed
B0010060	CryptoServer module FIPS140
	known answer test for ECC CDH failed
B0010070	CryptoServer module FIPS140
	known answer test for KDF_800108 failed
B0010080	CryptoServer module FIPS140
	known answer tests for (internally used only) utility functions failed
B0010100	CryptoServer module FIPS140
	bad command length
B0010200	CryptoServer module FIPS140
	function called with invalid parameter

### B006xxxx - Bootloader

Code	Description
B0060000	Bootloader
	invalid parameter
B0060001	Bootloader
	item not found
B0060002	Bootloader
	invalid item length
B0060003	Bootloader
	buffer size too small
B006001x	Bootloader
	command section
B0060010	Bootloader
	command section
	bad length within format string
B0060011	Bootloader
	command section
	bad parameter structure
B0060012	Bootloader
	command section
	bad format string
B0060013	Bootloader
	command section
	bad format
B0060014	Bootloader
	command section
	timeout occured
B0060015	Bootloader
	command section
	command is not allowed

Code	Description
B0060016	Bootloader
	command section
	invalid command header
B0060017	Bootloader
	command section
	invalid command length
B0060018	Bootloader
	command section
	invalid function code
B0060019	Bootloader
	command section
	invalid sub-function code
B006001A	Bootloader
	command section
	invalid challenge
B006001B	Bootloader
	command section
	command is not allowed in FIPS mode
B006001C	Bootloader
	command section
	command not available in current configuration
B006003x	Bootloader
	module section
B0060031	Bootloader
	module section
	invalid MTC Header
B0060032	Bootloader
	module section
	no MTC signature present

B0060033 Bootloader module section invalid MMC Header  B0060034 Bootloader module section no MMC signature present  B0060035 Bootloader module section MMC hash compare failed  B0060036 Bootloader module section invalid MSC Header
invalid MMC Header  B0060034 Bootloader module section no MMC signature present  B0060035 Bootloader module section MMC hash compare failed  B0060036 Bootloader module section
B0060034 Bootloader module section no MMC signature present  B0060035 Bootloader module section MMC hash compare failed  B0060036 Bootloader module section
module section no MMC signature present  B0060035 Bootloader module section MMC hash compare failed  B0060036 Bootloader module section
no MMC signature present  B0060035 Bootloader module section MMC hash compare failed  B0060036 Bootloader module section
B0060035 Bootloader module section MMC hash compare failed  B0060036 Bootloader module section
module section  MMC hash compare failed  B0060036 Bootloader  module section
MMC hash compare failed  B0060036 Bootloader  module section
B0060036 Bootloader module section
module section
invalid MSC Header
B0060037 Bootloader
module section
MSC hash compare failed
B0060038 Bootloader
module section
no module info found
B006004x Bootloader
coff section
B0060040 Bootloader
coff section
invalid coff name
B0060041 Bootloader
coff section
invalid coff header
B0060042 Bootloader
coff section
invalid header magic

Code	Description
B0060043	Bootloader
	coff section
	invalid header size
B0060044	Bootloader
	coff section
	invalid section
B0060045	Bootloader
	coff section
	invalid relocation of section
B0060046	Bootloader
	coff section
	invalid run address
B0060047	Bootloader
	coff section
	invalid load address
B0060048	Bootloader
	coff section
	invalid section memory
B0060049	Bootloader
	coff section
	invalid opt header
B006004A	Bootloader
	coff section
	invalid size
B006004B	Bootloader
	coff section
	invalid address
B006004C	Bootloader
	coff section
	invalid MTC

Code	Description
B006004D	Bootloader
	coff section
	invalid entry point
B006004E	Bootloader
	coff section
	invalid CPU type
B006004F	Bootloader
	coff section
	invalid coff file
B006005x	Bootloader
	signature secture
B0060050	Bootloader
	signature secture
	invalid pkcs1 padding
B0060051	Bootloader
	signature secture
	hash compare failed
B006006x	Bootloader
	RSA section
B0060060	Bootloader
	RSA section
	rsa result overflow
B0060061	Bootloader
	RSA section
	modulus is zero
B0060062	Bootloader
	RSA section
	modulus is smaller than operand
B006007x	Bootloader
	file section

Code	Description
B0060071	Bootloader
	file section
	error formating flash file
B0060072	Bootloader
	file section
	flash file formated succesfully, now looping forever
B0060073	Bootloader
	file section
	Initialization of file system failed
B0060074	Bootloader
	file section
	file already exists
B0060075	Bootloader
	file section
	invalid filename
B0060076	Bootloader
	file section
	invalid file type
B0060077	Bootloader
	file section
	invalid file size
B0060078	Bootloader
	file section
	file not found
B006007A	Bootloader
	file section
	file open error
B006007B	Bootloader
	file section
	file read error

B006007C Bootloader file section file write error	
file write error	
B006007D Bootloader	
file section	
file close error	
B006008x Bootloader	
PCI section	
B0060080 Bootloader	
PCI section	
timeout occured	
B0060081 Bootloader	
PCI section	
protocol error	
B0060082 Bootloader	
PCI section	
length error	
B0060083 Bootloader	
PCI section	
crc error	
B0060084 Bootloader	
PCI section	
buffer size too small	
B0060085 Bootloader	
PCI section	
invalid parameter	
B006009x Bootloader	
UID section	
B0060090 Bootloader	
UID section	
bad CRC on UID	

Code	Description
B0060091	Bootloader
	UID section
	UID not found
B0060092	Bootloader
	UID section
	Extended UID invalid
B00600Ax	Bootloader
	SL section
B00600A0	Bootloader
	SL section
	invalid device name
B00600A1	Bootloader
	SL section
	invalid handle value
B00600A2	Bootloader
	SL section
-	device is not open
B00600A3	Bootloader
	SL section
	device is already in use
B00600A4	Bootloader
	SL section
	invalid parameter
B00600A5	Bootloader
	SL section
	invalid parameter value
B00600A6	Bootloader
	SL section
	timeout

Code	Description
B00600A7	Bootloader
	SL section
	invalid crc
B00600A8	Bootloader
	SL section
	overrun error
B00600A9	Bootloader
	SL section
	parity error
B00600AA	Bootloader
	SL section
	framing error
B00600AB	Bootloader
	SL section
	data compare failed
B00600Bx	Bootloader
	MSP BSL section
B00600B1	Bootloader
	MSP BSL section
	get version failed
B00600B2	Bootloader
	MSP BSL section
	sync failed
B00600B3	Bootloader
	MSP BSL section
	erase failed
B00600B4	Bootloader
	MSP BSL section
	login failed

Code	Description
B00600B5	Bootloader
	MSP BSL section
	write failed
B00600Cx	Bootloader
	JTAG section
B00600C0	Bootloader
	JTAG section
	invalid state
B00600C1	Bootloader
	JTAG section
	unexpected IDCODE
B00600Dx	Bootloader
	Flash section
B00600D0	Bootloader
	Flash section
	timeout during flash operation
B00600D1	Bootloader
	Flash section
	error reading flash id
B00600D2	Bootloader
	Flash section
	erase failed
B00600D3	Bootloader
	Flash section
	error reading flash page
B00600D4	Bootloader
	Flash section
	error writing flash page
B00600D5	Bootloader
	Flash section
	bad page data

Code	Description
B00600D6	Bootloader
	Flash section
	invalid CRC
B00600Ex	Bootloader
	log section
B00600E0	Bootloader
	log section
	log file does not exist
B00600Fx	Bootloader
	SDRAM section
B00600F1	Bootloader
	SDRAM section
	data bus test failed
B00600F2	Bootloader
	SDRAM section
	address bus test failed
B00600F3	Bootloader
	SDRAM section
	device test failed
B006010x	Bootloader
	USB section
B0060100	Bootloader
	USB section
	NACK received
B0060101	Bootloader
	USB section
	timeout occured
B0060102	Bootloader
	USB section
	protocol error

Code	Description
B0060103	Bootloader
	USB section
	device error
B0060104	Bootloader
	USB section
	invalid parameter
B0060105	Bootloader
	USB section
	function not supported
B0060106	Bootloader
	USB section
	initialisation failed
B0060107	Bootloader
	USB section
	error connecting device
B0060108	Bootloader
	USB section
	error determining device state
B0060109	Bootloader
	USB section
	usb protocol error
B006011x	Bootloader
	flash file section
B0060111	Bootloader
	flash file section
	no config page
B0060112	Bootloader
	flash file section
	invalid flash size

Code	Description
B0060113	Bootloader
	flash file section
	no bad block table
B0060114	Bootloader
	flash file section
	invalid bad block table
B0060115	Bootloader
	flash file section
	unable to store bad block
B0060116	Bootloader
	flash file section
	page is not blank
B006012x	Bootloader
	i2c device section
B0060120	Bootloader
	i2c device section
	one parameter is wrong
B0060121	Bootloader
	i2c device section
	got no acknowledge after sending a byte
B0060122	Bootloader
	i2c device section
	device does not exist
B006013x	Bootloader
	XSVF section
B0060131	Bootloader
	XSVF section
	unknown error
B0060132	Bootloader
	XSVF section
	TDO mismatch

B0060133 Bootloader XSVF section TDO mismatch after max retries  B0060134 Bootloader XSVF section illegal command  B0060135 Bootloader XSVF section illegal state  B0060136 Bootloader XSVF section buffer overflow  B006014x Bootloader SHA512 section B0060140 Bootloader SHA512 section SHA512 section SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section B0060150 Bootloader NVRAM section  B0060151 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error rewriting nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page	Code	Description
B0060134 Bootloader XSVF section illegal command  B0060135 Bootloader XSVF section illegal state  B0060136 Bootloader XSVF section buffer overflow  B0060140 Bootloader SHA512 section SHA512 section SHA512 section SHA512 section B0060150 Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page	B0060133	Bootloader
B0060134 Bootloader XSVF section illegal command  B0060135 Bootloader XSVF section illegal state  B0060136 Bootloader XSVF section buffer overflow  B006014x Bootloader SHA512 section B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		XSVF section
XSVF section illegal command  B0060135 Bootloader XSVF section illegal state  B0060136 Bootloader XSVF section buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060154 Bootloader NVRAM section error writing nvram page  B0060155 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		TDO mismatch after max retries
illegal command  B0060135 Bootloader XSVF section illegal state  B0060136 Bootloader XSVF section buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nyram operation  B0060151 Bootloader NVRAM section error reading nyram page  B0060152 Bootloader NVRAM section error writing nyram page  B0060153 Bootloader NVRAM section error writing nyram page  B0060153 Bootloader NVRAM section error writing nyram page	B0060134	Bootloader
B0060135 Bootloader XSVF section illegal state  B0060136 Bootloader XSVF section buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		XSVF section
XSVF section illegal state  B0060136 Bootloader XSVF section buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		illegal command
illegal state  B0060136 Bootloader  XSVF section buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page	B0060135	Bootloader
B0060136 Bootloader XSVF section buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		XSVF section
XSVF section buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		illegal state
buffer overflow  B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page	B0060136	Bootloader
B006014x Bootloader SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section		XSVF section
SHA512 section  B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section		buffer overflow
B0060140 Bootloader SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page	B006014x	Bootloader
SHA512 section SHA512 known answer test failed  B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		SHA512 section
B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error Writing nvram page	B0060140	Bootloader
B006015x Bootloader NVRAM section  B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section error writing nvram page		SHA512 section
NVRAM section  B0060150 Bootloader  NVRAM section  timeout during nvram operation  B0060151 Bootloader  NVRAM section  error reading nvram page  B0060152 Bootloader  NVRAM section  error writing nvram page  B0060153 Bootloader  NVRAM section  error Writing nvram page		SHA512 known answer test failed
B0060150 Bootloader NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section	B006015x	Bootloader
NVRAM section timeout during nvram operation  B0060151 Bootloader NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section		NVRAM section
timeout during nvram operation  B0060151 Bootloader  NVRAM section  error reading nvram page  B0060152 Bootloader  NVRAM section  error writing nvram page  B0060153 Bootloader  NVRAM section	B0060150	Bootloader
B0060151 Bootloader  NVRAM section  error reading nvram page  B0060152 Bootloader  NVRAM section  error writing nvram page  B0060153 Bootloader  NVRAM section		NVRAM section
NVRAM section error reading nvram page  B0060152 Bootloader NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section		timeout during nvram operation
error reading nvram page  B0060152 Bootloader  NVRAM section  error writing nvram page  B0060153 Bootloader  NVRAM section	B0060151	Bootloader
B0060152 Bootloader  NVRAM section  error writing nvram page  B0060153 Bootloader  NVRAM section		NVRAM section
NVRAM section error writing nvram page  B0060153 Bootloader NVRAM section		error reading nvram page
error writing nvram page  B0060153 Bootloader  NVRAM section	B0060152	Bootloader
B0060153 Bootloader  NVRAM section		NVRAM section
NVRAM section		error writing nvram page
	B0060153	Bootloader
bad page data		NVRAM section
		bad page data

Code	Description
B0060154	Bootloader
	NVRAM section
	error reading flash id
B0060155	Bootloader
	NVRAM section
	NVRAM not available in Bootloader mode
B00602xx	Bootloader
	MSP section
B0060201	Bootloader
	MSP section
	data len for communication with msp too large
B0060299	Bootloader
	MSP section
	timeout occurred
B00602A5	Bootloader
	MSP section
	invalid command
B00602BD	Bootloader
	MSP section
	invalid address
B00602C3	Bootloader
	MSP section
	invalid data
B00602DB	Bootloader
	MSP section
	invalid crc
B00604xx	Bootloader
	SPI section
B0060401	Bootloader
	SPI section
	read timeout

Code	Description
B0060402	Bootloader
	SPI section
	timeout waiting for receiver ready
B0060403	Bootloader
	SPI section
	timeout waiting for MSP ready
B0060404	Bootloader
	SPI section
	timeout waiting for MSP ready low
B0060405	Bootloader
	SPI section
	timeout waiting for RRDY
B0060500	Bootloader
	SPI section
	EXAR section
B0060501	Bootloader
	SPI section
_	timeout during pci cfg operation
B0060502	Bootloader
	SPI section
	wrong data read
B0060503	Bootloader
	SPI section
	pci interface for accelerator busy
B0060504	Bootloader
	SPI section
	no exar accelerator found
B0060511	Bootloader
	SPI section
	memory allocation failed

Code	Description
B0060512	Bootloader
	SPI section
	invalid parameter
B0060513	Bootloader
	SPI section
	invalid handle
B0060514	Bootloader
	SPI section
	bad config file
B0060515	Bootloader
	SPI section
	section not found
B0060516	Bootloader
	SPI section
	item not found
B007001F	Bootloader
	SPI section
	Wrong Function Code (included for backward compatibility)
B007001F	Bootloader
	SPI section
	Wrong Function Code (included for backward compatibility)

#### **B00Axxxx** — CryptoServer module HCE

B00A0001 CryptoServer module HCE memory allocation failed  B00A0002 CryptoServer module HCE PCI master access error (DSP)  B00A0003 CryptoServer module HCE key size not supported  B00A0004 CryptoServer module HCE exponent greater modulus  B00A0005 CryptoServer module HCE hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE PCI DMA master access error
B00A0002 CryptoServer module HCE PCI master access error (DSP)  B00A0003 CryptoServer module HCE key size not supported  B00A0004 CryptoServer module HCE exponent greater modulus  B00A0005 CryptoServer module HCE hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
B00A0003 CryptoServer module HCE key size not supported  B00A0004 CryptoServer module HCE exponent greater modulus  B00A0005 CryptoServer module HCE hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A0000 CryptoServer module HCE Self-test failed  B00A0000 CryptoServer module HCE Self-test failed  B00A0000 CryptoServer module HCE Module LNA not found  B00A0000 CryptoServer module HCE
B00A0003 CryptoServer module HCE key size not supported  B00A0004 CryptoServer module HCE exponent greater modulus  B00A0005 CryptoServer module HCE hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A0000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
key size not supported  B00A0004
B00A0004 CryptoServer module HCE exponent greater modulus  B00A0005 CryptoServer module HCE hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
exponent greater modulus  B00A0005 CryptoServer module HCE hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
B00A0005 CryptoServer module HCE hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
hardware engine timeout  B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
B00A0006 CryptoServer module HCE result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
result too big for buffer  B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
B00A0007 CryptoServer module HCE illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
illegal sizes of prime  B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
B00A0008 CryptoServer module HCE data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
data size too big (greater than modulus)  B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
B00A0009 CryptoServer module HCE Self-test failed  B00A000A CryptoServer module HCE Module LNA not found  B00A000B CryptoServer module HCE
Self-test failed  B00A000A CryptoServer module HCE  Module LNA not found  B00A000B CryptoServer module HCE
B00A000A CryptoServer module HCE  Module LNA not found  B00A000B CryptoServer module HCE
Module LNA not found  B00A000B CryptoServer module HCE
B00A000B CryptoServer module HCE
PCI DMA master access error
B00A000C CryptoServer module HCE
No driver module found
B00A000D CryptoServer module HCE
Driver does not allow routing from HCE to driver.
B00A000E CryptoServer module HCE
invalid parameter

Code	Description
B00A000F	CryptoServer module HCE
	function is not supported
B00A0010	CryptoServer module HCE
	Signature verification failed
B00A80xx	CryptoServer module HCE
	hardware engine error

#### **B00Dxxxx** — CryptoServer module EXAR

Code	Description
B00D0001	CryptoServer module EXAR
	no Marvell bridge detected
B00D0002	CryptoServer module EXAR
	no Exar chip detected
B00D0003	CryptoServer module EXAR
	invalid parameter
B00D0004	CryptoServer module EXAR
	timeout
B00D0005	CryptoServer module EXAR
	memory allocation failed
B00D0006	CryptoServer module EXAR
	selftest failed
B00D0007	CryptoServer module EXAR
	insufficient buffer size
B00D0008	CryptoServer module EXAR
	invalid command state
B00D0009	CryptoServer module EXAR
	invalid parameter length
B00D000A	CryptoServer module EXAR
	sign failed
B00D000B	CryptoServer module EXAR
	signature verification failed
B00D000C	CryptoServer module EXAR
	key size not supported
B00D000D	CryptoServer module EXAR
	data size too big
B00D0010	CryptoServer module EXAR
	address error

Code	Description
B00D0011	CryptoServer module EXAR
	ECC error
B00D0012	CryptoServer module EXAR
	all engines are busy
B00D0020	CryptoServer module EXAR
	PCI is busy
B00D0021	CryptoServer module EXAR
	PCI timeout
B00D0022	CryptoServer module EXAR
	PCI access error

#### **B00Exxxx** — CryptoServer module HCE

B00E0001 CryptoServer module HCE memory allocation failed  B00E0002 CryptoServer module HCE PCI master access error (DSP)  B00E0003 CryptoServer module HCE key size not supported  B00E0004 CryptoServer module HCE exponent greater modulus  B00E0005 CryptoServer module HCE hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE hardware engine error	Code	Description
B00E0002 CryptoServer module HCE PCI master access error (DSP)  B00E0003 CryptoServer module HCE key size not supported  B00E0004 CryptoServer module HCE exponent greater modulus  B00E0005 CryptoServer module HCE hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0001	CryptoServer module HCE
PCI master access error (DSP)  B00E0003 CryptoServer module HCE key size not supported  B00E0004 CryptoServer module HCE exponent greater modulus  B00E0005 CryptoServer module HCE hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE		memory allocation failed
B00E0003 CryptoServer module HCE key size not supported  B00E0004 CryptoServer module HCE exponent greater modulus  B00E0005 CryptoServer module HCE hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0002	CryptoServer module HCE
key size not supported  B00E0004 CryptoServer module HCE exponent greater modulus  B00E0005 CryptoServer module HCE hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE		PCI master access error (DSP)
B00E0004 CryptoServer module HCE exponent greater modulus  B00E0005 CryptoServer module HCE hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0003	CryptoServer module HCE
exponent greater modulus  B00E0005		key size not supported
B00E0005 CryptoServer module HCE hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0004	CryptoServer module HCE
hardware engine timeout  B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE  CryptoServer module HCE CryptoServer module HCE CryptoServer module HCE CryptoServer module HCE CryptoServer module HCE CryptoServer module HCE CryptoServer module HCE CryptoServer module HCE		exponent greater modulus
B00E0006 CryptoServer module HCE result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0005	CryptoServer module HCE
result too big for buffer  B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE		hardware engine timeout
B00E0007 CryptoServer module HCE illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0006	CryptoServer module HCE
illegal sizes of prime  B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE		result too big for buffer
B00E0008 CryptoServer module HCE data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0007	CryptoServer module HCE
data size too big (greater than modulus)  B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE		illegal sizes of prime
B00E0009 CryptoServer module HCE Self-test failed  B00E000A CryptoServer module HCE Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0008	CryptoServer module HCE
Self-test failed  B00E000A CryptoServer module HCE  Module LNA not found  B00E000B CryptoServer module HCE  PCI DMA master access error  B00E80xx CryptoServer module HCE		data size too big (greater than modulus)
B00E000A CryptoServer module HCE  Module LNA not found  B00E000B CryptoServer module HCE  PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E0009	CryptoServer module HCE
Module LNA not found  B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE		Self-test failed
B00E000B CryptoServer module HCE PCI DMA master access error  B00E80xx CryptoServer module HCE	B00E000A	CryptoServer module HCE
PCI DMA master access error  B00E80xx CryptoServer module HCE		Module LNA not found
B00E80xx CryptoServer module HCE	B00E000B	CryptoServer module HCE
		PCI DMA master access error
hardware engine error	B00E80xx	CryptoServer module HCE
		hardware engine error

# **B050xxxx** — CryptoServer module PK

B0500001 CryptoServer module PK invalid parameter	
invalid parameter	
B0500002 CryptoServer module PK	
memory allocation failed	
B0500003 CryptoServer module PK	
unknown distinguished nar	ne type
B0500004 CryptoServer module PK	
invalid distinguished name	(value or length)
B0500005 CryptoServer module PK	
invalid time format	
B0500006 CryptoServer module PK	
unknown / unsupported ke	y type
B0500007 CryptoServer module PK	
unknown / unsupported sig	nature algorithm
B0500008 CryptoServer module PK	
unknown / unsupported ha	sh algorithm
B0500009 CryptoServer module PK	
invalid / unsupported version	on
B050000A CryptoServer module PK	
unknown / unsupported Pk	CCS7 content type
B050000B CryptoServer module PK	
no PKCS7 version found	
B050000C CryptoServer module PK	
unknown PKCS7 element t	ype
B050000D CryptoServer module PK	
element type SIGNATURE r	not found
B050000E CryptoServer module PK	
element type ENVELOPED I	not found

Code	Description
B050000F	CryptoServer module PK
	element type CERT not found
B0500010	CryptoServer module PK
	element type AUTH_ATT not found
B0500011	CryptoServer module PK
	element type UNAUTH_ATT not found
B0500012	CryptoServer module PK
	element type SIG_TIME not found
B0500013	CryptoServer module PK
	element type DATA not found
B0500014	CryptoServer module PK
	no signer certificate given
B0500015	CryptoServer module PK
	no data or hash given to perform sign / verify operation
B0500016	CryptoServer module PK
	invalid PKCS7 content type
B0500017	CryptoServer module PK
	no digest algorithm in PKCS7 data found
B0500018	CryptoServer module PK
	no signer infos found
B0500019	CryptoServer module PK
	no issuer / serial number found
B050001A	CryptoServer module PK
	number of PK_P7_ELEM too small
B050001B	CryptoServer module PK
	invalid signer reference
B050001C	CryptoServer module PK
	content type is not SignedData
B050001D	CryptoServer module PK
	content type is not Enveloped

Code	Description
B050001E	CryptoServer module PK
	digestEncryptionAlgorithm doesn't match signer certificate key type
B050001F	CryptoServer module PK
	signature verfication failed
B0500020	CryptoServer module PK
	no recipient certificate given
B0500021	CryptoServer module PK
	unknown / unsupported encryption key type
B0500022	CryptoServer module PK
	multiple recipients not supported
B0500023	CryptoServer module PK
	given certificate doesn't match certificate in PKCS7 structure
B0500024	CryptoServer module PK
	given key doesn't match key encryption algorithm
B0500025	CryptoServer module PK
	no key encryption algorithm identifier found
B0500026	CryptoServer module PK
	no content type found
B0500027	CryptoServer module PK
	no content encryption algorithm identifier found
B0500028	CryptoServer module PK
	invalid attribute structure
B0500029	CryptoServer module PK
	given buffer / struct doesn't contain enough space for this operation
B0500030	CryptoServer module PK
	Firmware module AES not loaded
B0500031	CryptoServer module PK
	unknown attribute type
B0500032	CryptoServer module PK
	CRL issuer doesn't match certificate's subject / issuer

Code	Description
B0500033	CryptoServer module PK
	requested attribute not available (optional)
B0500034	CryptoServer module PK
	bad CRL format
B0500035	CryptoServer module PK
	CRL is not yet valid
B0500036	CryptoServer module PK
	partial CRL verification not initialized
B0500037	CryptoServer module PK
	algorithm oid of crl header and trailer differ
B0500040	CryptoServer module PK
	unsupported time format
B0500041	CryptoServer module PK
	given time format contains century < 2000
B0500042	CryptoServer module PK
	indefinite length not supportet
B0500043	CryptoServer module PK
	Firmware module ECDSA not loaded
B0500050	CryptoServer module PK
	invalid signer / invalid signer information
B0500051	CryptoServer module PK
	invalid signer structure (ASN.1 error)

# **B061**xxxx — CryptoServer module CTS

Code	Description
B0610001	CryptoServer module CTS
	Wrong command length
B0610002	CryptoServer module CTS
	memory allocation error
B0610003	CryptoServer module CTS
	Invalid key index
B0610004	CryptoServer module CTS
	Signature Algorithm unsupported (hash or signing)
B0610005	CryptoServer module CTS
	key index already exists in database
B0610006	CryptoServer module CTS
	selected key is not enabled for signing
B0610007	CryptoServer module CTS
	No key for the imported certificate available
B0610008	CryptoServer module CTS
	certification validity expired
B0610009	CryptoServer module CTS
	certificate is not yet valid
B061000A	CryptoServer module CTS
	permission denied
B061000B	CryptoServer module CTS
	No certificate to the according key imported
B061000C	CryptoServer module CTS
	mbk from MBK module not found
B061000D	CryptoServer module CTS
	MBK module not loaded
B061000E	CryptoServer module CTS
	RSA key token length invalid

Code	Description
B061000F	CryptoServer module CTS
	Calculated hash doesn't match given one
B0610010	CryptoServer module CTS
	Unknown DN component
B0610011	CryptoServer module CTS
	Given ASN1_ITEM of a DN is no struct
B0610012	CryptoServer module CTS
	Issuer and Subject not the same
B0610013	CryptoServer module CTS
	(ASN1) Tag unknown
B0610014	CryptoServer module CTS
	Given issuer / subject not found
B0610015	CryptoServer module CTS
	Certificate already exist
B0610016	CryptoServer module CTS
	TimeStamp ASN.1 structure not correct
B0610017	CryptoServer module CTS
	Given certificate not equal to the one in the database
B0610018	CryptoServer module CTS
	Given delay to set the new time is too big
B0610019	CryptoServer module CTS
	Too many time adjustments on this day
B061001A	CryptoServer module CTS
	TSA name contained in timestamp doesn't match signer name

# **B064**xxxx — CryptoServer module PKCS11

Code	Description
B0640001	CryptoServer module PKCS11
	corrupted object data structure
B0640002	CryptoServer module PKCS11
	bad arguments
B0640003	CryptoServer module PKCS11
	object has to many attributes
B0640004	CryptoServer module PKCS11
	too many concurrent applications
B0640005	CryptoServer module PKCS11
	bad application reference
B0640006	CryptoServer module PKCS11
	object handle overflow
B0640007	CryptoServer module PKCS11
	bad public exponent
B0640008	CryptoServer module PKCS11
	bad modulus
B0640009	CryptoServer module PKCS11
	AES module not found
B064000A	CryptoServer module PKCS11
	ECA/ECDSA modules not found
B064000B	CryptoServer module PKCS11
	access denied
B064000C	CryptoServer module PKCS11
	corrupted slot data structure
B064000D	CryptoServer module PKCS11
	MBK module not found
B064000E	CryptoServer module PKCS11
	no MBK key loaded

Code	Description
B064000F	CryptoServer module PKCS11
	invalid backup
B0640010	CryptoServer module PKCS11
	PKCS#11 service terminated
B0640011	CryptoServer module PKCS11
	slot not empty
B0640012	CryptoServer module PKCS11
	DSA module not found
B0640013	CryptoServer module PKCS11
	application timeout
B0640014	CryptoServer module PKCS11
	validity period has expired
B0648xxx	CryptoServer module PKCS11
	PKCS#11 standard error

# **B068xxxx** — CryptoServer module CXI

Code	Description
B0680000	CryptoServer module CXI
	memory allocation error
B0680001	CryptoServer module CXI
	permission denied
B0680002	CryptoServer module CXI
	buffer size too small
B0680003	CryptoServer module CXI
	function not supported
B0680004	CryptoServer module CXI
	MBK firmware module not loaded
B0680005	CryptoServer module CXI
	invalid parameter tag
B0680006	CryptoServer module CXI
	invalid parameter length
B0680007	CryptoServer module CXI
	invalid parameter value
B0680008	CryptoServer module CXI
	invalid flags
B0680009	CryptoServer module CXI
	SFC is reserved for further use
B068000A	CryptoServer module CXI
	an internal error occured
B068000B	CryptoServer module CXI
	invalid MBK key type
B068000C	CryptoServer module CXI
	validity period has expired
B0680010	CryptoServer module CXI
	property has to be absent

Code	Description
B0680011	CryptoServer module CXI
	unknown property
B0680012	CryptoServer module CXI
	property not found
B0680013	CryptoServer module CXI
	property already exists
B0680014	CryptoServer module CXI
	property is read-only
B0680015	CryptoServer module CXI
	property is protected
B0680016	CryptoServer module CXI
	invalid property tag
B0680017	CryptoServer module CXI
	invalid property value
B0680018	CryptoServer module CXI
	invalid property length
B0680019	CryptoServer module CXI
	property is sensitive
B068001A	CryptoServer module CXI
	property doesn't match given template
B068001B	CryptoServer module CXI
	property only valid for objects in a group
B0680020	CryptoServer module CXI
	invalid key algo
B0680021	CryptoServer module CXI
	invalid key size
B0680022	CryptoServer module CXI
	invalid key tag
B0680023	CryptoServer module CXI
	invalid key component

Code	Description
B0680024	CryptoServer module CXI
	invalid format of key blob
B0680025	CryptoServer module CXI
	invalid key type
B0680026	CryptoServer module CXI
	invalid mac of key blob
B0680027	CryptoServer module CXI
	invalid key name
B0680028	CryptoServer module CXI
	invalid key token
B0680029	CryptoServer module CXI
	missing key component
B068002B	CryptoServer module CXI
	key export is denied
B068002C	CryptoServer module CXI
	key import is denied
B068002D	CryptoServer module CXI
	mechanism not allowed
B068002E	CryptoServer module CXI
	invalid block length
B068002F	CryptoServer module CXI
	illegal key usage
B0680030	CryptoServer module CXI
	invalid padding
B0680031	CryptoServer module CXI
	invalid mechanism
B0680032	CryptoServer module CXI
	invalid IV length
B0680033	CryptoServer module CXI
	signature verification failed

Code	Description
B0680034	CryptoServer module CXI
	invalid data length
B0680035	CryptoServer module CXI
	invalid mechanism parameter
B0680040	CryptoServer module CXI
	item not found
B0680041	CryptoServer module CXI
	invalid item tag
B0680042	CryptoServer module CXI
	invalid item length
B0680043	CryptoServer module CXI
	invalid item value
B0680044	CryptoServer module CXI
	invalid number of items
B0680050	CryptoServer module CXI
	invalid file size
B0680060	CryptoServer module CXI
	enumeration was aborted
B0680061	CryptoServer module CXI
	invalid input parameter
B06801xx	CryptoServer module CXI
	FIPS mode
B0680100	CryptoServer module CXI
	FIPS mode
	function not available in FIPS mode
B0680101	CryptoServer module CXI
	FIPS mode
	mechanism not supported in FIPS mode
B0680102	CryptoServer module CXI
	FIPS mode
	object type not available in FIPS mode

Code	Description
B0680103	CryptoServer module CXI
	FIPS mode
	algorithm not available in FIPS mode
B0680104	CryptoServer module CXI
	FIPS mode
	key size not allowed in FIPS mode
B0680105	CryptoServer module CXI
	FIPS mode
	clear text key import not allowed in FIPS mode
B0680106	CryptoServer module CXI
	FIPS mode
	clear text key export not allowed in FIPS mode
B0680107	CryptoServer module CXI
	FIPS mode
	property not available in FIPS mode
B0680108	CryptoServer module CXI
	FIPS mode
	Curve not available in FIPS mode
B0680109	CryptoServer module CXI
	FIPS mode
	Key usage is restricted in FIPS mode
B06802xx	CryptoServer module CXI
	SECURE
B0680200	CryptoServer module CXI
	SECURE
	decrypt property true not allowed
B0680201	CryptoServer module CXI
	SECURE
	encrypt property true not allowed

Code	Description
B0680202	CryptoServer module CXI
	SECURE
	always sensitive property false not allowed
B0680203	CryptoServer module CXI
	SECURE
	sensitive property false not allowed
B0680204	CryptoServer module CXI
	SECURE
	wrap property true not allowed
B0680205	CryptoServer module CXI
	SECURE
	cannot use public keys for wrapping
B0680206	CryptoServer module CXI
	SECURE
	check value missing or invalid

# B081xxxx — CryptoServer module VDES

Code	Description
B0810001	CryptoServer module VDES
	length of data is not a multiple of 8 bytes
B0810002	CryptoServer module VDES
	length of key is not 8, 16, or 24
B0810003	CryptoServer module VDES
	cannot allocate memory
B0810004	CryptoServer module VDES
	key is weak
B0810005	CryptoServer module VDES
	key is semi-weak
B0810006	CryptoServer module VDES
	two of the 8byte key parts are identical
B0810007	CryptoServer module VDES
	mode is unknown
B0810008	CryptoServer module VDES
	could not get local Master Key
B0810009	CryptoServer module VDES
	unknown padding mechanism
B081000A	CryptoServer module VDES
	invalid padding
B081000B	CryptoServer module VDES
	invalid parameter
B081000C	CryptoServer module VDES
	key is possibly weak
B081000E	CryptoServer module VDES
	Zero length not allowed

#### B082xxxx — CryptoServer module PP, PIN pad driver

Code	Description
B0820001	CryptoServer module PP, PIN pad driver
	operation aborted by user
B0820002	CryptoServer module PP, PIN pad driver
	command block too long
B0820003	CryptoServer module PP, PIN pad driver
	timeout while writing to PIN pad
B0820004	CryptoServer module PP, PIN pad driver
	answer buffer too small
B0820005	CryptoServer module PP, PIN pad driver
	timeout while reading from PIN pad
B0820006	CryptoServer module PP, PIN pad driver
	IO error
B0820007	CryptoServer module PP, PIN pad driver
	connection not open
B0820008	CryptoServer module PP, PIN pad driver
	invalid parameter
B0820009	CryptoServer module PP, PIN pad driver
	bad RAPDU from smartcard
B082000A	CryptoServer module PP, PIN pad driver
	no smartcard in reader
B082000B	CryptoServer module PP, PIN pad driver
	bad PIN pad type specified
B082000C	CryptoServer module PP, PIN pad driver
	bad length of command block
B082000D	CryptoServer module PP, PIN pad driver
	protocol error
B082000E	CryptoServer module PP, PIN pad driver
	timeout while waiting for key input

Code	Description
B082000F	CryptoServer module PP, PIN pad driver
	timeout while waiting for card insertation
B0820010	CryptoServer module PP, PIN pad driver
	bad repetition of PIN entry
B0820011	CryptoServer module PP, PIN pad driver
	function is not supported
B0820012	CryptoServer module PP, PIN pad driver
	invalid parameter
B0820013	CryptoServer module PP, PIN pad driver
	access denied
B0820014	CryptoServer module PP, PIN pad driver
	bad input
B0820015	CryptoServer module PP, PIN pad driver
	no response from smartcard
B0820016	CryptoServer module PP, PIN pad driver
	no supported smartcard reader connected
B0820017	CryptoServer module PP, PIN pad driver
	not allowed in CC Endorsed Mode
B08201xx	CryptoServer module PP, PIN pad driver
	PIN pad error
B08202xx	CryptoServer module PP, PIN pad driver
	CCID Error

# **B083**xxxx — CryptoServer module CMDS, Command scheduler

Code	Description
B0830001	CryptoServer module CMDS, Command scheduler
	permission denied
B0830002	CryptoServer module CMDS, Command scheduler
	can't alloc memory
B0830003	CryptoServer module CMDS, Command scheduler
	invalid parameter
B0830004	CryptoServer module CMDS, Command scheduler
	module id already in use
B0830005	CryptoServer module CMDS, Command scheduler
	bad function code (module ID)
B0830006	CryptoServer module CMDS, Command scheduler
	function doesn't exist
B0830007	CryptoServer module CMDS, Command scheduler
	invalid user name
B0830008	CryptoServer module CMDS, Command scheduler
	illegal length of command block
B0830009	CryptoServer module CMDS, Command scheduler
	can't create task
B083000A	CryptoServer module CMDS, Command scheduler
	bad tag of command block
B083000B	CryptoServer module CMDS, Command scheduler
	bad length within format string (scanf)
B083000C	CryptoServer module CMDS, Command scheduler
_	bad format of command block
B083000D	CryptoServer module CMDS, Command scheduler
	bad parameter structure (scanf)

Code	Description
B083000E	CryptoServer module CMDS, Command scheduler
	bad format string (scanf)
B083000F	CryptoServer module CMDS, Command scheduler
	user already exists
B0830010	CryptoServer module CMDS, Command scheduler
	invalid mechanism
B0830011	CryptoServer module CMDS, Command scheduler
	no DB module present
B0830012	CryptoServer module CMDS, Command scheduler
	invalid AUTH layer command
B0830013	CryptoServer module CMDS, Command scheduler
	authentication failed
B0830014	CryptoServer module CMDS, Command scheduler
	no VRSA module present
B0830015	CryptoServer module CMDS, Command scheduler
	bad permission mask
B0830016	CryptoServer module CMDS, Command scheduler
	unknown user
B0830017	CryptoServer module CMDS, Command scheduler
	bad user attributes
B083001B	CryptoServer module CMDS, Command scheduler
	logoff failed
B083001C	CryptoServer module CMDS, Command scheduler
	logged in user can't be deleted
B083001D	CryptoServer module CMDS, Command scheduler
	bad user token (key or password)
B083001E	CryptoServer module CMDS, Command scheduler
	no VDES module present
B083001F	CryptoServer module CMDS, Command scheduler
	no UTIL module present

Code	Description
B0830020	CryptoServer module CMDS, Command scheduler
	no HASH module present
B0830021	CryptoServer module CMDS, Command scheduler
	secure messaging failed
B0830022	CryptoServer module CMDS, Command scheduler
	secure messaging session expired
B0830023	CryptoServer module CMDS, Command scheduler
	invalid secure messaging ID
B0830024	CryptoServer module CMDS, Command scheduler
	internal buffer overflow
B0830025	CryptoServer module CMDS, Command scheduler
	FIPS140 initialization failed
B0830026	CryptoServer module CMDS, Command scheduler
	mode does not match user
B0830027	CryptoServer module CMDS, Command scheduler
	invalid mode
B0830028	CryptoServer module CMDS, Command scheduler
	illegal answer buffer size
B0830029	CryptoServer module CMDS, Command scheduler
	no MBK module present
B083002A	CryptoServer module CMDS, Command scheduler
	invalid backup data
B083002B	CryptoServer module CMDS, Command scheduler
	bad entry in user DB (internal error)
B083002C	CryptoServer module CMDS, Command scheduler
	buffer size too small
B083002D	CryptoServer module CMDS, Command scheduler
	no MBK key found
B083002E	CryptoServer module CMDS, Command scheduler
	MBK type does not match

Code	Description
B083002F	CryptoServer module CMDS, Command scheduler
	no AES module present
B0830030	CryptoServer module CMDS, Command scheduler
	no HMAC algorithm available
B0830031	CryptoServer module CMDS, Command scheduler
	no ECC algorithm available
B0830032	CryptoServer module CMDS, Command scheduler
	ALARM state
B0830033	CryptoServer module CMDS, Command scheduler
	bad file 'init.key'
B0830034	CryptoServer module CMDS, Command scheduler
	Administrator must remain
B0830035	CryptoServer module CMDS, Command scheduler
	user flag not allowed
B0830036	CryptoServer module CMDS, Command scheduler
	permissions of users of same session must not differ
B0830037	CryptoServer module CMDS, Command scheduler
	error acessing NVRAM
B0830038	CryptoServer module CMDS, Command scheduler
	too many unsuccessful authentication tries
B0830039	CryptoServer module CMDS, Command scheduler
	parameter not valid in FIPS mode
B083003A	CryptoServer module CMDS, Command scheduler
	authentication mandatory in FIPS mode
B083003B	CryptoServer module CMDS, Command scheduler
	mechanism not allowed in FIPS mode
B083003C	CryptoServer module CMDS, Command scheduler
	user attributes not allowed in FIPS mode
B083003D	CryptoServer module CMDS, Command scheduler
	user flag not allowed in FIPS mode

Code	Description
B083003E	CryptoServer module CMDS, Command scheduler
	maximum of logged in/authenticated users reached
B083003F	CryptoServer module CMDS, Command scheduler
	authentication without secure messaging not allowed in FIPS mode
B0830040	CryptoServer module CMDS, Command scheduler
	static login not allowed in FIPS mode
B0830041	CryptoServer module CMDS, Command scheduler
	authentication not available in FIPS error state
B0830042	CryptoServer module CMDS, Command scheduler
	function not available in FIPS mode
B0830043	CryptoServer module CMDS, Command scheduler
	function not available in FIPS error state
B0830044	CryptoServer module CMDS, Command scheduler
	function is blocked in Administration Mode
B0830046	CryptoServer module CMDS, Command scheduler
	file for MaxAuthFailures corrupted
B0830050	CryptoServer module CMDS, Command scheduler
	static login not allowed in CC mode
B0830051	CryptoServer module CMDS, Command scheduler
	authentication not available in CC error state
B0830052	CryptoServer module CMDS, Command scheduler
	function not available in CC mode
B0830053	CryptoServer module CMDS, Command scheduler
	function not available in CC error state
B0830054	CryptoServer module CMDS, Command scheduler
	CC-CMS initialization failed
B0830055	CryptoServer module CMDS, Command scheduler
	permissions must not overlap in CC mode
B0830056	CryptoServer module CMDS, Command scheduler
	cc-cms.msc module missing in flash

Code	Description
B0830057	CryptoServer module CMDS, Command scheduler
	RSA token < 1024 bit not allowed in CC mode
B0830059	CryptoServer module CMDS, Command scheduler
	parameter not valid in CC mode
B083005A	CryptoServer module CMDS, Command scheduler
	authentication mandatory in CC mode
B083005B	CryptoServer module CMDS, Command scheduler
	mechanism not allowed in CC mode
B083005C	CryptoServer module CMDS, Command scheduler
	user attributes not allowed in CC mode
B083005D	CryptoServer module CMDS, Command scheduler
	user flag not allowed in CC mode
B083005F	CryptoServer module CMDS, Command scheduler
	authentication without secure messaging not allowed in CC mode
B0830060	CryptoServer module CMDS, Command scheduler
	DH parameter from host for sessionkey is weak
B0830061	CryptoServer module CMDS, Command scheduler
	This function is not available in this HSM configuration
B0830062	CryptoServer module CMDS, Command scheduler
	wrong version of HASH module
B0830063	CryptoServer module CMDS, Command scheduler
	illegal challenge length requested
B0830064	CryptoServer module CMDS, Command scheduler
	Mutual Authentication not available in alarm state

## **B084**xxxx — CryptoServer module VRSA

Code	Description
B0840001	CryptoServer module VRSA
	cannot allocate memory
B0840002	CryptoServer module VRSA
	buffer for result is to small
B0840003	CryptoServer module VRSA
	bad raw data value
B0840004	CryptoServer module VRSA
	modulus is not p * q
B0840006	CryptoServer module VRSA
	p is greater or equal than q
B0840009	CryptoServer module VRSA
	u is not (1/q) mod p
B084000A	CryptoServer module VRSA
	dp is not d mod (p-1)
B084000B	CryptoServer module VRSA
	dq is not d mod (q-1)
B084000C	CryptoServer module VRSA
	byte string is not a keytoken
B084000D	CryptoServer module VRSA
	component is not a member of this key token
B084000E	CryptoServer module VRSA
	component is already a member of this key token
B084000F	CryptoServer module VRSA
	value for flags is invalid
B0840010	CryptoServer module VRSA
	Invalid hash algorithm
B0840011	CryptoServer module VRSA
	Signature verification failed

Code	Description
B0840012	CryptoServer module VRSA
	Key length too small
B0840014	CryptoServer module VRSA
	modulus to small
B0840015	CryptoServer module VRSA
	bad key components P and Q
B0840016	CryptoServer module VRSA
	data size too big (greater than modulus)
B0840017	CryptoServer module VRSA
	missing component in key token
B0840018	CryptoServer module VRSA
	invalid parameter
B0840019	CryptoServer module VRSA
	gcd(p-1,e) != 1 or gcd(q-1,e) != 1
B084001A	CryptoServer module VRSA
	$d * e != 1 \mod (p-1)(q-1)$
B084001B	CryptoServer module VRSA
	function obsolete
B084001C	CryptoServer module VRSA
	key generation failed
B084001D	CryptoServer module VRSA
	invalid blinding value
B084001E	CryptoServer module VRSA
	blinding value generation failed
B084001F	CryptoServer module VRSA
	PKCS#1 decryption failed
B0840020	CryptoServer module VRSA
	invalid public exponent
B0840021	CryptoServer module VRSA
	bad length of key token

Code	Description
B0840022	CryptoServer module VRSA
	PKCS#1 encoding error
B0840023	CryptoServer module VRSA
	The pairwise consistency test failed!
B0840024	CryptoServer module VRSA
	Function is not available
B0840025	CryptoServer module VRSA
	Blinding mechanism unknown
B0840100	CryptoServer module VRSA
	bad key token in command string
B0840101	CryptoServer module VRSA
	random number request does not match (FIPS test)
B0840102	CryptoServer module VRSA
	Key length too small (FIPS140)
B0840103	CryptoServer module VRSA
	Key length too small (CC)

# **B085**xxxx — CryptoServer Module SC

Code	Description
B0850001	CryptoServer Module SC
	Bad Length of Application Name
B0850002	CryptoServer Module SC
	Card Error from "select" Command
B0850003	CryptoServer Module SC
	Card Error from "internal auth." Command
B0850004	CryptoServer Module SC
	Wrong SM Key
B0850005	CryptoServer Module SC
	Card Error from "ver. passw." Command
B0850006	CryptoServer Module SC
	Card Error from "mse" Command
B0850007	CryptoServer Module SC
	Card Error from "read record" Command
B0850008	CryptoServer Module SC
	Bad Record Length
B0850009	CryptoServer Module SC
	Record not Found
B085000A	CryptoServer Module SC
	File not Found
B085000B	CryptoServer Module SC
	Access Denid
B085000C	CryptoServer Module SC
	Bad Parameter: SFI, REC#
B085000D	CryptoServer Module SC
	Bad Data Length
B085000E	CryptoServer Module SC
	Bad Tag for SM

B085000F CryptoServer Module SC Card Error from "update record" Command  B0850010 CryptoServer Module SC Card Error from "chg. passw." Command  B0850011 CryptoServer Module SC Pasword File not Found  B0850012 CryptoServer Module SC Bad Personalization Data  B0850013 CryptoServer Module SC Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B0850010 CryptoServer Module SC Bad Certificate Format  B0850010 CryptoServer Module SC Card Error from "get data" Command  B0850010 CryptoServer Module SC Unknown Application Type  B0850010 CryptoServer Module SC Unknown Application Type  B0850010 CryptoServer Module SC This Action is not Implemented on the Found Card Type	Code	Description
B0850010 CryptoServer Module SC Card Error from "chg. passw." Command  B0850011 CryptoServer Module SC Pasword File not Found  B0850012 CryptoServer Module SC Bad Personalization Data  B0850013 CryptoServer Module SC Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B0850010 CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC Unknown Application Type	B085000F	CryptoServer Module SC
Card Error from "chg. passw." Command  B0850011 CryptoServer Module SC Pasword File not Found  B0850012 CryptoServer Module SC Bad Personalization Data  B0850013 CryptoServer Module SC Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B0850010 CryptoServer Module SC Card Error from "get data" Command  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC Unknown Application Type		Card Error from "update record" Command
B0850011 CryptoServer Module SC Pasword File not Found B0850012 CryptoServer Module SC Bad Personalization Data B0850013 CryptoServer Module SC Card Error while Personalizing B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command B0850015 CryptoServer Module SC Application not Found B0850016 CryptoServer Module SC Card Error from "read binary" Command B0850017 CryptoServer Module SC Bad PIN Length B0850018 CryptoServer Module SC Memory Allocation Error B0850019 CryptoServer Module SC Card Error from "pso" Command B0850010 CryptoServer Module SC Card Error from "get data" Command B085001B CryptoServer Module SC Card Error from "get data" Command B085001C CryptoServer Module SC Unknown Application Type B085001D CryptoServer Module SC Unknown Application Type	B0850010	CryptoServer Module SC
Pasword File not Found  B0850012 CryptoServer Module SC Bad Personalization Data  B0850013 CryptoServer Module SC Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B0850010 CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC Unknown Application Type		Card Error from "chg. passw." Command
B0850012 CryptoServer Module SC Bad Personalization Data  B0850013 CryptoServer Module SC Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B0850010 CryptoServer Module SC Card Error from "gso" Command  B0850010 CryptoServer Module SC Card Error from "gso" Command  B0850010 CryptoServer Module SC Card Error from "get data" Command  B0850010 CryptoServer Module SC Unknown Application Type  B0850010 CryptoServer Module SC Unknown Application Type	B0850011	CryptoServer Module SC
Bad Personalization Data  B0850013 CryptoServer Module SC Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC Card Error Module SC Card Error from "get data" Command		Pasword File not Found
B0850013 CryptoServer Module SC Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC CryptoServer Module SC CryptoServer Module SC Card Error from "get data" Command	B0850012	CryptoServer Module SC
Card Error while Personalizing  B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC CryptoServer Module SC Card Error from "get data" Command		Bad Personalization Data
B0850014 CryptoServer Module SC Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC CryptoServer Module SC CryptoServer Module SC Card Error from "get data" Command	B0850013	CryptoServer Module SC
Card Error from "get sessionkey" Command  B0850015 CryptoServer Module SC		Card Error while Personalizing
B0850015 CryptoServer Module SC Application not Found  B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B0850014	CryptoServer Module SC
Application not Found  B0850016		Card Error from "get sessionkey" Command
B0850016 CryptoServer Module SC Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B0850015	CryptoServer Module SC
Card Error from "read binary" Command  B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC		Application not Found
B0850017 CryptoServer Module SC Bad PIN Length  B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B0850016	CryptoServer Module SC
Bad PIN Length  CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC		Card Error from "read binary" Command
B0850018 CryptoServer Module SC Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B0850017	CryptoServer Module SC
Memory Allocation Error  B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC		Bad PIN Length
B0850019 CryptoServer Module SC Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B0850018	CryptoServer Module SC
Card Error from "pso" Command  B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC		Memory Allocation Error
B085001A CryptoServer Module SC Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B0850019	CryptoServer Module SC
Bad Certificate Format  B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC		Card Error from "pso" Command
B085001B CryptoServer Module SC Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B085001A	CryptoServer Module SC
Card Error from "get data" Command  B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC		Bad Certificate Format
B085001C CryptoServer Module SC Unknown Application Type  B085001D CryptoServer Module SC	B085001B	CryptoServer Module SC
Unknown Application Type  B085001D CryptoServer Module SC		Card Error from "get data" Command
B085001D CryptoServer Module SC	B085001C	CryptoServer Module SC
		Unknown Application Type
This Action is not Implmented on the Found Card Type	B085001D	CryptoServer Module SC
		This Action is not Implmented on the Found Card Type

Code	Description
B085001E	CryptoServer Module SC
	Invalid Pin
B085001F	CryptoServer Module SC
	Signing Supported until 48 Byte (Possible Hashes md5, ripemd160, sha1,
	sha224)
B0850020	CryptoServer Module SC
	Wrong Command for Card Application
B0850021	CryptoServer Module SC
	Hash Size Bigger than 40% of the Key Size
B0850022	CryptoServer Module SC
	Card not Opened Before or Unknown Card

## **B086xxxx** — CryptoServer module UTIL

B0860001 CryptoServer module UTIL Error opening RTC Device  B0860002 CryptoServer module UTIL RTC: IOCTL Error  B0860003 CryptoServer module UTIL RTC: Read Error  B0860004 CryptoServer module UTIL RTC: Write Error  B0860005 CryptoServer module UTIL
B0860002 CryptoServer module UTIL RTC: IOCTL Error  B0860003 CryptoServer module UTIL RTC: Read Error  B0860004 CryptoServer module UTIL RTC: Write Error  B0860005 CryptoServer module UTIL
B0860003 CryptoServer module UTIL RTC: Read Error  B0860004 CryptoServer module UTIL RTC: Write Error  B0860005 CryptoServer module UTIL
B0860003 CryptoServer module UTIL RTC: Read Error  B0860004 CryptoServer module UTIL RTC: Write Error  B0860005 CryptoServer module UTIL
RTC: Read Error  B0860004 CryptoServer module UTIL  RTC: Write Error  B0860005 CryptoServer module UTIL
B0860004 CryptoServer module UTIL RTC: Write Error  B0860005 CryptoServer module UTIL
RTC: Write Error  B0860005 CryptoServer module UTIL
B0860005 CryptoServer module UTIL
Error closing RTC Device
B0860006 CryptoServer module UTIL
Wrong Time Format
B0860007 CryptoServer module UTIL
Null Pointer given
B0860008 CryptoServer module UTIL
File Open Error
B0860009 CryptoServer module UTIL
File Read Error
B086000A CryptoServer module UTIL
File Close Error
B086000B CryptoServer module UTIL
Null Pointer given
B086000C CryptoServer module UTIL
Random Number Generator failed
B086000D CryptoServer module UTIL
Error allocating Memory
B086000E CryptoServer module UTIL
invalid argument

Code	Description
B086000F	CryptoServer module UTIL
	function not supported
B0860010	CryptoServer module UTIL
	Known answer test failed
B0860011	CryptoServer module UTIL
	Random Number Generator is not initialized
B0860012	CryptoServer module UTIL
	Bad Parameter
B0860013	CryptoServer module UTIL
	Given security strength not supported
B0860014	CryptoServer module UTIL
	Max number of requested randombits per call exceeded
B0860015	CryptoServer module UTIL
	prediction resistance not supported for current handle
B0860020	CryptoServer module UTIL
	RTC has lost power
B0860021	CryptoServer module UTIL
	RTC is not initialized (RTC has to be set)
B086FC00	CryptoServer module UTIL
	SMOS Version does not match

## **B087xxxx** — CryptoServer module ADM

Code	Description
B0870001	CryptoServer module ADM
	file open error
B0870002	CryptoServer module ADM
	file read error
B0870003	CryptoServer module ADM
	file write error
B0870004	CryptoServer module ADM
	file close error
B0870005	CryptoServer module ADM
	file (module) does not exist
B0870006	CryptoServer module ADM
	wrong filename syntax
B0870007	CryptoServer module ADM
	no module info found
B0870008	CryptoServer module ADM
	file not found
B087000A	CryptoServer module ADM
	no modules version found
B087000B	CryptoServer module ADM
	wrong command data length
B087000C	CryptoServer module ADM
	unable to open i2c device
B087000D	CryptoServer module ADM
	unable to read i2c device
B087000F	CryptoServer module ADM
	permission denied
B0870011	CryptoServer module ADM
	file size exceeds limit

Code	Description
B0870012	CryptoServer module ADM
	bad signature
B0870013	CryptoServer module ADM
	no UTIL module present
B0870014	CryptoServer module ADM
	memory allocation error
B0870015	CryptoServer module ADM
	function not supported
B0870016	CryptoServer module ADM
	invalid crc
B0870017	CryptoServer module ADM
	invalid size
B0870018	CryptoServer module ADM
	bad MMC format
B0870019	CryptoServer module ADM
	no HASH module present
B087001A	CryptoServer module ADM
	no VRSA module present
B087001B	CryptoServer module ADM
	no DB module present
B087001C	CryptoServer module ADM
	no AES module present
B087001D	CryptoServer module ADM
	module decryption failed
B087001E	CryptoServer module ADM
	invalid key type
B087001F	CryptoServer module ADM
	invalid parameter
B0870020	CryptoServer module ADM
	invalid file type

Code	Description
B0870021	CryptoServer module ADM
	invalid item length
B0870022	CryptoServer module ADM
	item not found
B0870023	CryptoServer module ADM
	no MBK module present
B0870024	CryptoServer module ADM
	no MBK key available
B0870025	CryptoServer module ADM
	cannot allocate memory
B0870026	CryptoServer module ADM
	cannot allocate secure memory
B0870027	CryptoServer module ADM
	export of MBK database not allowed
B0870028	CryptoServer module ADM
	invalid MBK value (valid: 0 (DES), 1 (AES))
B0870029	CryptoServer module ADM
-	given MBK type differs to stored MBK with the highest priority
B087002A	CryptoServer module ADM
	given MAC differs to calculated MAC
B087002B	CryptoServer module ADM
	given DB index differs to original DB index
B087002C	CryptoServer module ADM
	import of database session.db not allowed
B087002D	CryptoServer module ADM
	export of database session.db not allowed
B087002E	CryptoServer module ADM
_	import of MBK database not allowed
B087003x	CryptoServer module ADM
	module section

Code	Description
B0870030	CryptoServer module ADM
	module section
	invalid MTC header
B0870031	CryptoServer module ADM
	module section
	invalid MMC header
B0870032	CryptoServer module ADM
	module section
	invalid MSC header
B0870033	CryptoServer module ADM
	module section
	invalid MSC header
B0870034	CryptoServer module ADM
	module section
	invalid SLF header
B0870035	CryptoServer module ADM
	module section
	no module info found
B0870036	CryptoServer module ADM
	module section
	MTC doesn't contain signature
B0870037	CryptoServer module ADM
	module section
	invalid MMC hash
B0870038	CryptoServer module ADM
	module section
	can't decrypt firmware module
B0870039	CryptoServer module ADM
	module section
	invalid SCF header

Code	Description
B087004x	CryptoServer module ADM
	key section
B0870040	CryptoServer module ADM
	key section
	key is corrupted
B087005x	CryptoServer module ADM
	cfg section
B0870051	CryptoServer module ADM
	cfg section
	could not retrieve version of requested module
B0870052	CryptoServer module ADM
	cfg section
	requested module is too old, does not yet support cfg
B0870053	CryptoServer module ADM
	cfg section
	unknown module, unknown how to cfg
B0870054	CryptoServer module ADM
	cfg section
	loading of an Alternative Module Signature Key is blocked
B087006x	CryptoServer module ADM
	FIPS section
B0870061	CryptoServer module ADM
	FIPS section
	evaluation of FIPS mode has gone wrong
B0870062	CryptoServer module ADM
	FIPS section
	virtual error code for restricted FIPS mode
B0870063	CryptoServer module ADM
	FIPS section
	function not available in FIPS mode

Code	Description
B0870064	CryptoServer module ADM
	FIPS section
	function not available in FIPS error state
B0870070	CryptoServer module ADM
	FIPS section
	not allowed in CC Endorsed Mode
B0870071	CryptoServer module ADM
	FIPS section
	not allowed in CC Error State
B0870080	CryptoServer module ADM
	FIPS section
	import of authentication key database not allowed
B0870081	CryptoServer module ADM
	FIPS section
	export of authentication key database not allowed

## **B088xxx** — CryptoServer Database Module

Code	Description
B0880001	CryptoServer Database Module
	memory allocation failed
B0880002	CryptoServer Database Module
	bad master encryption key
B0880003	CryptoServer Database Module
	no space in database
B0880004	CryptoServer Database Module
	record not found
B0880005	CryptoServer Database Module
	record already exists
B0880006	CryptoServer Database Module
	no space in cache
B0880007	CryptoServer Database Module
	corrupted database file
B0880008	CryptoServer Database Module
	record CRC error
B0880009	CryptoServer Database Module
	bad database name
B088000A	CryptoServer Database Module
	bad database handle
B088000B	CryptoServer Database Module
	bad file type of database file
B088000D	CryptoServer Database Module
	bad info structure
B088000E	CryptoServer Database Module
	database in use
B088000F	CryptoServer Database Module
	bad data length

Code	Description
B0880011	CryptoServer Database Module
	database handle confused
B0880012	CryptoServer Database Module
	internal inconsistency
B0880013	CryptoServer Database Module
	SMOS version is too old
B0881000	CryptoServer Database Module
	bad length of command block
B0881001	CryptoServer Database Module
	io error on database file
B0881002	CryptoServer Database Module
	test database not open
B0881003	CryptoServer Database Module
	db handle corrupted
B0881004	CryptoServer Database Module
	db node corrupted
B0881005	CryptoServer Database Module
	db cache corrupted

# **B089xxxx** — CryptoServer module HASH

Code	Description
B0890001	CryptoServer module HASH
	Memory Error
B0890002	CryptoServer module HASH
	Illegal Parameter
B0890003	CryptoServer module HASH
	Illegal Length
B0890004	CryptoServer module HASH
	Illegal Mode
B0890005	CryptoServer module HASH
	Function not supported
B0890006	CryptoServer module HASH
	Mode not permitted in FIPS mode

# **B08Bxxxx** — CryptoServer module AES

Code	Description
B08B0001	CryptoServer module AES
	length of data is not a multiple of 16 bytes
B08B0002	CryptoServer module AES
	length of key is not 16, 24, or 32
B08B0003	CryptoServer module AES
	cannot allocate memory
B08B0004	CryptoServer module AES
	mode is unknown
B08B0005	CryptoServer module AES
	For cfb1 decryption the key must always prepared for encryption
B08B0006	CryptoServer module AES
	unknown padding mechanism
B08B0007	CryptoServer module AES
	invalid padding
B08B0008	CryptoServer module AES
	invalid parameter
B08B0009	CryptoServer module AES
	could not get local Master Key
B08B000A	CryptoServer module AES
	mode of prepared key does not match mode parameter
B08B000C	CryptoServer module AES
	Zero data length is not allowed
B08B000D	CryptoServer module AES
	Overflow of block counter in CTR chaining mode
B08B000E	CryptoServer module AES
	Tag verification on CCM/GCM decrypt failed

## **B08Dxxxx** — CryptoServer module DSA

Code	Description
B08D0001	CryptoServer module DSA
	cannot allocate memory
B08D0002	CryptoServer module DSA
	prime P is too small
B08D0003	CryptoServer module DSA
	prime Q is too small
B08D0004	CryptoServer module DSA
	domain parameter generation failed
B08D0005	CryptoServer module DSA
	invalid generator value G
B08D0006	CryptoServer module DSA
	bad primes P and Q
B08D0007	CryptoServer module DSA
	byte string is not a keytoken
B08D0008	CryptoServer module DSA
	component is not a member of this token
B08D0009	CryptoServer module DSA
	component is already a member of this token
B08D000A	CryptoServer module DSA
	value for flags is invalid
B08D000B	CryptoServer module DSA
	wrong hash value length
B08D000C	CryptoServer module DSA
	private and public key do not correspond
B08D000D	CryptoServer module DSA
	invalid parameter
B08D000E	CryptoServer module DSA
	bad public key

Code	Description
B08D000F	CryptoServer module DSA
	bad private key
B08D0010	CryptoServer module DSA
	bad length of key token
B08D0011	CryptoServer module DSA
	signature verification failed
B08D0012	CryptoServer module DSA
	bad format of signature
B08D0013	CryptoServer module DSA
	no ASN.1 module loaded
B08D0014	CryptoServer module DSA
	buffer for result is to small
B08D0015	CryptoServer module DSA
	pairwise consistency check failed on keygen
B08D0018	CryptoServer module DSA
	Zero length not allowed
B08D0030	CryptoServer module DSA
	The function called is no longer supported
B08D0100	CryptoServer module DSA
	bad key token in command string

## **B08Exxxx** — CryptoServer module LNA

Code	Description
B08E0001	CryptoServer module LNA
	result overflow
B08E0002	CryptoServer module LNA
	result negativ
B08E0003	CryptoServer module LNA
	modulus too short
B08E0004	CryptoServer module LNA
	data greater than modulus
B08E0005	CryptoServer module LNA
	can't alloc memory
B08E0006	CryptoServer module LNA
	exponent is 0
B08E0007	CryptoServer module LNA
	division by zero
B08E0008	CryptoServer module LNA
	number too short
B08E0009	CryptoServer module LNA
	bad parameter
B08E000A	CryptoServer module LNA
	no prime found
B08E000B	CryptoServer module LNA
	modulus is even
B08E0100	CryptoServer module LNA
	result overflow
B08E0101	CryptoServer module LNA
	bad argument length
B08E0102	CryptoServer module LNA
	internal error while generating prime

# **B08Fxxxx** — CryptoServer module ECA

Code	Description
B08F0001	CryptoServer module ECA
	can't alloc memory
B08F0002	CryptoServer module ECA
	not supported
B08F0003	CryptoServer module ECA
	bad parameter
B08F0004	CryptoServer module ECA
	curve not found
B08F0005	CryptoServer module ECA
	curve already registered
B08F0006	CryptoServer module ECA
	input number too big
B08F0007	CryptoServer module ECA
	infinite result
B08F0008	CryptoServer module ECA
	incompatible precalculated point
B08F0009	CryptoServer module ECA
	bad length of argument
B08F000A	CryptoServer module ECA
	bad tag of point
B08F000B	CryptoServer module ECA
	no square root found
B08F000C	CryptoServer module ECA
	non-residue could not be found
B08F000D	CryptoServer module ECA
	no ASN.1 module found
B08F000E	CryptoServer module ECA
	error decoding ASN.1 EC domain parameter

Code	Description
B08F000F	CryptoServer module ECA
	bad value of EC point
B08F0010	CryptoServer module ECA
	bad value of EC domain parameter
B08F0011	CryptoServer module ECA
	EC domain parameters differ
B08F0012	CryptoServer module ECA
	invalid domain parameter
B08F0013	CryptoServer module ECA
	invalid irreducible polynomial
B08F0014	CryptoServer module ECA
	curve not available in FIPS mode
B08F0015	CryptoServer module ECA
	function not available in FIPS mode
B08F0016	CryptoServer module ECA
	Curve not secure for CC standards
B08F0017	CryptoServer module ECA
	table of precalculated values empty/inconsistent
B08F0101	CryptoServer module ECA
	bad argument length
B08F0102	CryptoServer module ECA
	internal error

# **B090**xxxx — CryptoServer module TECA

Code	Description
B0900001	CryptoServer module TECA
	permission denied
B0900002	CryptoServer module TECA
	invalid parameter
B0900003	CryptoServer module TECA
	invalid parameter length
B0900004	CryptoServer module TECA
	memory allocation failed
B0900005	CryptoServer module TECA
	invalid mode
B0900006	CryptoServer module TECA
	item not found
B0900007	CryptoServer module TECA
	unresolved module dependency
B0900008	CryptoServer module TECA
	file I/O error

## **B091xxxx** — CryptoServer module ASN1

Code	Description
B0910001	CryptoServer module ASN1
	Memory Error
B0910002	CryptoServer module ASN1
	Parameter flag is incorrect
B0910003	CryptoServer module ASN1
	ASN1_ITEM table overflow
B0910004	CryptoServer module ASN1
	bad ZKA format
B0910005	CryptoServer module ASN1
	ASN1 data overrun
B0910006	CryptoServer module ASN1
	tag too big
B0910007	CryptoServer module ASN1
	indefinite length not supportet
B0910008	CryptoServer module ASN1
	lenght field too big
B0910009	CryptoServer module ASN1
	internal stack overflow
B091000A	CryptoServer module ASN1
	item not found
B091000B	CryptoServer module ASN1
	ASN1 buffer overflow
B091000C	CryptoServer module ASN1
	bad value of 'nitems' in ITEM table
B091000D	CryptoServer module ASN1
	zero tag
B091000E	CryptoServer module ASN1
	bad PKCS#1 format

Code	Description
B091000F	CryptoServer module ASN1
	decoding error
B0910010	CryptoServer module ASN1
	calculated size exceeds given datasize

## **B096xxxx** — CryptoServer module MBK

Code	Description
B0960001	CryptoServer module MBK
	Parameter mismatch
B0960002	CryptoServer module MBK
	MBK database is suspended
B0960003	CryptoServer module MBK
	Unexpected null pointer
B0960004	CryptoServer module MBK
	Permission denied
B0960005	CryptoServer module MBK
	ISO hash check of key failed
B0960006	CryptoServer module MBK
	Key types do not match
B0960007	CryptoServer module MBK
	Key generation date do not match
B0960008	CryptoServer module MBK
	Key generation time do not match
B0960009	CryptoServer module MBK
	Key names do not match
B096000A	CryptoServer module MBK
	Verify of existing master key failed
B096000B	CryptoServer module MBK
	Slot is empty
B096000C	CryptoServer module MBK
	Slot number not valid
B096000D	CryptoServer module MBK
	Record number not valid
B096000E	CryptoServer module MBK
	Key length not valid

Code	Description
B096000F	CryptoServer module MBK
	Wrong format in time structure detected
B0960010	CryptoServer module MBK
	BCD coded time length mismatch
B0960011	CryptoServer module MBK
	No key name or NULL pointer for key name
B0960012	CryptoServer module MBK
	Action canceled by user
B0960013	CryptoServer module MBK
	Invalid mode for AES key passed
B0960014	CryptoServer module MBK
	Both versions of the MBK database exists
B0960015	CryptoServer module MBK
	External parameter already set from extern and overwrite flag is not set
B0960016	CryptoServer module MBK
	The AES Module is not available
B0960017	CryptoServer module MBK
	Invalid key type
B0960018	CryptoServer module MBK
	memory allocation failed
B0960019	CryptoServer module MBK
	bad database format
B096001A	CryptoServer module MBK
	smartcard record is empty
B096001B	CryptoServer module MBK
	smartcard only contains empty records
B096001C	CryptoServer module MBK
	unable to require semaphore
B096001D	CryptoServer module MBK
	maximum numbers of key exchange keys reached

Code	Description
B096001E	CryptoServer module MBK
	invalid flags value
B096001F	CryptoServer module MBK
	info length not valid
B0960020	CryptoServer module MBK
	key alread exists
B0960021	CryptoServer module MBK
	invalid length of key share
B0960022	CryptoServer module MBK
	invalid number of key shares
B0960023	CryptoServer module MBK
	the ECA module is not available
B0960024	CryptoServer module MBK
	number of key shares doesn't match
B0960025	CryptoServer module MBK
	invalid key ID
B0960026	CryptoServer module MBK
	multiple occurence of same key ID
B0960027	CryptoServer module MBK
	no kek found with given hash
B0960028	CryptoServer module MBK
	function is not supported
B0960029	CryptoServer module MBK
	no PIN pad module found
B096002A	CryptoServer module MBK
	no smartcard module found
B096002B	CryptoServer module MBK
	function not available in FIPS mode
B096002C	CryptoServer module MBK
	not allowed in CC Endorsed Mode

Code	Description
B096002D	CryptoServer module MBK
	function is deprecated

## **B099**xxxx — CryptoServer module PIN

Code	Description
B0990001	CryptoServer module PIN
	bad PIN block format
B0990002	CryptoServer module PIN
	bad parameter
B0990003	CryptoServer module PIN
	can't allocate memory
B0990004	CryptoServer module PIN
	bad PIN length
B0990005	CryptoServer module PIN
	not enaugh digits found
B0990006	CryptoServer module PIN
	bad translation table
B0990007	CryptoServer module PIN
	bad PIN conditions
B0990008	CryptoServer module PIN
	PIN does not meet conditions

## **B09Axxxx** — CryptoServer module NTP

Code	Description
B09A0001	CryptoServer module NTP
	NTP: Command with invalid data length
B09A0002	CryptoServer module NTP
	NTP: requested time delay too big
B09A0003	CryptoServer module NTP
	NTP: daily time delay exceeded
B09A0004	CryptoServer module NTP
	NTP: old function call; use new one
B09A0005	CryptoServer module NTP
	NTP: negative time set; use flag to set backward
B09A0006	CryptoServer module NTP
	NTP: ntp module is not activated
B09A0007	CryptoServer module NTP
	NTP: database error
B09A0008	CryptoServer module NTP
	NTP: permission denied
·	

### **B09Cxxxx** — CryptoServer module ECDSA

Code	Description
B09C0001	CryptoServer module ECDSA
	cannot allocate memory
B09C0002	CryptoServer module ECDSA
	null component in signature (r,s)
B09C0003	CryptoServer module ECDSA
	value for flags is invalid
B09C0004	CryptoServer module ECDSA
	private and public key do not correspond
B09C0005	CryptoServer module ECDSA
	bad public key
B09C0006	CryptoServer module ECDSA
	bad private key
B09C0007	CryptoServer module ECDSA
	signature verification failed
B09C0008	CryptoServer module ECDSA
	bad format of signature
B09C0009	CryptoServer module ECDSA
	no ASN.1 module loaded
B09C000A	CryptoServer module ECDSA
	buffer for result is to small
В09С000В	CryptoServer module ECDSA
	malformed ASN.1 coded key pair
B09C000C	CryptoServer module ECDSA
	bad parameter
B09C000D	CryptoServer module ECDSA
	mac check of ecies encrypted data failed
B09C000E	CryptoServer module ECDSA
	no AES module loaded

Code	Description
B09C000F	CryptoServer module ECDSA
	pairwise consistency check failed on keygen
B09C0010	CryptoServer module ECDSA
	Zero length not allowed
B09C0011	CryptoServer module ECDSA
	secure mode of curve not available
B09C0012	CryptoServer module ECDSA
	count of signatures per command exceeds limit

### **B900xxxx** — CryptoServer API

Code	Description
B90000xx	CryptoServer API
	CryptoServer API core functions
B9000000	CryptoServer API
	CryptoServer API core functions
	bad tag in data block
B9000001	CryptoServer API
	CryptoServer API core functions
	invalid handle
B9000002	CryptoServer API
	CryptoServer API core functions
	invalid argument
B9000003	CryptoServer API
	CryptoServer API core functions
	can't alloc memory
B9000004	CryptoServer API
	CryptoServer API core functions
	malformed protocol stack
B9000005	CryptoServer API
	CryptoServer API core functions
	data block too big
B9000007	CryptoServer API
	CryptoServer API core functions
	bad V24 device
B9000008	CryptoServer API
	CryptoServer API core functions
	bad V24 parameter
B9000009	CryptoServer API
	CryptoServer API core functions
	can't calculate block length

Code	Description
B900000A	CryptoServer API
	CryptoServer API core functions
	empty command block
B900000B	CryptoServer API
	CryptoServer API core functions
	malformed answer block from CSLAN
B900000C	CryptoServer API
	CryptoServer API core functions
	can't set V24 device
B90000D	CryptoServer API
	CryptoServer API core functions
	V24 mode not activated
B900000E	CryptoServer API
	CryptoServer API core functions
	V24 crc error on read
B9000010	CryptoServer API
	CryptoServer API core functions
	bad length within format string (scanf)
B9000011	CryptoServer API
	CryptoServer API core functions
	bad format of command block
B9000012	CryptoServer API
	CryptoServer API core functions
	bad parameter structure (scanf)
B9000013	CryptoServer API
	CryptoServer API core functions
	bad format string (scanf)
B9000014	CryptoServer API
	CryptoServer API core functions
	cs_scanf not supported

Code	Description
B9000015	CryptoServer API
	CryptoServer API core functions
	CSAPI handle still in use
B90001xx	CryptoServer API
	command layer for old KryptoServer
B9000100	CryptoServer API
	command layer for old KryptoServer
	length error of answer block
B9000101	CryptoServer API
	command layer for old KryptoServer
	bad length error of command data
B9000102	CryptoServer API
	command layer for old KryptoServer
	missing parameter structure
B90002xx	CryptoServer API
	command layer CMDS for CryptoServer
B9000200	CryptoServer API
	command layer CMDS for CryptoServer
	length error of answer block
B9000201	CryptoServer API
	command layer CMDS for CryptoServer
	bad length of command data
B9000202	CryptoServer API
	command layer CMDS for CryptoServer
	missing parameter structure
B9000203	CryptoServer API
	command layer CMDS for CryptoServer
	bad tag of answer block
B90003xx	CryptoServer API
	command layer CHNL for CryptoServer

Code	Description
B9000300	CryptoServer API
	command layer CHNL for CryptoServer
	length error of answer block
B9000301	CryptoServer API
	command layer CHNL for CryptoServer
	bad tag of answer block
B90004xx	CryptoServer API
	authentication layer for CryptoServer
B9000400	CryptoServer API
	authentication layer for CryptoServer
	length error of answer block
B9000401	CryptoServer API
	authentication layer for CryptoServer
	invalid function code
B9000402	CryptoServer API
	authentication layer for CryptoServer
	malformed answer block
B9000403	CryptoServer API
	authentication layer for CryptoServer
	invalid authentication mechanism
B9000404	CryptoServer API
	authentication layer for CryptoServer
	error in hash function
B9000405	CryptoServer API
	authentication layer for CryptoServer
_	error in signature function
B9000406	CryptoServer API
	authentication layer for CryptoServer
	error in HMAC function
B90005xx	CryptoServer API
	command layer BL for CryptoServer

Code	Description
B9000500	CryptoServer API
	command layer BL for CryptoServer
	length error of answer block
B9000501	CryptoServer API
	command layer BL for CryptoServer
	bad length error of command data
B9000502	CryptoServer API
	command layer BL for CryptoServer
	missing parameter structure
B9000503	CryptoServer API
	command layer BL for CryptoServer
	bad tag of answer block
B90006xx	CryptoServer API
	secure messaging layer for CryptoServer
B9000600	CryptoServer API
	secure messaging layer for CryptoServer
	length error of answer block
B9000601	CryptoServer API
	secure messaging layer for CryptoServer
	malformed answer block
B9000602	CryptoServer API
	secure messaging layer for CryptoServer
	invalid SM mechanism
B9000603	CryptoServer API
	secure messaging layer for CryptoServer
	zero length data
B9000604	CryptoServer API
	secure messaging layer for CryptoServer
	en- / decryption / MAC error

B9000605 CryptoServer API secure messaging layer for CryptoServer secure messaging unwrap error  B9000Axx CryptoServer API command layer CDI for CryptoServer  B9000A00 CryptoServer API command layer CDI for CryptoServer
secure messaging unwrap error  B9000Axx CryptoServer API command layer CDI for CryptoServer  B9000A00 CryptoServer API
B9000Axx CryptoServer API command layer CDI for CryptoServer  B9000A00 CryptoServer API
command layer CDI for CryptoServer  B9000A00 CryptoServer API
B9000A00 CryptoServer API
command layer CDI for CryptoServer
length error of answer block
B9000A01 CryptoServer API
command layer CDI for CryptoServer
bad length error of command data
B9000A02 CryptoServer API
command layer CDI for CryptoServer
missing parameter structure
B9000A03 CryptoServer API
command layer CDI for CryptoServer
bad tag of answer block
B9000Cxx CryptoServer API
command layer TL for CryptoServer
B9000C00 CryptoServer API
command layer TL for CryptoServer
length error of answer block
B9000C01 CryptoServer API
command layer TL for CryptoServer
bad tag of answer block
B9000Exx CryptoServer API
command layer DUMY for CryptoServer
B9000E00 CryptoServer API
command layer DUMY for CryptoServer
length error of answer block

Code	Description
B9000E01	CryptoServer API
	command layer DUMY for CryptoServer
	bad length error of command data
B9000E02	CryptoServer API
	command layer DUMY for CryptoServer
	missing parameter structure

## B901xxxx — CryptoServer API LINUX

Code	Description
B9010001	CryptoServer API LINUX
	path name too long
B9010002	CryptoServer API LINUX
	bad port number
B9010003	CryptoServer API LINUX
	bad IP address
B9010004	CryptoServer API LINUX
	bad host name
B9010005	CryptoServer API LINUX
	connection terminated by remote host
B9010006	CryptoServer API LINUX
	can't alloc memory
B9010007	CryptoServer API LINUX
	timeout occured
B9010008	CryptoServer API LINUX
	invalid argument
B9010009	CryptoServer API LINUX
	no space for sockaddr (internal error)
B901000A	CryptoServer API LINUX
	bad block size received
B901000B	CryptoServer API LINUX
	no ready message from CMDS
B901000C	CryptoServer API LINUX
	cs2 exceeds critical temperature
B901000D	CryptoServer API LINUX
	error on /proc file
B901000E	CryptoServer API LINUX
	can't stat device file

Code	Description
B901000F	CryptoServer API LINUX
	buffer size too small
B9011xxx	CryptoServer API LINUX
	can't open device
B9012xxx	CryptoServer API LINUX
	can't creat socket
B9013xxx	CryptoServer API LINUX
	can't get connection
B9014xxx	CryptoServer API LINUX
	error while polling
B9015xxx	CryptoServer API LINUX
	read error
B9015701	CryptoServer API LINUX
	read error
	timeout
B9015706	CryptoServer API LINUX
	read error
	operation interruptet by reset
B9015707	CryptoServer API LINUX
	read error
	high temperature
B901570A	CryptoServer API LINUX
	read error
	CryptoServer halted
B901570B	CryptoServer API LINUX
	read error
	panic message from CryptoServer
B9016xxx	CryptoServer API LINUX
	write error

Code	Description
B9016701	CryptoServer API LINUX
	write error
	timeout
B9016703	CryptoServer API LINUX
	write error
	request rejectet by CS2
B9016706	CryptoServer API LINUX
	write error
	operation interruptet by reset
B9016707	CryptoServer API LINUX
	write error
	high temperature
B901670A	CryptoServer API LINUX
	write error
	CryptoServer halted
B901670B	CryptoServer API LINUX
	write error
	panic message from CryptoServer
B9017xxx	CryptoServer API LINUX
	ioctl error
B9017701	CryptoServer API LINUX
	ioctl error
	timeout
B9017706	CryptoServer API LINUX
	ioctl error
	operation interrupted by reset
B9017707	CryptoServer API LINUX
	ioctl error
	high temperature

Code	Description
B901770A	CryptoServer API LINUX
	ioctl error
	CryptoServer halted
B901770B	CryptoServer API LINUX
	ioctl error
	panic message from CryptoServer
B901773x	CryptoServer API LINUX
	reset of CryptoServer failed
B9018xxx	CryptoServer API LINUX
	ioctl error (locking)
B9018706	CryptoServer API LINUX
	ioctl error (locking)
	operation interruptet by reset
B9019xxx	CryptoServer API LINUX
	tcp receive error
B901Axxx	CryptoServer API LINUX
	tcp send error

## **B902xxxx** — CryptoServer API Windows

Code	Description
B9020001	CryptoServer API Windows
	path name too long
B9020002	CryptoServer API Windows
	bad port number
B9020003	CryptoServer API Windows
	bad IP address
B9020004	CryptoServer API Windows
	bad host name
B9020005	CryptoServer API Windows
	connection terminated by remote host
B9020006	CryptoServer API Windows
	can't alloc memory
B9020007	CryptoServer API Windows
	timeout occured
B9020008	CryptoServer API Windows
	invalid argument
B9020009	CryptoServer API Windows
	no space for sockaddr (internal error)
B902000A	CryptoServer API Windows
	bad block size received
B902000B	CryptoServer API Windows
	no ready message from CMDS
B902000C	CryptoServer API Windows
	cs2 exceeds critical temperature
B9020010	CryptoServer API Windows
	invalid parameter
B9020011	CryptoServer API Windows
	invalid handle value

Code	Description
B9020013	CryptoServer API Windows
	error creating mutex
B9020014	CryptoServer API Windows
	unable to set lock
B9020015	CryptoServer API Windows
	timeout while waiting for mutex
B9020016	CryptoServer API Windows
	no valid mutex object
B90201xx	CryptoServer API Windows
	tcp: can't open device
B90202xx	CryptoServer API Windows
	tcp: can't create socket
B90203xx	CryptoServer API Windows
	tcp: can't get connection
B90204xx	CryptoServer API Windows
	tcp: error while polling
B90204F0	CryptoServer API Windows
	tcp: error while polling
	can't get connection
B90205xx	CryptoServer API Windows
	tcp: read error
B90206xx	CryptoServer API Windows
	tcp: write error
B90207xx	CryptoServer API Windows
	top: init error
B90208xx	CryptoServer API Windows
	tcp: ioctl error
B9021xxx	CryptoServer API Windows
	dci: can't open device
B9022xxx	CryptoServer API Windows
	read error

Code	Description
B9022001	CryptoServer API Windows
	read error
	read returned wrong length
B90220B5	CryptoServer API Windows
	read error
	read timeout
B9022706	CryptoServer API Windows
	read error
	operation interruptet by reset
B9022707	CryptoServer API Windows
	read error
	high temperature
B902273x	CryptoServer API Windows
	reset failed
B9023xxx	CryptoServer API Windows
	dci: write error
B9023001	CryptoServer API Windows
	dci: write error
	write returned wrong length
B90230B5	CryptoServer API Windows
	dci: write error
	write timeout
B9023706	CryptoServer API Windows
	dci: write error
	operation interrupted by reset
B9023707	CryptoServer API Windows
	dci: write error
	high temperature
B902373x	CryptoServer API Windows
	reset failed

Code	Description
B9024xxx	CryptoServer API Windows
	dci: ioctl error
B9024001	CryptoServer API Windows
	dci: ioctl error
	no ready message from CMDS
B90240B5	CryptoServer API Windows
	dci: ioctl error
	ioctl timeout
B9024706	CryptoServer API Windows
	dci: ioctl error
	operation interruptet by reset
B9024707	CryptoServer API Windows
	dci: ioctl error
	high temperature
B902473x	CryptoServer API Windows
	reset failed
B9025xxx	CryptoServer API Windows
	mutex section
B9028xxx	CryptoServer API Windows
	tcp: startup error
B9029xxx	CryptoServer API Windows
	tcp: address error
B902Axxx	CryptoServer API Windows
	tcp: can't create socket
B902Bxxx	CryptoServer API Windows
	tcp: can't get connection
B902B03C	CryptoServer API Windows
	tcp: can't get connection
	connection attempt timed out

Code	Description
B902B03D	CryptoServer API Windows
	tcp: can't get connection
	connection attempt refused
B902Cxxx	CryptoServer API Windows
	tcp: error on select
B902Dxxx	CryptoServer API Windows
	tcp: receive error
B902Exxx	CryptoServer API Windows
	tcp: send error
B902Fxxx	CryptoServer API Windows
	tcp: ioctl error

# B904xxxx — yacl library

B90400xx yacl library DES modul  B9040000 yacl library DES modul length of DES-Key is not 8, 16 or 24 byte  B9040001 yacl library DES modul length of input data is not a multiple of 8
B9040000 yacl library  DES modul length of DES-Key is not 8, 16 or 24 byte  B9040001 yacl library  DES modul length of input data is not a multiple of 8
DES modul length of DES-Key is not 8, 16 or 24 byte  B9040001 yacl library DES modul length of input data is not a multiple of 8
length of DES-Key is not 8, 16 or 24 byte  B9040001 yacl library  DES modul  length of input data is not a multiple of 8
B9040001 yacl library  DES modul  length of input data is not a multiple of 8
DES modul length of input data is not a multiple of 8
length of input data is not a multiple of 8
100
B9040013 yacl library
DES modul
invalid irreducible polynomial
B90401xx yacl library
RSA modul
B9040100 yacl library
RSA modul
effective length of result is greater
B9040101 yacl library
RSA modul
effective length of on input operand
B9040102 yacl library
RSA modul
result of subtraction would be negativ
B9040103 yacl library
RSA modul
divisor/modulus is zero with division
B9040104 yacl library
RSA modul
operand for 'esm' is greater than modulus

B9040201 yacl library Long Number Arithmetic B9040201 yacl library Long Number Arithmetic result overflow B9040202 yacl library Long Number Arithmetic result negativ B9040203 yacl library Long Number Arithmetic modulus too short B9040204 yacl library Long Number Arithmetic data greater than modulus B9040205 yacl library Long Number Arithmetic can't alloc memory B9040206 yacl library Long Number Arithmetic exponent is 0 B9040207 yacl library Long Number Arithmetic division by zero B9040208 yacl library Long Number Arithmetic division by zero B9040209 yacl library Long Number Arithmetic number too short B9040209 yacl library Long Number Arithmetic bad parameter	Code	Description
B9040201 yacl library Long Number Arithmetic result overflow  B9040202 yacl library Long Number Arithmetic result negativ  B9040203 yacl library Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic division by zero  B9040209 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic	B90402xx	yacl library
Long Number Arithmetic result overflow  B9040202 yacl library Long Number Arithmetic result negativ  B9040203 yacl library Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
result overflow  B9040202 yacl library Long Number Arithmetic result negativ  B9040203 yacl library Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic	B9040201	yacl library
B9040202 yacl library Long Number Arithmetic result negativ  B9040203 yacl library Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic result negativ  B9040203 yacl library Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		result overflow
result negativ  B9040203 yacl library Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic	B9040202	yacl library
B9040203 yacl library Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		result negativ
modulus too short  B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic	B9040203	yacl library
B9040204 yacl library Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic data greater than modulus  B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		modulus too short
B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic	B9040204	yacl library
B9040205 yacl library Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic can't alloc memory  B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		data greater than modulus
B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic	B9040205	yacl library
B9040206 yacl library Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic exponent is 0  B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		can't alloc memory
exponent is 0  B9040207 yacl library  Long Number Arithmetic  division by zero  B9040208 yacl library  Long Number Arithmetic  number too short  B9040209 yacl library  Long Number Arithmetic	B9040206	yacl library
B9040207 yacl library Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic division by zero  B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		exponent is 0
B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic	B9040207	yacl library
B9040208 yacl library Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic number too short  B9040209 yacl library Long Number Arithmetic		division by zero
number too short  B9040209 yacl library Long Number Arithmetic	B9040208	yacl library
B9040209 yacl library Long Number Arithmetic		Long Number Arithmetic
Long Number Arithmetic		number too short
	B9040209	yacl library
bad parameter		Long Number Arithmetic
		bad parameter

Code	Description
B904020A	yacl library
	Long Number Arithmetic
	no prime found
B904020B	yacl library
	Long Number Arithmetic
	modulus is even
B90403xx	yacl library
	RSA functions
B9040301	yacl library
	RSA functions
	cannot allocate memory
B9040302	yacl library
	RSA functions
	buffer for result is to small
B9040303	yacl library
	RSA functions
	data size too big (greater than modulus)
B9040304	yacl library
	RSA functions
	modulus is not p * q
B9040305	yacl library
	RSA functions
	p is greater then q
B9040306	yacl library
	RSA functions
	u is not (1/q) mod p
B9040307	yacl library
	RSA functions
	dp is not d mod (p-1)

Code	Description
B9040308	yacl library
	RSA functions
	dq is not d mod (q-1)
B9040309	yacl library
	RSA functions
	gcd(p-1,e) != 1 or gcd(q-1,e) != 1
B904030A	yacl library
	RSA functions
	d * e != 1 mod (p-1)(q-1)
B904030B	yacl library
	RSA functions
	Key length too small
B904030C	yacl library
	RSA functions
	modulus to small
B904030D	yacl library
	RSA functions
	bad key components
B904030E	yacl library
	RSA functions
	invalid parameter
B904030F	yacl library
	RSA functions
	key generation failed
B9040310	yacl library
	RSA functions
	Invalid hash algorithm
B9040311	yacl library
	RSA functions
	Signature verification failed

Code	Description
B9040312	yacl library
	RSA functions
	PKCS#1 decryption failed
B9040313	yacl library
	RSA functions
	PKCS#1 encoding error
B9040314	yacl library
	RSA functions
	invalid public exponent
B90404xx	yacl library
	SAFER module
B9040400	yacl library
	SAFER module
	length of SAFER-Key is not 8 or 16
B9040401	yacl library
	SAFER module
	length of input data is not a multiple of 8
B90405xx	yacl library
	Pseudo Random Number Generator
B9040501	yacl library
	Pseudo Random Number Generator
	Null pointer in argument
B9040502	yacl library
	Pseudo Random Number Generator
	Wrong length of seed
B9040503	yacl library
	Pseudo Random Number Generator
	Can't auto initialize rnd generator
B90406xx	yacl library
	AES module

Code	Description
B9040600	yacl library
	AES module
	length of AES-Key is not 16, 24 or 32
B9040601	yacl library
	AES module
	length of input data is not a multiple of 16
B9040602	yacl library
	AES module
	bad input parameter (eg. NULL pointer not allowed)
B90408xx	yacl library
	ASN1 module
B9040821	yacl library
	ASN1 module
	Memory Error
B9040822	yacl library
	ASN1 module
-	Parameter flag is incorrect
B9040823	yacl library
	ASN1 module
-	ASN1_ITEM table overflow
B9040824	yacl library
	ASN1 module
	Component flag is not defined
B9040825	yacl library
	ASN1 module
	ASN1 data overrun
B9040826	yacl library
	ASN1 module
	tag too big

Code	Description
B9040827	yacl library
	ASN1 module
	indefinite length not supportet
B9040828	yacl library
	ASN1 module
	lenght field too big
B904082A	yacl library
	ASN1 module
	item not found
B904082B	yacl library
	ASN1 module
	ASN1 buffer overflow
B904082C	yacl library
	ASN1 module
	bad value of 'nitems' in ITEM table
B904082D	yacl library
	ASN1 module
	zero tag
B904082F	yacl library
	ASN1 module
	decoding error
B9040830	yacl library
	ASN1 module
	calculated size exceeds given datasize
B90409xx	yacl library
	Hash module
B9040901	yacl library
	Hash module
	Invalid hash mode

Code	Description
B9040902	yacl library
	Hash module
	Invalid length
B9040903	yacl library
	Hash module
	Invalid parameter
B9040Axx	yacl library
	module ECA
B9040A01	yacl library
	module ECA
	can't alloc memory
B9040A02	yacl library
	module ECA
	not supported
B9040A03	yacl library
	module ECA
	bad parameter
B9040A04	yacl library
	module ECA
	curve not found
B9040A05	yacl library
	module ECA
	curve already registered
B9040A06	yacl library
	module ECA
	input number too big
B9040A07	yacl library
	module ECA
	infinite result

Code	Description
B9040A08	yacl library
	module ECA
	incompatible precalculated point
B9040A09	yacl library
	module ECA
	bad length of argument
B9040A0A	yacl library
	module ECA
	bad tag of point
B9040A0B	yacl library
	module ECA
	no square root found
B9040A0C	yacl library
	module ECA
	non-residue could not be found
B9040A0D	yacl library
	module ECA
	no ASN.1 module found
B9040A0E	yacl library
	module ECA
	error decoding ASN.1 EC domain parameter
B9040A0F	yacl library
	module ECA
	bad value of EC point
B9040A10	yacl library
	module ECA
	bad value of EC domain parameter
B9040A11	yacl library
	module ECA
	EC domain parameters differ

Code	Description
B9040A12	yacl library
	module ECA
	invalid domain parameter
B9040Bxx	yacl library
	module ECDSA
B9040B01	yacl library
	module ECDSA
	cannot allocate memory
B9040B02	yacl library
	module ECDSA
	null component in signature (r,s)
B9040B03	yacl library
	module ECDSA
	value for flags is invalid
B9040B04	yacl library
	module ECDSA
	private and public key do not correspond
B9040B05	yacl library
	module ECDSA
	bad public key
B9040B06	yacl library
	module ECDSA
	bad private key
B9040B07	yacl library
	module ECDSA
	signature verification failed
B9040B08	yacl library
	module ECDSA
	bad format of signature

Code	Description
B9040B09	yacl library
	module ECDSA
	no ASN.1 module loaded
B9040B0A	yacl library
	module ECDSA
	buffer for result is to small
B9040B0B	yacl library
	module ECDSA
	malformed ASN.1 coded key pair
B9040Cxx	yacl library
	module DSA
B9040C01	yacl library
	module DSA
	prime P is too small
B9040C02	yacl library
	module DSA
	prime Q is too small
B9040C03	yacl library
	module DSA
	domain parameter generation failed
B9040C04	yacl library
	module DSA
	invalid generator value G
B9040C05	yacl library
	module DSA
	bad primes P and Q
B9040C06	yacl library
	module DSA
	hash value too long

Code	Description
B9040C07	yacl library
	module DSA
	private and public key do not correspond
B9040C08	yacl library
	module DSA
	invalid parameter
B9040C09	yacl library
	module DSA
	bad public key
B9040C0A	yacl library
	module DSA
	bad private key
B9040C0B	yacl library
	module DSA
	signature verification failed
B9040C0C	yacl library
	module DSA
	bad format of signature
B9040C0D	yacl library
	module DSA
	buffer for result is to small
B9040Dxx	yacl library
	PK module
B9040D01	yacl library
	PK module
	invalid parameter
B9040D02	yacl library
	PK module
	memory allocation failed

Code	Description
B9040D03	yacl library
	PK module
	unknown distinguished name type
B9040D04	yacl library
	PK module
	invalid distinguished name (value or length)
B9040D05	yacl library
	PK module
	invalid time format
B9040D06	yacl library
	PK module
	unknown / unsupported key type
B9040D07	yacl library
	PK module
	unknown / unsupported signature algorithm
B9040D08	yacl library
	PK module
	unknown / unsupported hash algorithm
B9040D09	yacl library
	PK module
	invalid / unsupported version
B9040D0A	yacl library
	PK module
	unknown / unsupported PKCS7 content type
B9040D0B	yacl library
	PK module
	no PKCS7 version found
B9040D0C	yacl library
	PK module
	unknown PKCS7 element type

Code	Description
B9040D0D	yacl library
	PK module
	element type SIGNATURE not found
B9040D0E	yacl library
	PK module
	element type ENVELOPED not found
B9040D0F	yacl library
	PK module
	element type CERT not found
B9040D10	yacl library
	PK module
	element type AUTH_ATT not found
B9040D11	yacl library
	PK module
-	element type UNAUTH_ATT not found
B9040D12	yacl library
	PK module
	element type SIG_TIME not found
B9040D13	yacl library
	PK module
	element type DATA not found
B9040D14	yacl library
	PK module
	no signer certificate given
B9040D15	yacl library
	PK module
	no data or hash given to perform sign / verify operation
B9040D16	yacl library
	PK module
	invalid PKCS7 content type

Code	Description
B9040D17	yacl library
	PK module
	no digest algorithm in PKCS7 data found
B9040D18	yacl library
	PK module
	no signer infos found
B9040D19	yacl library
	PK module
	no issuer / serial number found
B9040D1A	yacl library
	PK module
	number of PK_P7_ELEM too small
B9040D1B	yacl library
	PK module
	invalid signer reference
B9040D1C	yacl library
	PK module
	content type is not SignedData
B9040D1D	yacl library
	PK module
	content type is not Enveloped
B9040D1E	yacl library
	PK module
	digestEncryptionAlgorithm doesn't match signer certificate key type
B9040D1F	yacl library
	PK module
	signature verfication failed
B9040D20	yacl library
	PK module
	no recipient certificate given

Code	Description
B9040D21	yacl library
	PK module
	unknown / unsupported encryption key type
B9040D22	yacl library
	PK module
	multiple recipients not supported
B9040D23	yacl library
	PK module
	given certificate doesn't match certificate in PKCS7 structure
B9040D24	yacl library
	PK module
	given key doesn't match key encryption algorithm
B9040D25	yacl library
	PK module
	no key encryption algorithm identifier found
B9040D26	yacl library
	PK module
	no content type found
B9040D27	yacl library
	PK module
	no content encryption algorithm identifier found
B9040D28	yacl library
	PK module
	invalid attribute structure
B9040D29	yacl library
	PK module
	given buffer / struct doesn't contain enough space for this operation
B9040D30	yacl library
	PK module
	Unable to retrieve system time / convert time;

Code	Description
B9040D31	yacl library
	PK module
	unknown attribute type
B9040D32	yacl library
	PK module
	CRL issuer doesn't match certificate's subject / issuer
B9040D33	yacl library
	PK module
	requested attribute not available (optional)
B9040D34	yacl library
	PK module
	bad CRL format
B9040D35	yacl library
	PK module
	CRL is not yet valid
B9040D36	yacl library
	PK module
	partial CRL verification not initialized
B9040D40	yacl library
	PK module
	unsupported time format
B9040D41	yacl library
	PK module
_	given time format contains century < 1900
B9040D42	yacl library
	PK module
	indefinite length not supportet
B9040D50	yacl library
	PK module
	invalid signer / invalid signer information

Code	Description
B9040D51	yacl library
	PK module
	invalid signer structure (ASN.1 error)
B9040Exx	yacl library
	crypt module
B9040E01	yacl library
	crypt module
	Old Crypt Version

### B905xxxx — Serial Driver

Code	Description
B9050001	Serial Driver
	too many lines open
B9050002	Serial Driver
	error setting line parameters
B9050003	Serial Driver
	can't open device
B9050004	Serial Driver
	handle not open
B9050005	Serial Driver
	invalid handle
B9050006	Serial Driver
	invalid parameter value
B9050007	Serial Driver
	invalid parameter type
B9050008	Serial Driver
	error on read
B9050009	Serial Driver
	timeout on read
B905000A	Serial Driver
	error on write
B905000B	Serial Driver
	timeout on write
B905000C	Serial Driver
	error on ioctl
B9050010	Serial Driver
	no valid device name
B9050011	Serial Driver
	no valid Buffer selected

Code	Description
B9050012	Serial Driver
	line state parameter incorrect
B9050013	Serial Driver
	line select parameter incorrect
B9050014	Serial Driver
	error in comunication driver
B9050015	Serial Driver
	Parity Error
B9050016	Serial Driver
	Frame Error
B9050017	Serial Driver
	Flush failed
B9050018	Serial Driver
	EOF on read

## **B906xxxx** — CryptoServer admin library

Code	Description
B9060001	CryptoServer admin library
	malloc() failed
B9060002	CryptoServer admin library
	malformed PIN-Pad application list
B9061xxx	CryptoServer admin library
	Utility Functions
B9061001	CryptoServer admin library
	Utility Functions
	File Open Error
B9061002	CryptoServer admin library
	Utility Functions
	Key Structure has not been initialized
B9061003	CryptoServer admin library
	Utility Functions
	unable to open Keyfile
B9061004	CryptoServer admin library
	Utility Functions
	unknown Type of Keyfile
B9061005	CryptoServer admin library
	Utility Functions
	Error reading Keyfile
B9061006	CryptoServer admin library
	Utility Functions
	Error writing Keyfile
B9061007	CryptoServer admin library
	Utility Functions
	Wrong Keyfile Format in .tok file

Code	Description
B9061008	CryptoServer admin library
	Utility Functions
	Wrong Keyfile Format in .key file
B9061009	CryptoServer admin library
	Utility Functions
	Wrong File Name
B906100A	CryptoServer admin library
	Utility Functions
	invalid Key Source (file or smartcard)
B906100B	CryptoServer admin library
	Utility Functions
	invalid Key Type (private or public)
B906100C	CryptoServer admin library
	Utility Functions
	invalid Data Length
B906100D	CryptoServer admin library
	Utility Functions
	invalid Key Length
B906100E	CryptoServer admin library
	Utility Functions
	can't decrypt keyfile
B906100F	CryptoServer admin library
	Utility Functions
	no get_pass function specified (or twice)
B9061010	CryptoServer admin library
	Utility Functions
	Wrong Time Format YYYYMMDDHHMMSS
B9061011	CryptoServer admin library
	Utility Functions
	file not found

Code Descripti	on
B9061012 CryptoSe	rver admin library
Utility Fu	nctions
invalid pa	arameter
B9061013 CryptoSe	rver admin library
Utility Fu	nctions
function	not supported
B9062xxx CryptoSe	rver admin library
Bootload	er Command Interface
B9062001 CryptoSe	rver admin library
Bootload	er Command Interface
Error cald	culating Hash with SHA1
B9062002 CryptoSe	rver admin library
Bootload	er Command Interface
error exe	cuting RSA
B9062003 CryptoSe	rver admin library
Bootload	er Command Interface
no rando	m value present
B9062004 CryptoSe	rver admin library
Bootload	er Command Interface
invalid pa	arameter
B9062005 CryptoSe	rver admin library
Bootload	er Command Interface
invalid ke	y format
B9062006 CryptoSe	rver admin library
Bootload	er Command Interface
file open	error
B9062007 CryptoSe	rver admin library
Bootload	er Command Interface
file read e	error

Code	Description
B9062008	CryptoServer admin library
	Bootloader Command Interface
	memory allocation error
B9062009	CryptoServer admin library
	Bootloader Command Interface
	response error from Cryptoserver
B906200A	CryptoServer admin library
	Bootloader Command Interface
	Module Name Syntax incorrect
B906200B	CryptoServer admin library
	Bootloader Command Interface
	Wrong Response Length from CS2
B906200C	CryptoServer admin library
	Bootloader Command Interface
	file does not exist
B906200D	CryptoServer admin library
	Bootloader Command Interface
	unable to convert time
B906200E	CryptoServer admin library
	Bootloader Command Interface
	invalid key size
B906200F	CryptoServer admin library
	Bootloader Command Interface
	no external erase prevailing
B9063xxx	CryptoServer admin library
	Admin Module Command Interface
B9063001	CryptoServer admin library
	Admin Module Command Interface
	invalid Parameter

Code	Description
B9063002	CryptoServer admin library
	Admin Module Command Interface
	File Name Syntax incorrect
B9063003	CryptoServer admin library
	Admin Module Command Interface
	File Open Error
B9063004	CryptoServer admin library
	Admin Module Command Interface
	File Read Error
B9063005	CryptoServer admin library
	Admin Module Command Interface
	File Path incorrect
B9063006	CryptoServer admin library
	Admin Module Command Interface
	Memory Allocation Error
B9063007	CryptoServer admin library
	Admin Module Command Interface
	wrong response length from CS2
B9063008	CryptoServer admin library
	Admin Module Command Interface
	file does not exist
B9063009	CryptoServer admin library
	Admin Module Command Interface
	unknown battery state
B906300A	CryptoServer admin library
	Admin Module Command Interface
	unable to convert time
B906300B	CryptoServer admin library
	Admin Module Command Interface
	malformed audit log file

Code	Description
B906300C	CryptoServer admin library
	Admin Module Command Interface
	no external erase prevailing
B906300D	CryptoServer admin library
	Admin Module Command Interface
	struct version mismatch (binary length)
B906300E	CryptoServer admin library
	Admin Module Command Interface
	invalid number of arguments returning
B906300F	CryptoServer admin library
	Admin Module Command Interface
	file not suitable for cryptoserver model
B9063010	CryptoServer admin library
	Admin Module Command Interface
	File Write Error
B9064xxx	CryptoServer admin library
	MMC / MTC tools
B9064001	CryptoServer admin library
	MMC / MTC tools
	Memory Allocation Error
B9064002	CryptoServer admin library
	MMC / MTC tools
	unable to open file
B9064003	CryptoServer admin library
	MMC / MTC tools
	Error reading file
B9064004	CryptoServer admin library
	MMC / MTC tools
	Error writing file

Code	Description
B9064005	CryptoServer admin library
	MMC / MTC tools
	unknown file type
B9064006	CryptoServer admin library
	MMC / MTC tools
	invalid encryption mode
B9064007	CryptoServer admin library
	MMC / MTC tools
	Module does not contain mdl_info
B9064008	CryptoServer admin library
	MMC / MTC tools
	Error reading mmc-header
B9064009	CryptoServer admin library
	MMC / MTC tools
	Error reading mtc-header
B906400A	CryptoServer admin library
	MMC / MTC tools
	key length isn't divisible by 8
B906400B	CryptoServer admin library
	MMC / MTC tools
	Error executing DES Decryption
B906400C	CryptoServer admin library
	MMC / MTC tools
	Error executing DES Encryption
B906400D	CryptoServer admin library
	MMC / MTC tools
	Error executing SHA1 Hash
B906400E	CryptoServer admin library
	MMC / MTC tools
	invalid Hash algo

Code	Description
B906400F	CryptoServer admin library
	MMC / MTC tools
	invalid Signature Key
B9064010	CryptoServer admin library
	MMC / MTC tools
	Null Pointer in Parameter
B9064011	CryptoServer admin library
	MMC / MTC tools
	Container is without Signature
B9064012	CryptoServer admin library
	MMC / MTC tools
	MTC is without Signature Info
B9064013	CryptoServer admin library
	MMC / MTC tools
	invalid MMC header
B9064014	CryptoServer admin library
	MMC / MTC tools
	invalid MTC header
B9064015	CryptoServer admin library
	MMC / MTC tools
	invalid signature header
B9064016	CryptoServer admin library
	MMC / MTC tools
	encryption not supported
B9064017	CryptoServer admin library
	MMC / MTC tools
	unknown target CPU of Module
B9064018	CryptoServer admin library
	MMC / MTC tools
	firmware decryption key required

Code	Description
B9064019	CryptoServer admin library
	MMC / MTC tools
	error decrypting firmware module
B906401A	CryptoServer admin library
	MMC / MTC tools
	invalid sign type
B906401B	CryptoServer admin library
	MMC / MTC tools
	write operation with zero data blocks
B9064020	CryptoServer admin library
	MMC / MTC tools
	invalid signature algo
B9064021	CryptoServer admin library
	MMC / MTC tools
_	calculated Hash doesn't match with decrypted Hash
B9064022	CryptoServer admin library
	MMC / MTC tools
	invalid RSA Modulus to en-/decrypt signature
B9064023	CryptoServer admin library
	MMC / MTC tools
	invalid RSA Public Exponent to decrypt signature
B9064024	CryptoServer admin library
	MMC / MTC tools
	invalid RSA Modulus Exponent to encrypt signature
B9064025	CryptoServer admin library
	MMC / MTC tools
	Error RSA-decryption signature
B9064026	CryptoServer admin library
	MMC / MTC tools
	Error RSA-encrypting signature

Code	Description
B9064027	CryptoServer admin library
	MMC / MTC tools
	Error reading header of signature
B9064028	CryptoServer admin library
	MMC / MTC tools
	invlaid Hash algo for signature
B9064029	CryptoServer admin library
	MMC / MTC tools
	invalid Key Length
B906402A	CryptoServer admin library
	MMC / MTC tools
	invalid block type
B906402B	CryptoServer admin library
	MMC / MTC tools
	invalid pkcs#1 format
B906402C	CryptoServer admin library
	MMC / MTC tools
-	bad hash value
B906402D	CryptoServer admin library
	MMC / MTC tools
	unknown target hardware of Module
B906402E	CryptoServer admin library
	MMC / MTC tools
	cannot sign an already signed SCF file
B9064040	CryptoServer admin library
	MMC / MTC tools
	parse error found in licence file
B9064041	CryptoServer admin library
	MMC / MTC tools
	not a licence file

Code	Description
B9064050	CryptoServer admin library
	MMC / MTC tools
	package archive contains no files
B9066xxx	CryptoServer admin library
	Authentication / Session layer
B9066001	CryptoServer admin library
	Authentication / Session layer
	Bad user name
B9066002	CryptoServer admin library
	Authentication / Session layer
	malloc failed
B9066003	CryptoServer admin library
	Authentication / Session layer
	bad user list returned from CS2
B9066004	CryptoServer admin library
	Authentication / Session layer
	bad length of answer from CS2
B9066006	CryptoServer admin library
	Authentication / Session layer
	specified keysize does not match smartcard
B9066008	CryptoServer admin library
	Authentication / Session layer
	invalid parameter
B9066009	CryptoServer admin library
	Authentication / Session layer
	user already exists
B906600A	CryptoServer admin library
	Authentication / Session layer
	file already exists

Code	Description
B906600B	CryptoServer admin library
	Authentication / Session layer
	file open error
B906600C	CryptoServer admin library
	Authentication / Session layer
	file read error
B906600D	CryptoServer admin library
	Authentication / Session layer
	file write error
B906600E	CryptoServer admin library
	Authentication / Session layer
-	bad user backup data
B906600F	CryptoServer admin library
	Authentication / Session layer
	at least one user has been skipped
B9066010	CryptoServer admin library
	Authentication / Session layer
	long username not supported
B9066011	CryptoServer admin library
	Authentication / Session layer
	function not supported
B9066012	CryptoServer admin library
	Authentication / Session layer
	unknown hash algorithm
B9066013	CryptoServer admin library
	Authentication / Session layer
	only CRT sign supported
B9066014	CryptoServer admin library
	Authentication / Session layer
	illegal SM mechanism

Code	Description
B9066015	CryptoServer admin library
	Authentication / Session layer
	error decrypting session key
B9066016	CryptoServer admin library
	Authentication / Session layer
	buffer too small for signature
B9066017	CryptoServer admin library
	Authentication / Session layer
	too many concurrent SC authentications
B9066018	CryptoServer admin library
	Authentication / Session layer
	no public key found on smartcard
B9066019	CryptoServer admin library
	Authentication / Session layer
	illegal SM mode
B906601A	CryptoServer admin library
	Authentication / Session layer
	CryptoServer's signature could not be verified
B906601B	CryptoServer admin library
	Authentication / Session layer
	illegal format in auth keys file
B906601C	CryptoServer admin library
	Authentication / Session layer
	auth keys file does not contain key for this CryptoServer
B906601D	CryptoServer admin library
	Authentication / Session layer
	HSM auth key type not supported
B906601E	CryptoServer admin library
	Authentication / Session layer
	HSM auth key mode not supported

B90670xxx CryptoServer admin library CSL Command Interface B9067001 CryptoServer admin library CSL Command Interface invalid record length returned B9067002 CryptoServer admin library CSL Command Interface memory allocation error B9067003 CryptoServer admin library CSL Command Interface invalid data length returned B9067004 CryptoServer admin library CSL Command Interface password encryption failed B9067005 CryptoServer admin library CSL Command Interface invalid parameter B9067006 CryptoServer admin library CSL Command Interface buffer size too small B9067007 CryptoServer admin library CSL Command Interface invalid answer data B9068xxx CryptoServer admin library PKG Command Interface B9068001 CryptoServer admin library PKG Command Interface accessing directory failed B9068002 CryptoServer admin library PKG Command Interface filename too long	Code	Description
B9067001 CryptoServer admin library CSL Command Interface invalid record length returned  B9067002 CryptoServer admin library CSL Command Interface memory allocation error  B9067003 CryptoServer admin library CSL Command Interface invalid data length returned  B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface invalid parameter  B9067007 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068000 CryptoServer admin library PKG Command Interface accessing directory failed  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface	B9067xxx	CryptoServer admin library
CSL Command Interface invalid record length returned  B9067002 CryptoServer admin library CSL Command Interface memory allocation error  B9067003 CryptoServer admin library CSL Command Interface invalid data length returned  B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface buffer size too small  B9068000 CryptoServer admin library PKG Command Interface invalid answer data  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
invalid record length returned  B9067002 CryptoServer admin library	B9067001	CryptoServer admin library
B9067002 CryptoServer admin library CSL Command Interface memory allocation error  B9067003 CryptoServer admin library CSL Command Interface invalid data length returned  B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface buffer size too small  B9068007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
CSL Command Interface memory allocation error  B9067003 CryptoServer admin library CSL Command Interface invalid data length returned  B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		invalid record length returned
memory allocation error  B9067003 CryptoServer admin library	B9067002	CryptoServer admin library
B9067003 CryptoServer admin library CSL Command Interface invalid data length returned  B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
CSL Command Interface invalid data length returned  B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		memory allocation error
invalid data length returned  B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface	B9067003	CryptoServer admin library
B9067004 CryptoServer admin library CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
CSL Command Interface password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		invalid data length returned
password encryption failed  B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface	B9067004	CryptoServer admin library
B9067005 CryptoServer admin library CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
CSL Command Interface invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		password encryption failed
invalid parameter  B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface	B9067005	CryptoServer admin library
B9067006 CryptoServer admin library CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
CSL Command Interface buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		invalid parameter
buffer size too small  B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface	B9067006	CryptoServer admin library
B9067007 CryptoServer admin library CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
CSL Command Interface invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		buffer size too small
invalid answer data  B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface	B9067007	CryptoServer admin library
B9068xxx CryptoServer admin library PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		CSL Command Interface
PKG Command Interface  B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		invalid answer data
B9068001 CryptoServer admin library PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface	B9068xxx	CryptoServer admin library
PKG Command Interface accessing directory failed  B9068002 CryptoServer admin library PKG Command Interface		PKG Command Interface
accessing directory failed  B9068002 CryptoServer admin library  PKG Command Interface	B9068001	CryptoServer admin library
B9068002 CryptoServer admin library PKG Command Interface		PKG Command Interface
PKG Command Interface		accessing directory failed
	B9068002	CryptoServer admin library
filename too long		PKG Command Interface
		filename too long

Code	Description
B9068003	CryptoServer admin library
	PKG Command Interface
	open file failed
B9068004	CryptoServer admin library
	PKG Command Interface
	read file failed
B9068005	CryptoServer admin library
	PKG Command Interface
	write file failed/
B9068006	CryptoServer admin library
	PKG Command Interface
	memory allocation failed
B9068007	CryptoServer admin library
	PKG Command Interface
	directory contains no files
B9068008	CryptoServer admin library
	PKG Command Interface
	invalid package file
B9068009	CryptoServer admin library
	PKG Command Interface
	invalid package name
B906800A	CryptoServer admin library
	PKG Command Interface
	directory already exist
B906800B	CryptoServer admin library
	PKG Command Interface
	creating directory failed
B906800C	CryptoServer admin library
	PKG Command Interface
	Invalid parameter

Code	Description
B906800D	CryptoServer admin library
	PKG Command Interface
	No key specifier given
B906800E	CryptoServer admin library
	PKG Command Interface
	Invalid SingedLicenseFile name
B9068010	CryptoServer admin library
	PKG Command Interface
	Possible loop in state machine detected
B9068011	CryptoServer admin library
	PKG Command Interface
	Load file failed
B9068012	CryptoServer admin library
	PKG Command Interface
	different module names with the same id /abbrev - config mismatch
B9068013	CryptoServer admin library
	PKG Command Interface
	could not start firmware module(s)
B9068014	CryptoServer admin library
	PKG Command Interface
	CryptoServer firmware module(s) differs from archive content
B9068015	CryptoServer admin library
	PKG Command Interface
	Given flag forbids to perform a BLClear
B9068016	CryptoServer admin library
	PKG Command Interface
	base firmware is missing / incomplete
B9068017	CryptoServer admin library
	PKG Command Interface
	firmware module not contained in archive

Code	Description
B9068018	CryptoServer admin library
	PKG Command Interface
	firmware module is contained in archive but with different CPU type
B9068019	CryptoServer admin library
	PKG Command Interface
	CryptoServer in alarm state
B906801A	CryptoServer admin library
	PKG Command Interface
	cryptoserver remains in an undefined state
B906801B	CryptoServer admin library
	PKG Command Interface
	creating temporary directory failed
B906801C	CryptoServer admin library
	PKG Command Interface
	old CryptoServer SDK version not supported
B906801D	CryptoServer admin library
	PKG Command Interface
	verification of firmware package failed
B9068020	CryptoServer admin library
	PKG Command Interface
	bad auth/sm parameter
B9068021	CryptoServer admin library
	PKG Command Interface
	bad session
B9068022	CryptoServer admin library
	PKG Command Interface
	illegal flag parameter
B9068023	CryptoServer admin library
	PKG Command Interface
	package loader <-> CryptoServer model mismatch

Code	Description
B9069xxx	CryptoServer admin library
	MBK tools
B9069001	CryptoServer admin library
	MBK tools
	bad pkcs1 format
B9069002	CryptoServer admin library
	MBK tools
	buffer size too small
B9069003	CryptoServer admin library
	MBK tools
	invalid response length
B9069004	CryptoServer admin library
	MBK tools
	memory allocation failed
B9069005	CryptoServer admin library
	MBK tools
	unable to open file
B9069006	CryptoServer admin library
	MBK tools
	invalid file format
B9069007	CryptoServer admin library
	MBK tools
	invalid parameter
B9069008	CryptoServer admin library
	MBK tools
	aborted by user
B9069009	CryptoServer admin library
	MBK tools
	invalid answer data

Code	Description
B906900A	CryptoServer admin library
	MBK tools
	invalid key length
B906900B	CryptoServer admin library
	MBK tools
	no password given
B906900C	CryptoServer admin library
	MBK tools
	no session
B9069010	CryptoServer admin library
	MBK tools
	smartcard responds error
B9069011	CryptoServer admin library
	MBK tools
	record not found
B9069012	CryptoServer admin library
	MBK tools
	file not found
B9069013	CryptoServer admin library
	MBK tools
	access denied
B9069014	CryptoServer admin library
	MBK tools
	secure messaging failed
B9069015	CryptoServer admin library
	MBK tools
	invalid record length
B9069016	CryptoServer admin library
	MBK tools
	password verification failed

Code	Description
B9069017	CryptoServer admin library
	MBK tools
	smartcard is locked
B9069018	CryptoServer admin library
	MBK tools
	bad pin repetition
B9069019	CryptoServer admin library
	MBK tools
	null pin still active
B906902x	CryptoServer admin library
	invalid pin
B906Axxx	CryptoServer admin library
	cs2adm smartcard tools
B906A001	CryptoServer admin library
	cs2adm smartcard tools
	memory allocation failed
B906A002	CryptoServer admin library
	cs2adm smartcard tools
	bad device name
B906A003	CryptoServer admin library
	cs2adm smartcard tools
	too many open handles
B906A004	CryptoServer admin library
	cs2adm smartcard tools
	requested smc_id already in use
B906A005	CryptoServer admin library
	cs2adm smartcard tools
	channel is not open
B906A006	CryptoServer admin library
	cs2adm smartcard tools
	invalid data length

Code	Description
B906A007	CryptoServer admin library
	cs2adm smartcard tools
	buffer size too small
B906A008	CryptoServer admin library
	cs2adm smartcard tools
	smartcard is locked
B906A009	CryptoServer admin library
	cs2adm smartcard tools
	bad response from smartcard
B906A00A	CryptoServer admin library
	cs2adm smartcard tools
	unknown smartcard
B906A00B	CryptoServer admin library
	cs2adm smartcard tools
	function not supported for given cardtype
B906A00C	CryptoServer admin library
	cs2adm smartcard tools
	function not supported for given cardtype
B906A00D	CryptoServer admin library
	cs2adm smartcard tools
	bad parameter given
B906A00E	CryptoServer admin library
	cs2adm smartcard tools
	login condition for this function not supplied
B906A00F	CryptoServer admin library
	cs2adm smartcard tools
	keylength not suitable for given card
B906A010	CryptoServer admin library
	cs2adm smartcard tools
	invalid PIN length

Code	Description
B906A011	CryptoServer admin library
	cs2adm smartcard tools
	PIN file doesn't exist
B906A012	CryptoServer admin library
	cs2adm smartcard tools
	Null-PIN is still active
B906A01C	CryptoServer admin library
	cs2adm smartcard tools
	PIN is invalid, no tries left
B906A01D	CryptoServer admin library
	cs2adm smartcard tools
	PIN is invalid, 1 try left
B906A01E	CryptoServer admin library
	cs2adm smartcard tools
	PIN is invalid, 2 tries left
B906A01F	CryptoServer admin library
	cs2adm smartcard tools
	PIN is invalid, 3 or more tries left
B906A020	CryptoServer admin library
	cs2adm smartcard tools
	bad data from backup card
B906A021	CryptoServer admin library
	cs2adm smartcard tools
	more keyhalfs given than existing
B906A022	CryptoServer admin library
	cs2adm smartcard tools
	bad data structure on Siemens CardOS card
B906Bxxx	CryptoServer admin library
	NTP Module Command Interface

B906B001 CryptoServer admin library NTP Module Command Interface invalid Parameter  B906B002 CryptoServer admin library NTP Module Command Interface wrong response length from CS2  B906B003 CryptoServer admin library NTP Module Command Interface unable to convert time  B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file	Code	Description
invalid Parameter  B906B002 CryptoServer admin library NTP Module Command Interface wrong response length from CS2  B906B003 CryptoServer admin library NTP Module Command Interface unable to convert time  B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F005 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file	B906B001	CryptoServer admin library
B906B002 CryptoServer admin library NTP Module Command Interface wrong response length from CS2  B906B003 CryptoServer admin library NTP Module Command Interface unable to convert time  B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file		NTP Module Command Interface
NTP Module Command Interface wrong response length from CS2  B906B003 CryptoServer admin library NTP Module Command Interface unable to convert time  B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F005 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		invalid Parameter
wrong response length from CS2  B906B003 CryptoServer admin library NTP Module Command Interface unable to convert time  B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface	B906B002	CryptoServer admin library
B906B003 CryptoServer admin library NTP Module Command Interface unable to convert time  B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		NTP Module Command Interface
NTP Module Command Interface unable to convert time  B906C001		wrong response length from CS2
B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file	B906B003	CryptoServer admin library
B906C001 CryptoServer admin library NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		NTP Module Command Interface
NTP Module Command Interface there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		unable to convert time
there are no database entries in the given file  B906Fxxx CryptoServer admin library Clone Database Command Interface  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface	B906C001	CryptoServer admin library
B906Fxxx CryptoServer admin library Clone Database Command Interface  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  CryptoServer admin library Clone Database Command Interface		NTP Module Command Interface
Clone Database Command Interface  B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  CryptoServer admin library Clone Database Command Interface		there are no database entries in the given file
B906F002 CryptoServer admin library Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file	B906Fxxx	CryptoServer admin library
Clone Database Command Interface incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file		Clone Database Command Interface
incorrect structure of backup file  B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file	B906F002	CryptoServer admin library
B906F003 CryptoServer admin library Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface incorrect length of backup file		Clone Database Command Interface
Clone Database Command Interface unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		incorrect structure of backup file
unable to open backup file  B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface	B906F003	CryptoServer admin library
B906F004 CryptoServer admin library Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		Clone Database Command Interface
Clone Database Command Interface memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		unable to open backup file
memory allocation failed  B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface	B906F004	CryptoServer admin library
B906F005 CryptoServer admin library Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		Clone Database Command Interface
Clone Database Command Interface incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface		memory allocation failed
incorrect length of backup file  B906F006 CryptoServer admin library Clone Database Command Interface	B906F005	CryptoServer admin library
B906F006 CryptoServer admin library Clone Database Command Interface		Clone Database Command Interface
Clone Database Command Interface		incorrect length of backup file
	B906F006	CryptoServer admin library
cannot find search_key1		Clone Database Command Interface
		cannot find search_key1

Code	Description
B906F007	CryptoServer admin library
	Clone Database Command Interface
	cannot find search_key2
B906F008	CryptoServer admin library
	Clone Database Command Interface
	invalid length of snippet

# B908xxxx — LCD Display module

Code	Description
B9080001	LCD Display module
	string too long
B9080002	LCD Display module
	Cannot open another display
B9080003	LCD Display module
	timeout reached
B9080004	LCD Display module
	memory allocation failed
B9080005	LCD Display module
	display not open
B9080006	LCD Display module
	dsp_getexp cancelled
B9080007	LCD Display module
	parameter out of range

#### B90Axxxx - CSLAN

Code	Description
B90A01xx	CSLAN
	CSLAN Control Module
B90A0101	CSLAN
	CSLAN Control Module
	wrong parameter
B90A0102	CSLAN
	CSLAN Control Module
	system call failure
B90A0103	CSLAN
	CSLAN Control Module
	wrong permission for file operations
B90A0104	CSLAN
	CSLAN Control Module
	no relation between port and cs device
B90A0105	CSLAN
	CSLAN Control Module
	no such file
B90A0106	CSLAN
	CSLAN Control Module
	length mismatch for vchar parameter
B90A0107	CSLAN
	CSLAN Control Module
	operation aborted because cs has been reset
B90A0108	CSLAN
	CSLAN Control Module
	authentication failed
B90A0109	CSLAN
	CSLAN Control Module
	memory allocation failed

Code Desc	cription
B90A010A CSL	AN
CSL	AN Control Module
no s	serial number available
B90A010B CSL	AN
CSL	AN Control Module
Сгур	otoServer is locked
B90A010C CSL	AN
CSL	AN Control Module
Сгур	otoServer is already locked
B90A010D CSL	AN
CSL	AN Control Module
Сгур	otoServer lock denied (on loadbalancing ports)
B90A010E CSL	AN
CSL	AN Control Module
No s	space left on device for this operation
B90A010F CSL	AN
CSL	AN Control Module
To n	nany routes for the state device(s)
B90A0120 CSL	AN
CSL	AN Control Module
ksap	oi compatibility listener not found
B90A0121 CSL	AN
CSL	AN Control Module
none	existent subfunction code
B90A0201 CSL	AN
CSL	AN Control Module
illeg	al configuration file
B90A0301 CSL	AN
CSL	AN Control Module
que	ue full

Code	Description
B90A0302	CSLAN
	CSLAN Control Module
	no cryptoserver online
B90A0303	CSLAN
	CSLAN Control Module
	mismatch between real packet length and data length
B90A0304	CSLAN
	CSLAN Control Module
	connection table full
B90A0305	CSLAN
	CSLAN Control Module
	ksapi compatibility mapping not found

### B90Bxxxx - csadm Tool

Code	Description
B90B0001	csadm Tool
	memory allocation failed
B90B0002	csadm Tool
	NULL passphrase
B90B0003	csadm Tool
	passphrase repetition wrong
B90B0004	csadm Tool
	buffer size to small
B90B0005	csadm Tool
	command wrongly called
B90B0010	csadm Tool
	invalid number of arguments
B90B0011	csadm Tool
	invalid argument format
B90B0012	csadm Tool
	aborted by user
B90B0013	csadm Tool
	invalid argument length
B90B0014	csadm Tool
	invalid response length
B90B0015	csadm Tool
	invalid response data
B90B0020	csadm Tool
	invalid number of key parts

#### B90Cxxxx - CSXAPI

Code	Description
B90C0001	CSXAPI
	memory allocation failed
B90C0002	CSXAPI
	invalid data length
B90C0003	CSXAPI
	invalid response length
B90C0004	CSXAPI
	buffer size too small
B90C0005	CSXAPI
	invalid parameter value
B90C0006	CSXAPI
	maximum number of cached pins reached
B90C0007	CSXAPI
	invalid session
B90C01xx	CSXAPI
	Cluster API
B90C0101	CSXAPI
	Cluster API
	unable to open any device
B90C0102	CSXAPI
	Cluster API
	unable to logon to any device
B90C0103	CSXAPI
	Cluster API
	unable to execute command on any device
B90C0104	CSXAPI
	Cluster API
	unknown device name

Code	Description
B90C0105	CSXAPI
	Cluster API
	invalid connection parameter
B90C0106	CSXAPI
	Cluster API
	handle still in use
B90C1xxx	CSXAPI
	windows system error
B90C2xxx	CSXAPI
	unix system error

# **B90D**xxxx — ulog library

Code	Description
B90D0001	ulog library
	timeout reading socket
B90D1xxx	ulog library
	socket failed
B90D2xxx	ulog library
	bind failed
B90D3xxx	ulog library
	send failed
B90D4xxx	ulog library
	poll failed
B90D5xxx	ulog library
	recv failed

## **B90Exxxx** — Simple Database library

Code	Description
B90E0001	Simple Database library
	memory allocation failed
B90E0002	Simple Database library
	database file does not exist
B90E0003	Simple Database library
	record not found
B90E0004	Simple Database library
	record already exists
B90E0005	Simple Database library
	corrupted database file
B90E0006	Simple Database library
	bad database handle
B90E0007	Simple Database library
	bad info structure
B90E0008	Simple Database library
	bad data length
B90E0009	Simple Database library
	locking failed
B90E000A	Simple Database library
	invalid file name
B90E1xxx	Simple Database library
	open failed
B90E2xxx	Simple Database library
	creat failed
B90E3xxx	Simple Database library
	Iseek failed
B90E4xxx	Simple Database library
	read failed

Code	Description
B90E5xxx	Simple Database library
	write failed
B90E6xxx	Simple Database library
	creating mutex failed
B90E7xxx	Simple Database library
	locking mutex failed
B90E8xxx	Simple Database library
	locking file failed

#### B90Fxxxx — P11 admin library

Code	Description
B90F0001	P11 admin library
	memory allocation error
B90F0002	P11 admin library
	invalid parameter
B90F0003	P11 admin library
	insufficient buffer size
B90F0004	P11 admin library
	invalid key type
B90F0005	P11 admin library
	unable to open / create file
B90F0006	P11 admin library
	invalid mechanism
B90F0007	P11 admin library
	invalid key length
B90F1xxx	P11 admin library
	OpenSSL section
B90F2xxx	P11 admin library
	PKCS#11 section

#### B912xxxx — Host Service Daemon

Code	Description
B9120001	Host Service Daemon
	memory allocation error
B9120002	Host Service Daemon
	error on WSAStartup
B9120003	Host Service Daemon
	error on WSACleanup
B9120004	Host Service Daemon
	err creating mutex
B9120005	Host Service Daemon
	error creating socket
B9120006	Host Service Daemon
	socket creating error
B9120007	Host Service Daemon
	timeout
B9120008	Host Service Daemon
	connection was terminated
B9120009	Host Service Daemon
	invalid cmds data length
B912000A	Host Service Daemon
	invalid cmds header length
B912000B	Host Service Daemon
	invalid argument
B912000C	Host Service Daemon
	binding socket failed
B912000D	Host Service Daemon
	listen failed
B912000E	Host Service Daemon
	setsockopt failed

Code	Description
B912000F	Host Service Daemon
	bad configuration
B9120010	Host Service Daemon
	protocol error
B9120011	Host Service Daemon
	unable to load auxiliary library
B9120012	Host Service Daemon
	unable to create mutex
B9120013	Host Service Daemon
	unable to lock mutex
B9120014	Host Service Daemon
	unable to unlock mutex
B9120015	Host Service Daemon
	timeout while trying to lock mutex
B9121xxx	Host Service Daemon
	select error
B9122xxx	Host Service Daemon
	receive error
B9123xxx	Host Service Daemon
	send error
B9124xxx	Host Service Daemon
	control module
B9124001	Host Service Daemon
	control module
	wrong subfunction code
B9124002	Host Service Daemon
	control module
	bad control command
B9124003	Host Service Daemon
	control module
	authentication failed

Code	Description
B9124004	Host Service Daemon
	control module
	bad CryptoServer answer
B9125xxx	Host Service Daemon
	init failed

#### B915xxxx — dsp\_admin3 - DSP Daemon on CSLAN

Code	Description
B9150001	dsp_admin3 - DSP Daemon on CSLAN
	wrong parameter or parameter usage
B9150002	dsp_admin3 - DSP Daemon on CSLAN
	some of the manyfold time conversions failed (w/o userinteraction)
B9150003	dsp_admin3 - DSP Daemon on CSLAN
	some of the manyfold time conversions failed (w/ userinteraction)
B9150004	dsp_admin3 - DSP Daemon on CSLAN
	some provided buffer was too small
B9150042	dsp_admin3 - DSP Daemon on CSLAN
	some data struct could not be parsed internally
B91501xx	dsp_admin3 - DSP Daemon on CSLAN
	CryptoServer Administration section
B9150101	dsp_admin3 - DSP Daemon on CSLAN
	CryptoServer Administration section
	No Alarm prevailing
B9150102	dsp_admin3 - DSP Daemon on CSLAN
	CryptoServer Administration section
	Function not available in FIPS mode
B91502xx	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration section
B91503xx	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
B9150300	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	CSLAN Administration - Update - calcbase
B9150301	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	Extraction of archive failed

Code	Description
B9150302	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	Not a CSLAN OS archive file.
B9150303	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	Did not find expected indicator in archive.
B9150304	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	Wrong/missing <partition> argument</partition>
B9150305	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	Can't mount user1/user2
B9150306	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	Could not touch INIT-COPY-CONFIG ActionFile
B9150307	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	Post update script returned error
B915037F	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	sh could not be executed
B91503FF	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - Update
	file was no .tar.gz (old msg)
B91504xx	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
B9150400	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
	CSLAN Administration - ActionFiles - calcbase

Code	Description
B9150401	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
	Wrong/missing <command/> argument
B9150402	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
	Wrong/missing <actionfile> argument</actionfile>
B9150403	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
	Wrong/missing <partition> argument</partition>
B9150404	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
	prevailing actionFile
B9150405	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
	can't mount target user1/user2
B915047F	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - ActionFiles
	sh could not be executed
B91505xx	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
B9150500	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
	CSLAN Administration - SNMP - calcbase
B9150501	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
	Wrong/missing <command/> argument
B9150502	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
	Failed to write /etc/sysconfig/snmpd

Code	Description
B9150503	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
	Failed to write /etc/sysconfig/trapd
B9150504	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
	Failed to write /etc/snmp/snmpd.conf
B915057F	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
	sh could not be executed
B91505FF	dsp_admin3 - DSP Daemon on CSLAN
	CSLAN Administration - SNMP
	fork(2) failed
B91506xx	dsp_admin3 - DSP Daemon on CSLAN
	Error Code from Linux:

#### B916xxxx — Host API CTS - Crypto Timestamp

Code	Description
B9164001	Host API CTS - Crypto Timestamp
	Environment variable CRYPTOSERVER not set
B9164002	Host API CTS - Crypto Timestamp
	Environment variable CRYPTOSERVER not configured for TCP
B9164003	Host API CTS - Crypto Timestamp
	Incorrect function arguments given
B9164004	Host API CTS - Crypto Timestamp
	Error occurred while encoding the timestamp request
B9164005	Host API CTS - Crypto Timestamp
	Given input buffer is too small to copy encoded data
B9164006	Host API CTS - Crypto Timestamp
	Incorrect data received from TimestampServer
B9164007	Host API CTS - Crypto Timestamp
	Error returned from the TimestampServer
B9164008	Host API CTS - Crypto Timestamp
	Cannot open file
B9164009	Host API CTS - Crypto Timestamp
	given data is not pkcs7 encoded
B916400A	Host API CTS - Crypto Timestamp
	only signed and signedAndEnveloped PKCS7 types supported
B916400B	Host API CTS - Crypto Timestamp
	given data contains more than one certificate
B916400C	Host API CTS - Crypto Timestamp
	given data contains no certificate
B916400D	Host API CTS - Crypto Timestamp
	given data contains no plain certificate
B916400E	Host API CTS - Crypto Timestamp
	Given TimeStamp structure is not a valid ASN.1 format

Code	Description
B916400F	Host API CTS - Crypto Timestamp
	Unsupported hash algorithm
B9164010	Host API CTS - Crypto Timestamp
	Calculated hash value does not match with the hash value contained in the
	TimeStamp
B9164011	Host API CTS - Crypto Timestamp
	given memory buffer too small or invalid length returned from the CSLAN
B9164012	Host API CTS - Crypto Timestamp
	can't allocate memory
B9164013	Host API CTS - Crypto Timestamp
	Error while reading/writing PKCS7 data
B9164014	Host API CTS - Crypto Timestamp
	Given timestamp contains no timestamp token (maybe error in request?)
B9164015	Host API CTS - Crypto Timestamp
	invalid hash length
B9164016	Host API CTS - Crypto Timestamp
	invalid http response
B9164100	Host API CTS - Crypto Timestamp
	tcp: init error
B9164101	Host API CTS - Crypto Timestamp
	tcp: incorrect IP address
B9164102	Host API CTS - Crypto Timestamp
	tcp: incorrect hostname
B9164103	Host API CTS - Crypto Timestamp
	tcp: incorrect port number
B9164104	Host API CTS - Crypto Timestamp
	tcp: connection timeout
B9164105	Host API CTS - Crypto Timestamp
	tcp: connection closed by remote host
B91642xx	Host API CTS - Crypto Timestamp
	tcp: can't create socket

Code	Description
B91643xx	Host API CTS - Crypto Timestamp
	tcp: can't get connection
B91644xx	Host API CTS - Crypto Timestamp
	tcp: recv error
B91645xx	Host API CTS - Crypto Timestamp
	tcp: send error
B91646xx	Host API CTS - Crypto Timestamp
	tcp: select error
B9164800	Host API CTS - Crypto Timestamp
	tcp: select error
	HTTP error
B9164990	Host API CTS - Crypto Timestamp
	tcp: select error
	HTTP error 400: Bad Request
B9164993	Host API CTS - Crypto Timestamp
	tcp: select error
	HTTP error 403: Forbidden
B9164994	Host API CTS - Crypto Timestamp
	tcp: select error
	HTTP error 404: Not Found
B9164995	Host API CTS - Crypto Timestamp
	tcp: select error
	HTTP error 405: Method not allowed
B91649F4	Host API CTS - Crypto Timestamp
	tcp: select error
	HTTP error 500: Server error
B91649F7	Host API CTS - Crypto Timestamp
	tcp: select error
	HTTP error 503: Service unavailable

## **B917**xxxx — CryptoServer Protocol Daemon

Code	Description
B9170001	CryptoServer Protocol Daemon
	memory allocation error
B9170002	CryptoServer Protocol Daemon
	invalid parameter
B9170003	CryptoServer Protocol Daemon
	bad configuration
B9170004	CryptoServer Protocol Daemon
	can't open any device
B9170005	CryptoServer Protocol Daemon
	timeout
B9170006	CryptoServer Protocol Daemon
	connection was terminated
B9170007	CryptoServer Protocol Daemon
	invalid command data length
B9170008	CryptoServer Protocol Daemon
	protocol error
B9170009	CryptoServer Protocol Daemon
	maximum number of connections reached
B917000A	CryptoServer Protocol Daemon
	can't open file
B917000B	CryptoServer Protocol Daemon
	buffer size too small
B917001x	CryptoServer Protocol Daemon
	mutex section
B9170012	CryptoServer Protocol Daemon
	mutex section
	unable to create mutex

Code	Description
B9170013	CryptoServer Protocol Daemon
	mutex section
	timeout while trying to lock mutex
B9170014	CryptoServer Protocol Daemon
	mutex section
	unable to lock mutex
B9170015	CryptoServer Protocol Daemon
	mutex section
	atempt to lock mutex timed out
B9170016	CryptoServer Protocol Daemon
	mutex section
	unable to unlock mutex
B917002x	CryptoServer Protocol Daemon
	control module
B9170021	CryptoServer Protocol Daemon
	control module
	wrong subfunction code
B9170022	CryptoServer Protocol Daemon
	control module
	bad control command
B9170023	CryptoServer Protocol Daemon
	control module
	authentication failed
B9170024	CryptoServer Protocol Daemon
	control module
	bad CryptoServer answer
B9170025	CryptoServer Protocol Daemon
	control module
	invalid parameter
B9171xxx	CryptoServer Protocol Daemon
	TCP error

Code	Description
B9172xxx	CryptoServer Protocol Daemon
	system error

#### **B918**xxxx — CryptoServer Protocol Daemon

Code	Description
B9180001	CryptoServer Protocol Daemon
	memory allocation error
B9180002	CryptoServer Protocol Daemon
	invalid parameter
B9180003	CryptoServer Protocol Daemon
	bad configuration
B9180004	CryptoServer Protocol Daemon
	can't open any device
B9180005	CryptoServer Protocol Daemon
	timeout
B9180006	CryptoServer Protocol Daemon
	connection was terminated
B9180007	CryptoServer Protocol Daemon
	invalid command data length
B9180008	CryptoServer Protocol Daemon
	protocol error
B9180009	CryptoServer Protocol Daemon
	maximum number of connections reached
B918000A	CryptoServer Protocol Daemon
	can't open file
B918000B	CryptoServer Protocol Daemon
	buffer size too small
B918000C	CryptoServer Protocol Daemon
	authentication failed
B9180010	CryptoServer Protocol Daemon
	invalid command length
B9180011	CryptoServer Protocol Daemon
	invalid function code

Code	Description
B9180012	CryptoServer Protocol Daemon
	invalid sub-function code
B918002x	CryptoServer Protocol Daemon
	mutex section
B9180022	CryptoServer Protocol Daemon
	mutex section
	unable to create mutex
B9180023	CryptoServer Protocol Daemon
	mutex section
	timeout while trying to lock mutex
B9180024	CryptoServer Protocol Daemon
	mutex section
	unable to lock mutex
B9180025	CryptoServer Protocol Daemon
	mutex section
	atempt to lock mutex timed out
B9180026	CryptoServer Protocol Daemon
	mutex section
	unable to unlock mutex
B9181xxx	CryptoServer Protocol Daemon
	TCP error
B9182xxx	CryptoServer Protocol Daemon
	system error

#### **B91Cxxxx** — CryptoServer PKCS11 API

Description
CryptoServer PKCS11 API
CryptoServer command size exceeded
CryptoServer PKCS11 API
Unknown authentication method
CryptoServer PKCS11 API
Invalid authentication credentials
CryptoServer PKCS11 API
Unknown hash algorithm
CryptoServer PKCS11 API
Malformed answer of CryptoServer
CryptoServer PKCS11 API
Number of login strings < 2
CryptoServer PKCS11 API
Login string too long
CryptoServer PKCS11 API
Invalid login string
CryptoServer PKCS11 API
CryptoServer handle lost

## B91Dxxxx — PIN pad API

Code	Description
B91D0001	PIN pad API
	memory allocation failed
B91D0002	PIN pad API
	invalid PIN pad type
B91D0003	PIN pad API
	no device found
B91D0004	PIN pad API
	bad device name
B91D0005	PIN pad API
	too may open connections
B91D0006	PIN pad API
	bad handle
B91D0007	PIN pad API
	invalid parameter
B91D0008	PIN pad API
	requested feature is not supported
B91D0009	PIN pad API
	connection is not open
B91D000A	PIN pad API
	timeout occurred
B91D000B	PIN pad API
	action canceled
B91D000C	PIN pad API
	invalid data length
B91D000D	PIN pad API
	bad PIN repetition
B91D000E	PIN pad API
	invalid buffer size

Code	Description
B91D000F	PIN pad API
	protocol error
B91D0010	PIN pad API
	bad ICC state
B91D0011	PIN pad API
	bad data length returned from ICC
B91D0012	PIN pad API
	bad response recieved from ICC
B91D0013	PIN pad API
	no smartcard inserted
B91D0020	PIN pad API
	USB driver is not running
B91D0021	PIN pad API
	USB open failed
B91D0022	PIN pad API
	USB write failed
B91D0023	PIN pad API
	USB read failed
B91D0024	PIN pad API
	USB is not available
B91D0030	PIN pad API
	bad input
B91D0031	PIN pad API
	access denied
B91D0032	PIN pad API
	no reader connected
B91D0041	PIN pad API
	JCOP simulator send/receive timeout
B91D0044	PIN pad API
	JCOP simulator unknown error

Code	Description
B91D1xxx	PIN pad API
	PC/SC
B91D2xxx	PIN pad API
	MKT
B91D3xxx	PIN pad API
	CP8
B91D4xxx	PIN pad API
	ACR80
B91D5xxx	PIN pad API
	USB
B91D6xxx	PIN pad API
	CCID
B91D7xxx	PIN pad API
	cyberJack
B91D8xxx	PIN pad API
	JCOP

## **B91Exxxx** — copa Config Parser

Code	Description
B91E0000	copa Config Parser
	Cant open/access configuration file
B91E0100	copa Config Parser
	line from input file to long
B91E0101	copa Config Parser
	No matching ] found
B91E0102	copa Config Parser
	No = after variable found
B91E0103	copa Config Parser
	No value for variable after = found
B91E0104	copa Config Parser
	No Matching ör' found
B91E0105	copa Config Parser
	No valid Hex Number after \$
B91E0106	copa Config Parser
	not all hex codes are two byte
B91E0107	copa Config Parser
	No Value in List found
B91E0108	copa Config Parser
	second char after \$ is no valid hex value
B91E0109	copa Config Parser
	One of the list elements it not in the config file
B91E0110	copa Config Parser
	One of the config file elements it not in the list
B91E0111	copa Config Parser
	Value is not a Boolean value
B91E0112	copa Config Parser
	Value is not an Integer number

Code	Description
B91E0113	copa Config Parser
	Char in String is non printable
B91E0114	copa Config Parser
	strol returns long, the result does not fit in int
B91E0115	copa Config Parser
	strol returns variable is out of range

#### **B920xxxx** — CryptoServer Core API Cxi

Code	Description
B9200001	CryptoServer Core API Cxi
	memory allocation failed
B9200002	CryptoServer Core API Cxi
	invalid parameter
B9200003	CryptoServer Core API Cxi
	invalid parameter length
B9200004	CryptoServer Core API Cxi
	parameter out of range
B9200005	CryptoServer Core API Cxi
	buffer size too small
B9200006	CryptoServer Core API Cxi
	invalid answer length
B9200007	CryptoServer Core API Cxi
	invalid format of answer data
B9200008	CryptoServer Core API Cxi
	unterminated string
B9200009	CryptoServer Core API Cxi
	string conversion failed
B920000A	CryptoServer Core API Cxi
	object/item not found
B920000B	CryptoServer Core API Cxi
	compare failed
B920000C	CryptoServer Core API Cxi
	invalid algorithm
B920000D	CryptoServer Core API Cxi
	invalid state
B920000E	CryptoServer Core API Cxi
	file error

Code	Description
B920000F	CryptoServer Core API Cxi
	user does not exist
B9200010	CryptoServer Core API Cxi
	operation not supported
B9200011	CryptoServer Core API Cxi
	invalid key
B9200012	CryptoServer Core API Cxi
	I/O error
B9200013	CryptoServer Core API Cxi
	log access error
B9200014	CryptoServer Core API Cxi
	database access error
B9200015	CryptoServer Core API Cxi
	invalid ASN.1 format
B9200016	CryptoServer Core API Cxi
	memory corruption
B9200017	CryptoServer Core API Cxi
	invalid number of mechs
B9201xxx	CryptoServer Core API Cxi
	system error

#### B980xxxx — java CryptoServer API

Code	Description
B9800001	java CryptoServer API
	Connection terminated by remote host
B9800002	java CryptoServer API
	Bad block length received
B9800003	java CryptoServer API
	Bad answer length
B9800004	java CryptoServer API
	Bad tag of answer block
B9800005	java CryptoServer API
	Too many authentications
B9800006	java CryptoServer API
	Bad length of password
B9800007	java CryptoServer API
	Can't translate user name
B9800008	java CryptoServer API
	Hash algo not available
B9800009	java CryptoServer API
	Could not get challenge
B980000A	java CryptoServer API
	JCE Provider not found
B980000B	java CryptoServer API
	JCE Key Exception (Jurisdiction files installed?)
B980000C	java CryptoServer API
	JCE Exception
B980000D	java CryptoServer API
	Secure Messaging failed
B980000E	java CryptoServer API
	Unknown SM mode

Code	Description
B980000F	java CryptoServer API
	Bad session key decryption
B9800010	java CryptoServer API
	JNI Interface Error
B9800011	java CryptoServer API
	Bad parameter
B9800012	java CryptoServer API
	Missung authentication
B9800013	java CryptoServer API
	Unsupported encoding
B9800014	java CryptoServer API
	Invalid data length
B9800015	java CryptoServer API
	Can't decrypt key file
B9800016	java CryptoServer API
	I/O Error
B9800017	java CryptoServer API
	No device specified
B9800018	java CryptoServer API
	Invalid authentication mechanism
B980002x	java CryptoServer API
	CryptoServer Cluster API
B9800021	java CryptoServer API
	CryptoServer Cluster API
	Unable to open any CryptoServer
B9800022	java CryptoServer API
	CryptoServer Cluster API
	Unable to logon to any CryptoServer
B9800023	java CryptoServer API
	CryptoServer Cluster API
	Unable to execute command on any CryptoServer

Code	Description
B98001xx	java CryptoServer API
	RSA Key class
B9800101	java CryptoServer API
	RSA Key class
	Malformed RSA Key file
B9800102	java CryptoServer API
	RSA Key class
	Decryption failed
B98002xx	java CryptoServer API
	CryptoServer Smartcard API
B9800200	java CryptoServer API
	CryptoServer Smartcard API
	Smartcard returned error status
B9800201	java CryptoServer API
	CryptoServer Smartcard API
	bad padding
B9800202	java CryptoServer API
	CryptoServer Smartcard API
	invalid specifier
B98003xx	java CryptoServer API
	CryptoServer Database API
B9800300	java CryptoServer API
	CryptoServer Database API
	JNI Interface Error

# B981xxxx — Java CryptoServer API CXI

Code	Description
B9810000	Java CryptoServer API CXI
	invalid parameter
B9810001	Java CryptoServer API CXI
	bad key name
B9810002	Java CryptoServer API CXI
	key name required for internal storage
B9810003	Java CryptoServer API CXI
	internal charset converting error
B9810004	Java CryptoServer API CXI
	bad key token
B9810005	Java CryptoServer API CXI
	malformed answer block of CryptoServer
B9810006	Java CryptoServer API CXI
	bad key attributes from CryptoServer
B9810007	Java CryptoServer API CXI
	bad algorithm
B9810008	Java CryptoServer API CXI
	bad user name
B9810009	Java CryptoServer API CXI
	missing device entry
B981000A	Java CryptoServer API CXI
	key component not found
B981000B	Java CryptoServer API CXI
	key not found
B981000C	Java CryptoServer API CXI
	version of CryptoServerAPI too small
B981000D	Java CryptoServer API CXI
	no EC parameter data available

Code	Description
B981000E	Java CryptoServer API CXI
	no output IV available
B981000F	Java CryptoServer API CXI
	firmware version too small
B9810010	Java CryptoServer API CXI
	ASN.1 decoding error
B9810011	Java CryptoServer API CXI
	JCE AES decrypt error
B9810020	Java CryptoServer API CXI
	bad ECC parameter
B9810030	Java CryptoServer API CXI
	config item missing
B9810040	Java CryptoServer API CXI
	invalid data length
B9810050	Java CryptoServer API CXI
	invalid number of mechs

#### B982xxxx — Database API Java

Code	Description
B9820000	Database API Java
	JNI Interface Error

#### B983xxxx — PinPad API Java

Code	Description
B9830000	PinPad API Java
	JNI Interface Error
B9830001	PinPad API Java
	invalid specifier

## **B984xxx** — JCA/JCE provider

Code	Description
B9840002	JCA/JCE provider
	KeyStorePath

#### **B985**xxxx — CryptoServerAPI.NET

Code	Description
B9850001	CryptoServerAPI.NET
	Invalid parameter
B9850002	CryptoServerAPI.NET
	Invalid authentication mechanism
B985002x	CryptoServerAPI.NET
	CryptoServer Cluster API
B9850021	CryptoServerAPI.NET
	CryptoServer Cluster API
	Unable to open any CryptoServer
B9850022	CryptoServerAPI.NET
	CryptoServer Cluster API
	Unable to logon to any CryptoServer
B9850023	CryptoServerAPI.NET
	CryptoServer Cluster API
	Unable to execute command on any CryptoServer

#### B986xxxx — CryptoServer API CXI.NET

Description
CryptoServer API CXI.NET
invalid parameter
CryptoServer API CXI.NET
memory allocation failed
CryptoServer API CXI.NET
invalid state
CryptoServer API CXI.NET
malformed answer block of CryptoServer
CryptoServer API CXI.NET
key not found
CryptoServer API CXI.NET
no output IV available
CryptoServer API CXI.NET
config item missing



#### Contact

Utimaco IS GmbH Germanusstraße 4 D - 52080 Aachen Germany

phone +49 241 1696 - 200 fax +49 241 1696 - 199

web http://hsm.utimaco.com email support-cs@utimaco.com