

Instructions:

- 1. When designing the layout, holes must be placed at the 4 locations specified for connecting the PCB to the ground plane. The holes are located 10 mm away from the top and bottom edges and 7 mm away from the side edges.
- 2. The blue circles represent the SMA connector locations. They are located such that the input is to the left side and output to the right.
- 3. The transistor is oriented with the Gate at top left and drain at bottom right side.

For further clarifications, contact the course assistant.