ddCtr_prm.h

-enum: drvList = [DRV_GEN, ..., DRV_END]
+drvGetFunc[DRV_END]: ptrGetDrv = [getGenericoDriver, ...]



- -driversLoaded[QNTD_DRV]: static driver*
- -qntDrvLoaded: char
- -initCtrDrv(): char
- -callDriver(drv id:char,func id:char,parameters:void*): char
- -initDriver(newDriver:char): char