







FREEswing eTouch®

by Kesseböhmer




<http://support.kesseboehmer.de/freelift-etouch>







i

„mm“







1





2






403721 0000

06/2016

12.0001.010.434.0000.00

KESSEBÖHMER


3



403721 0000

4

PZ 2






06/2016

12.0001.010.434.0000.00

KESSEBÖHMER





5




6



PZ 2




7



403721 0000

8




06/2016


12.0001.010.434.0000.00

KESSEBÖHMER


9



10



11




5 mm



9 mm




„mm“



403721 0000

12






06/2016

12.00001.010.434.0000.00



KESSEBÖHMER

13





403721 0000




06/2016

12.0001.010.434.0000.00

KESSEBÖHMER

14



i

