Would-be PDM User instructions



Would-be PDM - general



- This software was born to create a tool to manage CAD files and to join CAD with SVN technology
- SVN is used to manage the version and the history of the files
- The SVN tool choosed for Would-be PDM is tortoise SVN (https://tortoisesvn.net)

Would-be PDM - prerequisites




- We assume you already have:
- TortoiseSVN (https://tortoisesvn.net) installed
- A SVN server (if you work alone tortoises vn can do as server); we tested visuals vn server and it works fine (https://www.visualsvn.com/server/)
- · A working folder
- · Skills on CAD macros
- · A lot of patience for our bugs



- Create the directory in the final disk (we suggest a local disk); i.e. C: Work Would-Be PDM
- · Rightclick the directory
- Select SVN Checkout




• Select the SVN repository





· Your directory appears like:




.svn


• it should be an empty dir with only one hidden subdir (.svn)

• Now you can install the software (Would-be PDM)



- Download the installer (Would-be_installer.msi) from github (https://github.com/robertobartola/WouldBePDM)
- Run the installer









- Select «Custom» installation
- We suggest NOT to install the example data, yet. You can add them later

• Browse target dir and select the dir of page 5









• Click Next


• Click Install








• Complete the installation







· You should get:

• Directory WouldBePDMData - the data directory

• JPG - sub dir containing images

• PDF - sub dir containing pdf drawings

• STEP - sub dir containing 3D exported files


• export_prt_list.xlsm - to create/edit your xml data base

· license.rtf - GNU-GPL license

• WouldBe_PDM_sharpdev.exe - the program


• WouldBeCFG.xml - the configuration file

• WouldBeXML.xml - the XML data base





- · Add to ignore list the following files (select hitting ctrl key and rightclick)
 - license.rtf
 - WouldBe_PDM_sharpdev.exe
 - · WouldBe(F(1.xml




🚵 WouldBePDMData

🚮 export_prt_list.xlsm

Ignore 3 items by name




• Right click on the white space and select SVN Commit...






Add a message and click
 OK


· And OK







• You get:



· And sub dir:




• If you don't need sample files skip next pages and jump to page 18


Would-be PDM - the samples



• If you want to add sample files run the installer again and select Change

• Select The Example data





Would-be PDM - the samples




- Click Next
- Click Change
- · Click OK



Would-be PDM - the samples



- · Now Commit all the files by right click
- Select SVN Commit...
- Slect All
- Write the message
- · Click OK



SVN Update SVN Commit...




- · Now you can play with Would-be PDM.
- Please remember to commit the files once they are OK




- You find 2 tabs (the Debug is temporary tab):
- PDM to select and manage the files

• Config - to configure your settings





- You can select Family -> Project -> Product -> Component
- · For each step you can have some property shown
- Possible will appear would-be PDM Step by step Status





• With Config tab you could customize your directories and the CAD exe and environment files

• If WouldBeCFG.xml does not exist you can create it by clicking Save cfg

Drectories CAD files dir			UG NX	TOP (i.e. V8)	
WouldBePDMData	Change		EXE	TUP (i.e. V8)	
PDF files dir				ram Files\Siemens\NX 10.0\UGII\ugraf.exe	Change
PDF	Change	Note: I assume that PDF dir.			
TEP files dir		STEP dir and JPG dir			
TEP	Change	are subdir of CAD dir.			
PG files dir		_ Thank you			
PG	Change		UG NX LOW (i.e. V4)		
		_	C:\swbase\plmsw\nx85\UGII\ugraf.exe		
Product (customer) drawing dir					
	Change				
		9			
-					
CATIA TOP (i.e. V5.24)					
CATIA TOP (i.e. V5.24) EXE dir	24\win b64\code\bin				Change
CATIA TOP (i.e. V5.24)	24\win_b64\code\bin			ENV	Change
CATIA TOP (i.e. V5.24) EXE dir C:\Program Files\Dassault Systemes\B2	24\win_b64\code\bin		Change	ENV C:\ProgramD ata\D assaultSystemes\CATEriv	Change Change
CATIA TOP (i.e. V5.24) EXE dir C:\Program Files\Dassault Systemes\B2 ENV folder CATIA.V5-6R2014.B24_RB	24\win_b64\code\bin		Change		
CATIA TOP (i.e. V5.24) EXE dir C:\Program Files\Dassault Systemes\B2 ENV folder CATIA.V5-6R2014.B24_RB	24\win_b64\code\bin		Change		
CATIA TOP (i.e. V5.24) EXE di CX-Program Files\Dassault Systemes\B2 ENV folder CATIA V5-6R2014-B24_RB CATIA LOW (i.e. V5.19) EXE dir			Change		Change
CATIA TOP (i.e. V5.24) EXE di C.V.Program Files VD assault Systemes\B2 ENV folder CATIA V5-6R2014.B24_RB CATIA LOW (i.e. V5.19)			Change		
C:\Program Files\Dassault Systemes\B2 ENV folder CATIA.V56R2014.B24_RB CATIA.UOW (i.e. V5.19) EXE dir C:\Program Files\Dassault Systemes\B1 C:\Program Files\Dassault Systemes\B1			Change	C:\ProgramD ata\D assaultSystemes\CATErv	Change



Thank you and Enjoy while using

Would-be PDM

Roberto