




## TEMPERATURE COMPENSATED REAL TIME CLOCK REFERENCE DESIGN KIT QUICK-START GUIDE










After the installation is complete, click the Browse Documentation button. Choose the Temperature Compensated RTC link on the left pane. Then choose the User's Guide.





If you are having trouble installing and/or using the reference design kit, please use the following support resources:

- 1. Temperature Compensated RTC Reference Design Kit User's Guide (included in the reference design kit CD)
- 2. AN293: Temperature Compensated RTC Reference Design Programmer's Guide (included in the reference design kit CD)
- 3. MCU Knowledgebase (available at www.silabs.com → SUPPORT)
- 4. Contact an Applications Engineer using the online information request form (available at www.silabs.com → SUPPORT).