# DIGITAL COMPASS REFERENCE DESIGN QUICK-START GUIDE

1 Place the AAA batteries in the battery holder (noting the proper orientation).


2 Tap the ENTER button.

**3** The direction and absolute information (degrees minutes format) will be displayed.

4 To use the Compass board with the Software PC application, install the CP210x drivers (instructions are in the User's Guide) and PC application from the Kit CD.


5 Connect the board to the PC's USB bus.

6 Tap the ENTER button.

7 The direction and absolute information (degrees minutes format) will be displayed as well as the USB symbol. Launch the Compass application and connect to the board.

Refer to the documents included on the Digital Compass Reference Design Kit CD in the Documentation folder for more information. The CP210x drivers for the Compass board USB support can also be found on the Kit CD.

Rev. 0.1 7/06