

Figure 8-24 IBM_RSC User ID Properties

8.5.4 LDAP Authentication

Before LDAP authentication is selected, the HMC must first be configured to access a LDAP server:

1. Select Configure LDAP on the WUI panel under Administration as show in Figure 8-25.




Figure 8-25 Configure LDAP WUI Selection

- 2. The window shown in Figure 8-26 on page 229 opens. Perform the following actions:
 - a. Select the Enable LDAP box.
 - b. Provide the Primary Unified Resource Identifier (URI), and optionally, the Backup URI.
 - c. Choose either TLS Encryption or Non-Anonymous Binding.