9.3.7 Physical icon

The topics in this section present information that is related to monitoring and manipulating physical volumes in the TS7740 and TS7720T clusters. To view or modify settings for physical volume pools to manage the physical volumes that are used by the tape-attached clusters, use the window that is shown in Figure 9-57.




Figure 9-57 Physical icon

Physical Volume Pools

The Physical Volume Pools properties table displays the media properties and encryption settings for every physical volume pool that is defined for a specific TS7700T cluster in the grid. This table contains these tabs:

- Pool Properties
- Encryption Settings

Tip: Pools 1 - 32 are preinstalled and initially set to default attributes. Pool 1 functions as the default pool and is used if no other pool is selected.

Figure 9-58 on page 429 show an example of the Physical Volume Pools window. There is a link that is available for a tutorial showing how to modify pool encryption settings. Click the link to see the tutorial material. This window is visible but disabled on the TS7700 MI if the grid possesses a physical library, but the selected cluster does not. This message is displayed:

The cluster is not attached to a physical tape library.