RG	Adapter locations	PCle+ I/O drawer	PCHIDs
RG2 Right	LG12, LG14, LG17, and LG19	1	120-121,128-129,130-131,138-139
		2	160-161,168-169,170-171,178-179
		3	1A0-1A1,1A8-1A9,1B0-1B1,1B8-1B9
		4	1E0-1E1,1E8-1E9,1F0-1F1,1F8-1F9
		5	220-221,228-229,230-231,238-239
		6	260-261,268-269,270-271,278-279
		7	2A0-2A1,2A8-2A9,2B0-2B1,2B8-2B9
		8	2E0-2E1,2E8-2E9,2F0-2F1,2F8-2F9
		9	320-321,328-329,330-331,338-339
		10	360-361,368-369,370-371,378-379
		11	3A0-3A1,3A8-3A9,3B0-3B1,3B8-3B9
		12	3E0-3E1,3E8-3E9,3F0-3F1,3F8-3F9
RG3 Left	LG03, LG05, LG08, and LG10	1	104-105,10C-10D,114-115,11C-11D
		2	144-145,14C-14D,154-155,15C-15D
		3	184-185,18C-18D,194-195,19C-19D
		4	1C4-1C5,1CC-1CD,1D4-1D5,1DC-1DD
		5	204-205,20C-20D,214-215,21C-21D
		6	244-245,24C-24D,254-255,25C-25D
		7	284-285,28C-28D,294-295,29C-29D
		8	2C4-2C5,2CC-2CD,2D4-2D5,2DC-2DD
		9	304-305,30C-30D,314-315,31C-31D
		10	344-345,34C-34D,354-355,35C-35D
		11	384-385,38C-38D,394-395,39C-39D
		12	3C4-3C5,3CC-3CD,3D4-3D5,3DC-3DD