5. When the key servers details are all entered, the USB flash drive encryption configuration window opens. In this step, master encryption key copies are stored in the USB flash drives. If there are fewer than three drives that are detected, the system requests that you plug in more USB flash drives, as shown on Figure 12-52. You cannot proceed until the required minimum number of USB flash drives is detected by the system.




Figure 12-52 Prompt to insert USB flash drives