7. The Retrieve activation codes window opens, which shows the license activation codes for the storage image, as shown in Figure 9-12. Print the activation codes or click **Download now** to save the activation codes in an XML file that you can import into the DS8000.




Figure 9-12 DSFA Retrieve activation codes window

8. Click **Settings** → **System** → **Licensed Functions** → **Activate** in the GUI to enter the activation codes after the initial installation. Click on the black symbol to import the XML file, or alternatively, you can enter individual license keys, as shown in Figure 9-13.




Figure 9-13 Activating additional licenses in the GUI