

Figure 5-88. *Lines are taut in the center.* 



Figure 5-89. Fold tail back for wind channel.




Figure 5-90. "S" fold drawing.

11. Pull the top center cell panel down to the bottom of the stack.



Figure 5-91. Packing paddle at 1/3rd location.



Figure 5-92. Creating the "S" fold.

- 12. Wrap the center cell around the folded canopy with the left and right about halfway to the center, then secure with clamps starting at the bottom. [Figure 5-93] The width of the folded canopy should be the width of the D-bag plus 2 inches (5cm).
- 13. Continue to wrap the center cell around the canopy stack and secure with additional clamps. [Figure 5-94]

Step 5. Placing the Canopy into the Deployment Bag and Stowing the Lines

- 1. Lift the base of the folded canopy and slide the reserve bag underneath. The grommets in the tongue of the bag should be even with the bottom of the stack. [Figure 5-95]
- 2. Make a second "S" fold to match Figure 5-96.
- 3. Split the loose fabric at the top to form two "ears." [Figure 5-97]
- 4. Gather the center cell material along the middle seam until you reach the bottom. Roll the material under, but do not cover the center cell. [Figure 5-98]