

Figure 5-15. *Cartridge/pneumatic starter schematic.*

The starter generator internal circuit has four field windings: a series field (C field), a shunt field, a compensating field, and an interpole or commutating winding. [Figure 5-17] During starting, the C field, compensating, and commutating windings are used. The unit is similar to a direct cranking




Figure 5-16. *Typical starter generator.*




Figure 5-17. *Starter generator internal circuit.*