0			Harness Inspection
Check	Inspection	Date	Inspection Points
			1. Color
			2. Sizing: risers, MLW, chest, leg strap, HZ
			3. 3-ring size
			Leg hardware—orientation, type
			Reserve riser ends—4 pt. W-W, guide rings, toggle stow loops
			6. Chest strap—3 pt. W-W each side
			Articulated harness ring junction—buffers
			8. Upper leg strap—4 pt. W-W, buffers, hardware orientation
			Lower leg strap—stitch pattern, buffers, stop end
			10. TSO label and orientation
			Harness stitching—SPI, backstitch, stop ends, tension
			12. Ripcord pocket—present, secure fit

Procedure

Disassembly

• Mark the locking loop at the bottom edge of the confluence wrap. [Figure A]



- Place a mark at the bottom of the confluence wrap and carefully remove the confluence wrap from the riser.
- Remove the old locking loop.

Reassembly

- 1. Cut a new loop the length of the old one plus 2 inches.
- 2. Fold the new loop in half and lay alongside the old loop. Transfer the marks from the old loop to the new one. [Figure B]
- 3. Align the marks on the loop with the mark at the bottom of the confluence wrap on the riser. [Figure C] Glue the loop in place.
- 4. Sew the loop with the 308 zigzag machine. [Figure D] Set the stitch width at approximately 1/8 inch and 10 SPI.
- 5. Trim the excess loop off at the top. [Figure E]
- 6. Reinstall the confluence wrap using the harness machine. [Figure F]





